ELYKEN HPC

ELYKEN 72-inch Pantry Cabinet Instruction Manual

Model: HPC | Brand: ELYKEN

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your ELYKEN 72-inch Pantry Cabinet, Model HPC. Designed with a farmhouse aesthetic, this tall kitchen storage cabinet offers versatile storage solutions for various household items. Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation.

Image 1.1: The ELYKEN 72-inch Pantry Cabinet, Model HPC, in a kitchen environment, highlighting its overall design and storage potential.

2. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following guidelines:

- **Anti-Tip Kit:** Always secure the cabinet to the wall using the included anti-tip kit to prevent accidental tipping, especially in households with children or pets.

- **Weight Limits:** Do not exceed the specified weight capacities for each shelf and drawer to avoid structural damage or injury.

- **Assembly:** Follow all assembly instructions carefully. Ensure all fasteners are tightened securely before use.
- **Placement:** Place the cabinet on a level, stable surface.

Image 2.1: Product dimensions and individual weight capacities for shelves and drawers. Top shelves support 50 lbs each, bottom shelf 100 lbs, main drawer 50 lbs, and door shelves 35 lbs.

Practical 3 large Pull Out Storage Drawers

The pull out cabinet organizer design allows for easy access to items inside the drawer without bending over or awkwardly reaching

Others | Ours

Image 2.2: Illustration of the anti-tip kit, demonstrating how to secure the cabinet to the wall for enhanced stability and safety.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components and hardware are present and undamaged. Each part is labeled with a serial number for easy identification.

Included Components:

- Cabinet Panels (sides, back, top, bottom)
- Doors (upper and lower sets)
- Drawers (central slide-out drawer, pull-out organizers)
- Shelves (adjustable interior shelves, door shelves)
- Hardware Pack (screws, dowels, hinges, handles, magnetic locks, anti-tip kit)

4. SETUP AND ASSEMBLY

Assembly is required for this pantry cabinet. The instructions provided with the product are designed to be clear and user-friendly. We recommend two adults for efficient assembly.

Assembly Steps:

1. **Unpack and Identify:** Carefully unpack all components and lay them out. Match each part to the corresponding label in the instruction manual.
2. **Prepare Tools:** A Phillips head screwdriver is essential. A cordless drill with an adjustable clutch is recommended for faster assembly, but ensure the clutch is set appropriately to avoid stripping screws.
3. **Assemble Frame:** Follow the step-by-step diagrams to construct the main cabinet frame.
4. **Install Shelves and Drawers:** Insert adjustable shelves into desired positions. Assemble and install the central slide-out drawer and the lower pull-out organizers.
5. **Attach Doors:** Mount the doors using the provided hinges. Ensure proper alignment for smooth opening and closing.

6. **Install Hardware:** Attach handles, magnetic locks, and any decorative metal accents.

7. **Secure Anti-Tip Kit:** Crucially, install the anti-tip kit to anchor the cabinet to a wall stud. This step is vital for safety.

Image 4.1: Detailed view of key hardware features: anti-tip mechanism, decorative metal accents, magnetic door lock, robust safety hinges, and the cabinet's thickened base.

5. OPERATING INSTRUCTIONS

The ELYKEN Pantry Cabinet is designed for versatile storage. Utilize its features to organize your items efficiently.

Key Features:

- **Adjustable Shelves:** The upper cabinet features two adjustable shelves, allowing you to customize the height to accommodate items of various sizes, from tall bottles to stacks of plates.

- **Door Shelves:** Eight door racks provide convenient storage for smaller items such as spice bottles, canned goods,

olive oil, and other frequently accessed pantry staples. This design optimizes space and keeps items visible.

- **Central Slide-Out Drawer:** A large, smooth-gliding drawer in the center offers accessible storage for utensils, dish towels, or other household essentials.

- **Pull-Out Organizers:** The lower section includes three practical pull-out organizers, making it easy to access items stored at the back without bending or reaching awkwardly. These are ideal for heavier items or bulkier pantry goods.

Image 5.1: Overview of the cabinet's interior, detailing the 8 door shelves, top cabinet with adjustable shelves, central drawer, and three pull-out storage racks.

Practical 3 large Pull Out Storage Drawers

※ The pull out cabinet organizer design allows for easy access to items inside the drawer without bending over or awkwardly reaching

Image 5.2: Detailed view of the 8 door shelves, illustrating their capacity for spices and small items, along with their dimensions (e.g., 5.5", 4.9", 7.3", 8.2" heights).

Spacious Storage Drawer

The slide-out drawer offers easy access and organization, ensuring that items inside are always within reach.

Image 5.3: The spacious central slide-out drawer, demonstrating its utility for organizing cutlery, dish towels, and other kitchen accessories.

8 Door Shelves Design
Optimize the cabinet space for easy access

5.5"

4.9"

15.6"

7.3"

8.2"

8.2"

Image 5.4: The three practical pull-out storage drawers, designed for easy access to items without bending, suitable for canned goods, dishes, and other pantry items.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your ELYKEN Pantry Cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Spill Management:** Clean up spills immediately to prevent staining or damage to the engineered wood.

7. TROUBLESHOOTING

If you encounter any issues with your pantry cabinet, refer to the following common solutions:

- **Doors Not Closing Properly:** Check the alignment of the hinges. Loosen the hinge screws slightly, adjust the door position, and then re-tighten. Ensure the magnetic locks are properly aligned and functioning.

- **Cabinet Wobbles:** Verify that the cabinet is placed on a level surface. Adjust any leveling feet if present. Ensure all assembly screws are fully tightened. Confirm the anti-tip kit is securely installed to the wall.

- **Drawers Stick or Don't Slide Smoothly:** Check for any obstructions in the drawer slides. Ensure the drawer is assembled correctly and that the slides are properly installed and lubricated if necessary.

- **Flexing or Instability:** This can occur if the cabinet is overloaded. Review the weight limits specified in Section 2 and redistribute items if necessary. Ensure all structural connections are tight.

8. SPECIFICATIONS

Brand	ELYKEN
Model Number	HPC
Color	Black
Product Dimensions (D x W x H)	15.75" x 30" x 72"
Material	Engineered Wood (MDF, P2), Metal
Item Weight	118 pounds
Overall Weight Limit	133 Pounds
Special Features	3 pull-out shelves, 8 door shelves, Adjustable partitions, Middle large drawer
Mounting Type	Floor Mount (with anti-tip kit for wall securing)
Assembly Required	Yes

9. WARRANTY AND SUPPORT

For specific warranty details and customer support, please refer to the documentation included with your purchase or contact ELYKEN customer service directly. Contact information can typically be found on the product packaging or the official ELYKEN website.

If you require assistance with assembly, missing parts, or have any questions regarding your ELYKEN Pantry Cabinet, please reach out to our support team. Provide your model number (HPC) and purchase details for faster service.