

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [EASE MOOSE](#) /

› EASE MOOSE Sectional Modular Sofa (Corduroy Green, 3 Seat) Instruction Manual

EASE MOOSE B0FC5Z7ZXJ

EASE MOOSE Sectional Modular Sofa (Corduroy Green, 3 Seat) Instruction Manual

Model: B0FC5Z7ZXJ

1. INTRODUCTION

Thank you for choosing the EASE MOOSE Sectional Modular Sofa. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new sofa. The EASE MOOSE modular sofa is designed for comfort and versatility, featuring oversized deep seats, a sturdy solid wood frame, and soft corduroy fabric. Its modular design allows for flexible arrangement to suit various living spaces.

2. SAFETY INFORMATION

- Always follow assembly instructions carefully.
- Ensure all connections are secure before use.
- Do not exceed the maximum weight limit of 350 pounds per seat.
- Keep small parts away from children during assembly to prevent choking hazards.
- Avoid standing or jumping on the sofa.
- Place the sofa on a level surface to prevent instability.
- Keep away from open flames and heat sources.

3. PACKAGE CONTENTS

Your EASE MOOSE Sectional Modular Sofa will arrive in multiple boxes. Please verify all components are present before beginning assembly.

Ease Moose



Dimensions

Overall Size: 117.32" L x 34.25" W x 37.4" H

YOU WILL RECEIVE 4 BOXES!

Box 1: A(Armrest Modules)

Box 2: BL(Middle Module)

Box 3: BR(Middle Module)

Box 4: B(Middle Module)



Image 1: Overview of EASE MOOSE Sectional Sofa dimensions and typical packaging. This image illustrates the overall size of the 3-seat sofa (117.32" L x 34.25" W x 37.4" H) and indicates that it is shipped in four boxes: Box 1 (Armrest Modules), Box 2 (Middle Module), Box 3 (Middle Module), and Box 4 (Middle Module).

Typical Components (3-Seat Sofa):

- Armrest Modules (typically 2)
- Middle Modules (typically 3 for a 3-seat configuration)
- Seat Cushions (corresponding to the number of modules)
- Backrest Pillows (corresponding to the number of modules)
- Armrest Pillows (typically 2)
- Sofa Legs (quantity varies by configuration)
- Connection Brackets (pre-installed or included)

4. SETUP AND ASSEMBLY

Assembly of your EASE MOOSE modular sofa is designed to be straightforward and tool-free, typically completed within 30 minutes. Follow these steps for proper setup:

1. **Unpack Components:** Carefully remove all parts from their packaging. Keep packaging materials for potential returns or disposal.
2. **Attach Legs:** Screw the sofa legs into the designated holes on the bottom of each module. Ensure they are tightened securely.
3. **Connect Modules:** Position the modules in your desired configuration. Use the pre-installed connection brackets on the sides of each module to link them together. Slide the brackets into place until they securely click.
4. **Place Cushions:** Position the seat cushions onto the module bases. The bottom of the cushions features 3D anti-slip fabric to prevent shifting.
5. **Add Backrest and Armrest Pillows:** Place the backrest pillows against the back of each module. The soft cushions and armrests are filled with comfortable 15D silk cotton and are secured in place with Velcro. Fluff pillows as needed to restore their shape after unpacking.

Assembly Video Guide:

Your browser does not support the video tag.

Video 1: This video demonstrates the assembly process for the EASE MOOSE modular sofa, showing how to unpack components, attach legs, connect modules, and place cushions.

Your browser does not support the video tag.

Video 2: This video provides a visual guide to assembling the EASE MOOSE oversized modular sectional, highlighting the ease of connecting modules and arranging the sofa.

Your browser does not support the video tag.

Video 3: This video showcases the assembly and modularity of the EASE MOOSE oversized modular sectional sofa, demonstrating how different pieces fit together.

5. OPERATING INSTRUCTIONS

The EASE MOOSE Sectional Modular Sofa offers flexibility in arrangement and comfortable seating for various activities.

5.1 Rearranging Modules

The modular design allows you to easily reconfigure your sofa layout without tools. Simply lift the modules slightly to disengage the connection brackets, then move them to your desired position and re-engage the brackets. This flexibility makes it suitable for adapting to different room sizes and needs.



Rearrangeable, add or remove modules to fit your evolving needs



Image 2: This image displays various configurations possible with the EASE MOOSE modular sectional sofa, illustrating how modules can be added or removed to fit evolving needs.

5.2 Comfortable Seating

The oversized deep seats (33.86 inches wide x 34.25 inches deep) and increased backrest height (19.7 inches) provide ample space and support for relaxation. The plush, high-density foam cushions offer exceptional comfort and durability.

- oversized spacious seats
- Thick and High Backrests
- Oversized deep seat sofa



Image 3: A person relaxing on the EASE MOOSE sectional sofa, highlighting the oversized deep seat and comfortable backrest dimensions (28.74" deep seat, 19.69" backrest height).

Comfortable armrest design

>Read >Leisure time >Rest and relax



Image 4: This image showcases the comfortable armrest design of the EASE MOOSE sofa, suitable for reading, leisure, and relaxation.

6. MAINTENANCE

Proper care will extend the life and appearance of your EASE MOOSE sofa.

6.1 Cleaning Instructions

The sofa's seat cushions, backrest pillows, and armrest pillows feature removable and washable covers for easy daily cleaning. The corduroy fabric is soft, comfortable, breathable, and resistant to pilling.

1. **Remove Covers:** Unzip and remove the covers from the seat cushions, backrest pillows, and armrest pillows.
2. **Washing:** Machine wash covers on a gentle cycle with cold water and a mild detergent. Avoid bleach.
3. **Drying:** Tumble dry on low heat or air dry. Do not iron. Ensure covers are completely dry before

reattaching.

4. **Spot Cleaning:** For minor spills, blot immediately with a clean, damp cloth. Avoid rubbing, which can spread the stain.



Image 5: This image illustrates the removable and washable covers of the EASE MOOSE sofa, showing a person removing a cover and a washing machine, emphasizing ease of cleaning.

6.2 General Care

- Regularly fluff cushions and pillows to maintain their shape and comfort.
- Vacuum the sofa periodically using a soft brush attachment to remove dust and debris.
- Avoid direct sunlight exposure to prevent fading.
- The fabric is OEKO-TEX certified, free of formaldehyde or harmful phthalates, making it safe for human health and suitable for families with pets.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Cushions appear flat or deflated.	Vacuum-sealed packaging; natural compression over time.	Fluff cushions vigorously upon unpacking and regularly thereafter. Allow 24-48 hours for cushions to fully expand.
Modules are not connecting securely.	Brackets not properly aligned or engaged.	Ensure modules are on a level surface. Realign the connection brackets and push firmly until they click into place.
Sofa feels unstable or wobbly.	Legs are loose or sofa is on an uneven surface.	Check and tighten all sofa legs. Move the sofa to a level surface.
Fabric pilling.	Friction or wear.	While the fabric is designed to resist pilling, if it occurs, use a fabric shaver to gently remove pills.

8. SPECIFICATIONS

Feature	Detail
Brand	EASE MOOSE
Model	Sectional Modular Sofa
Color	Corduroy Green
Size	3 Seat Sofa
Product Dimensions (D x W x H)	34.25"D x 117.32"W x 37.4"H
Seat Depth	28 inches
Seat Height	18.11 Inches
Backrest Height	19.7 inches (from feature bullets)
Arm Height	21.65 Inches
Weight Limit (per seat)	350 Pounds
Seating Capacity	3.0
Frame Material	Solid Wood
Upholstery Material	Corduroy
Fill Material	High-density sponge, 15D silk cotton
Assembly Required	Yes

Feature	Detail
Additional Features	Armrest pillow, Easy to Assemble, Removable Cover, OEKO-TEX certified fabric

9. WARRANTY AND SUPPORT

For specific warranty details and customer support, please refer to the documentation included with your purchase or contact EASE MOOSE customer service directly. General return policy allows for returns/replacements within 30 days of purchase. Extended protection plans may be available for purchase. For further assistance, please visit the [EASE MOOSE Store on Amazon](#).