

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Haier](#) /

> [Haier 8.5kg Top-Load Washing Machine with Automatic Detergent Dispenser and Inverter Technology, Model JW-KD85B](#)

## Haier JW-KD85B

# Haier 8.5kg Top-Load Washing Machine Instruction Manual

Model: JW-KD85B

## 1. IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before using the appliance. Keep this manual for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, or injury.

- Ensure the washing machine is properly grounded.
- Do not operate the machine if it is damaged or malfunctioning. Contact customer service.
- Keep children away from the appliance during operation.
- Do not wash items that have been soiled with flammable substances.
- Unplug the appliance before cleaning or performing any maintenance.

## 2. INSTALLATION AND SETUP

### 2.1 Unpacking

Carefully remove all packaging materials. Inspect the machine for any damage incurred during transit. Retain packaging for potential future transport.

### 2.2 Location Requirements

Place the washing machine on a firm, level surface. Ensure there is adequate space around the machine for ventilation and maintenance. Avoid direct sunlight or excessively humid environments.



**Image Description:** This diagram illustrates the necessary clearance for installation. It shows the product dimensions (57cm depth x 59cm width x 97cm height) and recommends additional space for door frames, entrances, and stairs. For example, an additional 10cm width is required for product dimensions when passing through narrow spaces. For installation, ensure at least 1cm clearance from the left/right wall and 1cm from the rear wall. When opening the top lid, allow 10-15cm clearance above the machine.

### 2.3 Water and Drain Connections

- Connect the water supply hose to the water inlet valve on the back of the machine and to a cold water tap. Ensure connections are tight to prevent leaks.
- Position the drain hose into a standpipe or laundry tub, ensuring it is securely fastened to prevent dislodging during the drain cycle. The drain hose connection should be at least 9cm above the floor.

### 2.4 Leveling the Machine

Use a spirit level to ensure the machine is perfectly level. Adjust the leveling feet at the bottom of the machine as needed. A level machine reduces vibration and noise during operation.

## 3. OPERATING INSTRUCTIONS

### 3.1 Control Panel Overview



**Image Description:** This image shows a close-up of the washing machine's touch control panel. It features an LED display in the center showing remaining time and settings. Buttons for water level, wash, rinse, spin, course selection, power, and start/pause are visible. The panel also indicates the 8.5kg capacity.

### 3.2 Loading Laundry

Open the top lid and load clothes loosely into the tub. Do not overload the machine. For optimal washing performance, ensure clothes can move freely.



**Image Description:** This image provides a top-down view of the Haier washing machine with its glass lid open, revealing the stainless steel wash tub and the pulsator at the bottom. The control panel is visible at the front.

### 3.3 Automatic Detergent Dispenser

The machine features an automatic liquid detergent dispenser. Pour liquid detergent into the designated compartment. The machine will automatically dispense the appropriate amount based on the laundry load, eliminating the need for manual measurement each time.



**Image Description:** This image shows a hand refilling the automatic liquid detergent dispenser located on the top edge of the washing machine. The dispenser is a clear, elongated container designed for easy pouring and monitoring of detergent levels.

### 3.4 Selecting a Wash Course

Turn on the power and select your desired wash course using the control panel. The machine offers various programs tailored for different fabric types and washing needs.



**Image Description:** This image displays a list of available wash courses for the Haier washing machine, including Standard A (daily wash), Standard B (single rinse), My Flow (custom settings), Careful (for jeans and thick items), Quick (for lightly soiled items), Blanket, Tub Air Dry, Fragrance Up (to enhance fabric softener scent), Dry (for delicate items), and Tub Cleaning.

#### Available Courses:

- **Standard A:** For everyday laundry.
- **Standard B:** For everyday laundry with a single rinse.
- **My Flow:** Allows you to save and use your preferred custom settings.
- **Careful:** Suitable for washing items like jeans and thick fabrics.
- **Quick:** A 10-minute cycle for lightly soiled items, reducing household chores. (Max 2.0kg load)
- **Blanket:** For washing blankets and large items.
- **Tub Air Dry:** Reduces drying time and is ideal for indoor drying.
- **Fragrance Up:** Ensures fabric softener scent adheres evenly to clothes, enhancing the fragrance effect.
- **Dry:** For delicate items.
- **Tub Cleaning:** For regular cleaning of the wash tub.

### 3.5 Starting the Wash Cycle

Press the Start/Pause button to begin the selected wash cycle. The machine will automatically fill with water, dispense detergent, wash, rinse, and spin.

### 3.6 Special Features

- **High Concentration Spiral Wash:** Creates a high-concentration detergent solution and powerful spiral water flow to effectively remove dirt.
- **Wrinkle-Reducing Spin:** Adjusts spin time and rotation speed to minimize wrinkles, reducing ironing time. (Max 1.0kg load)
- **DD Inverter Motor:** Direct drive inverter motor ensures low noise and low vibration operation, allowing for quiet washing even at night.

※画像はイメージです。

# 「高濃度スパイラル洗浄」

## 高濃度洗浄液×らせん状水流でしっかりキレイ


① 洗剤を少ない水で溶かし、  
高濃度洗浄液を作る



③ 水位を上げて、強力ならせん状水流で  
しっかり洗い流す



② 繊維に高濃度洗剤液をすばやく浸透させ、  
効率よく汚れを浮かせる



**Image Description:** This image highlights the washing machine's high cleaning power. It shows a shirt being washed in a powerful spiral water flow, alongside diagrams of the high-concentration spiral wash, 3D wing pulsator, and checkered tank design, all contributing to effective dirt removal.



**高濃度スパイラル洗浄**

高濃度の洗浄液で  
効率的に仕上げる



**3Dウイングパルセーター**

らせん状水流で  
しっかり洗える



**チェックカードタンク**

丸みのある凹凸で  
衣類を傷めずもみ洗い

**Image Description:** This diagram illustrates the internal structure of the DD Inverter motor, emphasizing its benefits: low noise, low vibration, and energy saving. It explains that the direct connection to the wash tub and precise control of rotation speed and friction contribute to reduced energy consumption.

## 4. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and extends the lifespan of your washing machine.

### 4.1 Cleaning the Tub

Use the 'Tub Cleaning' course regularly to prevent mold and mildew buildup in the wash tub. The 'Quick Tub Cleaning' function takes approximately 2 minutes and is recommended after each wash cycle to suppress mold growth.

# 購入後も日本全国で充実の アフターサービス

ハイアールは、日本全国47都道府県で365日、  
製品の修理、ご相談などを承ります。  
安心して長くご使用いただくために、ハイアールはお客さまとの  
お付き合いを大切にしていきたいと考えています。

## 充実のサポート

日本全国対応



ハイアール アクア  
サービス

365日受付サービス



ハイアール  
カスタマセンター

**Image Description:** This image shows the interior of the washing machine tub during a 'Quick Tub Cleaning' cycle, with water swirling inside. A timer indicating '2 minutes' is overlaid, highlighting the short duration of this maintenance function.

### 4.2 Cleaning the Detergent Dispenser

The automatic liquid detergent dispenser tank (approx. 540ml capacity) is removable for easy cleaning. Periodically remove and rinse it thoroughly to prevent residue buildup.

### 4.3 Cleaning the Lint Filter

Regularly clean the lint filter to ensure efficient lint removal and prevent drainage issues. Refer to the diagram in the full manual for filter location and removal instructions.

### 4.4 Exterior Cleaning

Wipe the exterior of the machine, including the glass top, with a soft, damp cloth. The flat glass top design makes cleaning easy.

## 5. TROUBLESHOOTING

Before contacting customer service, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Machine does not start	Power cord unplugged, lid not closed, water supply off.	Check power connection, ensure lid is fully closed, open water tap.

Problem	Possible Cause	Solution
Excessive vibration/noise	Machine not level, overloaded, foreign objects in tub.	Level the machine, reduce load, check for and remove foreign objects.
Water leakage	Loose hose connections, clogged drain hose.	Tighten hose connections, clear drain hose.
Detergent not dispensing	Dispenser tank empty, clogged dispenser.	Refill dispenser, clean dispenser tank.

## 6. PRODUCT SPECIFICATIONS

**Brand:** Haier

**Model Number:** JW-KD85B

**Product Dimensions (D x W x H):** 57 cm x 59 cm x 97 cm

**Capacity:** 8.5 kg

**Item Weight:** 40 kg

**Color:** White

**Voltage:** 100 V (AC)

**Noise Level:** 38 dB

**Control Type:** Touch Screen (LED Display)

**Operation Mode:** Fully Automatic

**Number of Programs:** 13

**Special Features:** Inverter, Start Reservation Timer, Child Lock, Drum Clean, Automatic Detergent Dispenser

**Tub Material:** Stainless Steel

**Included Components:** Magic hose connection (1), Bottom cover (with 1 screw), Liquid detergent auto dispenser tank (1), Water supply hose (1)

## 7. WARRANTY INFORMATION

This Haier washing machine (Model JW-KD85B) comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included with your product or contact Haier customer support.

## 8. CUSTOMER SUPPORT

For any inquiries, technical assistance, or service requests, please contact Haier customer support. Haier offers comprehensive after-sales service across Japan.



何人暮らし?



## ライフスタイル別 洗濯量とおすすめ洗濯機容量

	毎日	2日に1回	3~4日に1回	週末洗い
1人	1.5kg	3kg	4.5kg	7.5kg
2人	3kg	6kg	9kg	15kg
3人	4.5kg	9kg	13.5kg	22.5kg
4人	6kg	12kg	18kg	30kg
5人	7.5kg	15kg	22.5kg	37.5kg

### 洗濯量は洗濯機容量の7割までがおすすめ

洗濯機容量	14kg	12kg	10kg	8kg
実洗濯量	~9.5kg	~8kg	~7kg	~5.5kg
洗濯機容量	7kg	6kg	5.5kg	4.5kg
実洗濯量	~4.5kg	~4kg	~3.5kg	~3kg

**Image Description:** This image highlights Haier's nationwide after-sales service in Japan, available 365 days a year. It shows icons representing nationwide coverage across 47 prefectures and a 365-day reception service, indicating support from Haier Aqua Service and Haier Customer Center for repairs and consultations.

**Haier Customer Center:** Available 365 days a year for consultations and repairs.

Please visit the official Haier website or refer to the contact information provided in your product documentation for the most up-to-date support details.