

[Manuals.plus](#) /

> [YESHOMY](#) /

> YESHOMY Glass Fireplace TV Stand User Manual

YESHOMY YH-0270-GYNEW

YESHOMY Glass Fireplace TV Stand User Manual

Model: YH-0270-GYNEW

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your YESHOMY Glass Fireplace TV Stand. Please read this manual thoroughly before assembly and use to ensure safe and efficient operation of the product. Keep this manual for future reference.

Product Overview

The YESHOMY Glass Fireplace TV Stand is designed to accommodate televisions up to 65 inches, featuring a media entertainment center console with closed storage doors and an integrated electric fireplace. Its light grey finish and modern aesthetic are intended to complement various interior designs.

2. SAFETY INFORMATION

Always adhere to the following safety guidelines to prevent injury or damage to the product.

- Ensure all components are present and undamaged before beginning assembly.
- Do not exceed the maximum weight limit of 300 lbs for the TV stand.
- Use anti-tip hardware as instructed to secure the unit and prevent tipping.
- Keep children and pets away from the assembly area.
- Do not block the air vents of the electric fireplace.
- Only use the fireplace indoors and on a stable, level surface.
- Unplug the fireplace from the power outlet before cleaning or maintenance.

3. PACKAGE CONTENTS

Verify that all parts are included in your package. The item typically arrives in two separate packages, which may not arrive on the same day.



Image: Illustration showing two boxes and delivery process, indicating the product ships in two packages.

Refer to the included parts list in your assembly guide for a detailed inventory of all components and hardware.

4. SPECIFICATIONS

Product Specifications	
Feature	Detail
Brand	YESHOMY
Model Name	Glass Fireplace TV Stand
Model Number	YH-0270-GYNEW
Color	Light Grey

Feature	Detail
Product Dimensions (W x H x D)	59"W x 31.6"H x 13.7"D
Weight Limit (Top)	132 lbs (60 KG)
Weight Limit (Shelf)	33 lbs (15 KG)
Material	Tempered Glass, E1 Particleboard, Alloy Steel
Assembly Required	Yes
Fireplace Heating Area	Up to 400 sq.ft.
Fireplace BTU	5118 BTU




Image: Dimensional diagram of the TV stand, indicating overall width (59"), height (31.6"), depth (13.7"), and internal shelf dimensions, along with weight limitations for the top (132 lbs) and shelves (33 lbs).

5. SETUP AND ASSEMBLY

The YESHOMY Glass Fireplace TV Stand features modular construction designed for fast and stress-free assembly, typically within 15 minutes. It is recommended to assemble the unit with at least two people.

Before You Begin:

- Clear a spacious area for assembly.
- Lay out all components on a soft, clean surface to prevent scratches.
- Identify all parts and hardware using the included assembly guide.
- Ensure you have the necessary tools (e.g., screwdriver, if not provided).

Assembly Steps:

1. Unpack all components carefully from the two packages.
2. Follow the step-by-step instructions provided in the separate assembly manual.
3. Attach the main frame components, ensuring all connections are secure.
4. Install the tempered glass panels and doors according to the instructions.
5. Integrate the electric fireplace unit into the designated central compartment.
6. Secure the unit to the wall using the provided anti-tip hardware for enhanced stability.
7. Adjust the feet as needed to ensure the stand is level on uneven surfaces.



Image: A fully assembled light grey YESHOMY Glass Fireplace TV Stand, showcasing its design with a television placed on top, an integrated electric fireplace, and decorative items in the side cabinets.



Image: The YESHOMY TV stand with a television placed on top, visually demonstrating its compatibility with TVs up to 65 inches.

6. OPERATING THE ELECTRIC FIREPLACE

The integrated 24" 3D Panoramic Fireplace provides both aesthetic ambiance and heating functionality.

Features:

- Remote-controlled operation.
- 5118 BTU heating capacity, suitable for heating areas up to 400 sq.ft.
- Adjustable temperature range: 62°F-82°F.
- Three flame models/colors (e.g., orange, blue, mixed).
- Timer function (maximum 6 hours).
- Power consumption: 900W.

ALL-GLASS SURFACE



Image: A detailed view of the 24-inch 3D panoramic electric fireplace unit, showing its control panel, heating element, and various flame color options (orange, blue, and mixed). Key features like temperature range, BTU, timer, and wattage are also indicated.

Basic Operation:

1. Plug the fireplace power cord into a standard electrical outlet.
2. Use the remote control or the control panel on the fireplace to turn the unit on/off.
3. Adjust the flame brightness and color using the dedicated buttons.
4. Set the desired temperature for heating.
5. Utilize the timer function to automatically shut off the fireplace after a set duration.

7. CARE AND MAINTENANCE

Proper care will extend the life and maintain the appearance of your TV stand.

Cleaning the TV Stand:

- The tempered glass surfaces are smudge-resistant with an anti-fingerprint coating. Wipe with a soft, dry microfiber cloth.
- For the E1 particleboard and alloy steel frame, wipe with a damp cloth.
- Avoid using harsh chemical cleaners, abrasive materials, or polishes, as these can damage the finish.
- The nano-coated, waterproof base resists spills and stains; wipe up spills immediately.

24" 3D PANORAMIC FIREPLACE

with remote-controlled, 5118 BTU, heating for up to 400 sq.ft.



62F-82F



3 Model



Timer
(Maximum 6 Hours)



900W



NOTE: The item arrives in 2 packages, possibly not on the same day



Image: A close-up view highlighting the all-glass surface of the TV stand, emphasizing its smooth, reflective quality and modern design.

Fireplace Maintenance:

- Ensure the fireplace is unplugged before cleaning.
- Dust the exterior surfaces with a soft, dry cloth.
- Do not attempt to open or service the internal components of the fireplace. Refer to qualified service personnel if issues arise.

8. TROUBLESHOOTING

This section addresses common issues you might encounter.

Common Issues and Solutions

Problem	Possible Cause	Solution
Fireplace does not turn on.	Not plugged in; power outlet issue; remote battery dead.	Ensure power cord is securely plugged in. Test outlet with another device. Replace remote control batteries.
No heat from fireplace.	Heating function not activated; thermostat setting too low.	Activate heating function via remote/panel. Increase thermostat setting.
Stand is wobbly after assembly.	Uneven floor; loose connections; anti-tip hardware not installed.	Adjust leveling feet. Retighten all screws and bolts. Install anti-tip hardware as per instructions.
Doors do not align properly.	Hinges not adjusted correctly.	Adjust door hinges as per assembly guide to ensure proper alignment.

If you encounter issues not listed here, or if the suggested solutions do not resolve the problem, please contact customer support.

9. WARRANTY AND CUSTOMER SUPPORT

YESHOMY offers a 365-day warranty for this product. For warranty claims, replacement parts, assembly assistance, or styling tips, please contact YESHOMY customer support. You can typically find contact information on the manufacturer's website or through your purchase platform. Please have your model number (YH-0270-GYNEW) and purchase date ready when contacting support.

- **Customer Support:** Refer to your purchase documentation or the YESHOMY official website for contact details.
- **Returns:** This product is eligible for 30-day easy returns.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FC62RWF9>

More documents and user manuals: <https://manuals.plus/>