

Tineco Floor One S7 Artist

Tineco Floor One S7 Artist Wet Dry Vacuum Cleaner Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Tineco Floor One S7 Artist Wet Dry Vacuum Cleaner. Please read all instructions carefully before first use and retain this manual for future reference.

The Tineco Floor One S7 Artist is designed for superior floor cleaning with advanced features:

- **Elegant & Aesthetic Design:** Inspired by the Aurora Borealis, blending sky tones with vibrant aurora hues for a naturally beautiful home aesthetic.
- **Unmatched 22kPa Suction Power & 50-Min Runtime:** Deep cleans with industry-leading suction while offering extended runtime for uninterrupted cleaning.
- **180° Ultra-Slim Lay-Flat Design:** Compresses to just 5.06-inch, gliding effortlessly under beds, sofas, and low-clearance areas, ensuring no dust or hair is left behind.
- **Flashdry Self-Cleaning System:** Using heated fresh water to effectively dissolve stains from the pipe to the brush roller, and then using 185°F hot air to effectively dry every part of the machine. Truly worry-free after use.
- **DualBlock Anti-Tangle Design:** The dual-layer scrapers prevent hair tangling and clogging by capturing hair with a comb scraper and wiping away dirty water and hair with a straight scraper.


SETUP

Before using your Tineco Floor One S7 Artist, ensure all components are correctly assembled and the device is fully charged.

What's Included

Your package includes the main unit, a replacement brush roller, a cleaning tool, a drying & charging dock, and a cleaning solution.

What's included



Dry Filter



Brush Roller



Cleaning Tool



Drying & Charging Dock



Cleaning Solution




Image: All components included with the Tineco Floor One S7 Artist, laid out for inspection.

Assembly and Initial Charge

Assemble the handle to the main body until it clicks into place. Place the unit on the drying & charging dock and connect the power adapter. Allow the device to fully charge before first use. The display will indicate charging status.

Filling the Clean Water Tank

Open the clean water tank cap. Fill the tank with clean tap water. For optimal cleaning, ensure the water is at room temperature or slightly warm. Do not add cleaning solutions if using steam mode.

Up to 50* mins Runtime

Upgraded Pouch Cells

up to **50min**
Battery Runtime

*In lay-flat state with auto mode. Actual runtime may vary based on home environment and user habits

Image: The Tineco Floor One S7 Artist in various positions, highlighting its extended runtime and ability to clean under furniture.

OPERATING

The Tineco Floor One S7 Artist offers multiple cleaning modes and smart features for a customized cleaning experience.

Cleaning Modes

The device features Auto, Max, and Suction modes. Additionally, a dedicated Steam mode provides enhanced sanitization. Select the appropriate mode via the display on the handle.

iLoop Smart Sensor Technology

The iLoop Smart Sensor automatically detects dirt and debris on your floor and adjusts suction power and water flow accordingly, ensuring efficient cleaning without manual adjustments.



Image: A graphic representation of the iLoop Smart Sensor technology, illustrating how the device automatically adjusts cleaning power based on detected dirt levels.

180° Lay-Flat Design

The unique 180° lay-flat design allows the vacuum to compress to just 5.06 inches, enabling it to reach and clean under low-clearance furniture like beds and sofas with ease.



Image: A person demonstrating the 180° lay-flat design of the Tineco Floor One S7 Artist, showing how it can easily clean under low furniture.

Dual-Edge Cleaning

The dual-sided edge cleaning feature ensures thorough cleaning right up against baseboards and into corners, leaving no dirty spots behind.

180° Lay-Flat Design



Image: Two individuals using the Tineco Floor One S7 Artist, showcasing its dual-sided edge cleaning capability to clean close to walls and furniture.

Official Product Videos

For a visual guide on operating your Tineco Floor One S7 Artist, please refer to the official product videos below:

Video: Tineco Artist S9 STEAM Cordless: FULL review + Pros & Cons. This video provides a comprehensive review of the Tineco Floor One S9 Artist Steam, including its features, performance, and potential drawbacks. While the video title mentions S9, the content is relevant to the Artist series' steam functionality.

Video: Tineco Floor One S9 Artist Steam Showcase. This video demonstrates the key features and cleaning capabilities of the Tineco Floor One S9 Artist Steam, offering a visual overview of its operation. While the video title mentions S9, the content is relevant to the Artist series' steam functionality.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Tineco Floor One S7 Artist.

Flashdry Self-Cleaning System

After each use, place the device on the charging dock and activate the Flashdry self-cleaning cycle. This system uses heated fresh water to clean the brush roller and internal pipes, followed by 185°F hot air to thoroughly dry all components, preventing odors and bacterial growth.



Image: A visual breakdown of the Flashdry self-cleaning system, showing heated water cleaning and 185°F hot air drying the brush roller.

DualBlock Anti-Tangle Design

The DualBlock Anti-Tangle Design minimizes hair wrapping around the brush roller. Regularly check and clean the brush roller and scrapers to maintain optimal performance.

FlashDry Self-Cleaning



Step 1: Self-cleaning with Heated Water



Step 2: 5-minute Drying with 185°F Air

Image: A comparison illustrating the effectiveness of the DualBlock Anti-Tangle Design in preventing hair from tangling around the brush roller.

Emptying Dirty Water Tank and Filter Care

Empty the dirty water tank after each cleaning session. Remove and rinse the HEPA filter regularly to ensure consistent suction power. Allow the filter to air dry completely before reinserting.

TROUBLESHOOTING

Can I use it on carpet?

No, the Tineco Floor One S7 Artist is designed for hard floors only. Using it on carpets, especially with steam, can potentially damage delicate carpet fibers.

Can I use cleaning solution?

You may use a gentle cleanser if operating the device without steam power. However, if you plan to use Steam mode, do not add cleaning solutions to the water tank. The high temperature of the steam is sufficient for sanitization, and cleaners could be vaporized into the air or damage the unit.

SPECIFICATIONS

Feature	Detail
Brand	Tineco
Model Name	Floor One S7 Artist
Special Feature	185°F Flashdry Self-cleaning, DualBlock Anti-Tangle, Foldable, High Power, Tineco MHCBS Technology
Filter Type	HEPA Filter
Included Components	Replacement Brush Roller, Cleaning Tool, Drying & Charging Dock
Is Cordless?	Yes
Capacity	1 Liters
Wattage	190 watts
Form Factor	Upright
Color	Artist Grey
Product Dimensions	10.49"L x 8.66"W x 43.31"H
Noise Level	78 Decibels
Battery Life	50 minutes
Item Weight	11 pounds
Surface Recommendation	Hard Floor, Hardwoods, Laminate, Multi Surface
Power Source	Battery Powered

WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please visit the official Tineco website or

contact Tineco customer service. Retain your proof of purchase for warranty claims.