

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [Vongrasig](#) /

> Vongrasig Convertible Sectional Couch Instruction Manual

## Vongrasig Convertible Sectional Couch B0FC67VHPV

# Vongrasig Convertible Sectional Couch Instruction Manual

Model: Convertible Sectional Couch B0FC67VHPV

## IMPORTANT SAFETY INFORMATION

---

Please read and understand all instructions before assembly and use. Keep this manual for future reference. Failure to follow these instructions may result in injury or product damage.

- Ensure all components are present and undamaged before assembly.
- Do not use power tools for assembly unless specifically instructed, as overtightening may damage the product.
- Place the sofa on a level, stable surface.
- Do not exceed the maximum weight limit of 600 pounds.
- Keep children and pets away from the assembly area.
- Regularly check all fasteners to ensure they remain tight.

## PACKAGE CONTENTS

---

Verify that all parts listed below are included in your package:

- Sofa sections (3 seat cushions, backrests, armrests)
- Ottoman (with storage)
- Wooden legs
- Hardware pack (screws, washers, etc.)
- Assembly instructions (this manual)



Figure 1: Sofa components including thick seat cushions, solid wood frame, and sturdy legs.

## SETUP AND ASSEMBLY

Assembly is required for this product. No additional tools are needed. Please follow these steps carefully:

1. **Unpack all components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach the legs:** Securely screw the wooden legs into the designated holes on the bottom of each sofa section and the ottoman. Ensure they are tightened firmly.
3. **Connect sofa sections:** Align the connectors on the sofa sections and slide them together until they lock into place.
4. **Attach armrests:** Slide the armrests onto the sofa ends from the bottom up, ensuring they are fully seated and secure.
5. **Place cushions:** Position the seat cushions and back cushions onto the sofa frame. The seat cushions have Velcro to prevent sliding.
6. **Position ottoman:** Place the ottoman next to any sofa section to create an L-shaped configuration or use it

independently.

Your browser does not support the video tag.

Video 1: Demonstrates the Vongrasig Convertible Sectional Couch for Living Room, highlighting its features and versatility. This video is provided by a seller-type creator.



Figure 2: The flexible movable ottoman can be positioned on either side to create different L-shaped sofa configurations or used as a standalone piece.

## OPERATING INSTRUCTIONS

The Vongrasig Convertible Sectional Couch is designed for versatile use in various living spaces.

- **Convertible Design:** The ottoman can be moved to either the left or right side of the sofa to create an L-shaped chaise lounge, allowing for flexible room arrangements.
- **Storage Functionality:** The ottoman features a hidden storage compartment. Lift the top cushion to access space for blankets, magazines, or other small items.

- **Comfort Features:** The sofa is equipped with 5.5-inch high-density sponge cushions and soft linen fabric for optimal comfort.

## WHY CHOOSE US ?

✓ OURS



VS

⊗ OTHERS



Figure 3: The ottoman provides extra storage for various household items, keeping your living space tidy.

## MAINTENANCE AND CARE

Proper care will extend the life and appearance of your sofa.

- **Cleaning:** The armrests, seat cushions, and back covers are detachable for easy cleaning. Spot clean with a damp cloth and mild detergent. For deeper cleaning, follow fabric care instructions.
- **Cushion Care:** Fluff cushions regularly to maintain their shape and comfort.
- **Frame Care:** Wipe the wooden frame and legs with a dry cloth. Avoid harsh chemicals.
- **General Care:** Keep the sofa away from direct sunlight and heat sources to prevent fading and material degradation.



Figure 4: Key features of the sofa, including washable covers for easy maintenance.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Sofa feels unstable or wobbly.	Legs are not tightened or uneven surface.	Ensure all legs are securely tightened. Move the sofa to a level surface.
Cushions appear flat or lose shape.	Normal wear and tear, lack of fluffing.	Regularly fluff and rotate cushions to restore shape.
Difficulty connecting sofa sections.	Misalignment of connectors.	Ensure connectors are properly aligned before pushing sections together. Refer to assembly instructions.

## SPECIFICATIONS

Feature	Detail
Brand	Vongrasig
Model	Convertible Sectional Couch
Seating Capacity	3
Weight Limit	600 Pounds
Product Dimensions (D x W x H)	49.2"D x 79.1"W x 34.2"H
Item Weight	133 Pounds
Material	Linen Fabric, High-Density Sponge Cushion, Wood Frame
Assembly Required	Yes
Included Components	Hardware, Ottoman

# PRODUCT DIMENSION



**Weight Capacity: 600lbs**

Tips: Please measure the size of your space before ordering

Figure 5: Detailed product dimensions, including depth, width, and height, and weight capacity.

## WARRANTY INFORMATION

This Vongrasig product comes with a Limited Warranty. For specific details regarding coverage and duration, please refer to the warranty documentation included with your purchase or contact customer support.

## CUSTOMER SUPPORT

For assistance with assembly, parts, or any other inquiries, please contact Vongrasig customer support:

- **Online:** Visit the [Vongrasig Store on Amazon](#)
- **Seller:** Viogarden Direct (for purchases made through this seller)



