

[Manuals.plus](#) /

› [KOOFORWAY](#) /

› KOOFORWAY P8 Mini Laptop 8-inch HD Touchscreen Portable User Manual

KOOFORWAY P8

KOOFORWAY P8 Mini Laptop User Manual

Model: P8 | Brand: KOOFORWAY

WELCOME

Thank you for choosing the KOOFORWAY P8 Mini Laptop. This portable 2-in-1 device combines the functionality of a laptop with the versatility of a tablet, designed for productivity and entertainment on the go. This manual provides essential information for setting up, operating, and maintaining your device.

Key Features:

- 8-inch HD Touchscreen with 180° rotation for laptop and tablet modes.
- Powered by Intel N100 processor with 12GB LPDDR5 RAM and 512GB SSD.
- Pre-installed with Windows 11 Pro for a clean and efficient operating experience.
- Compact, full-metal body with USB 3.0, USB-C, HDMI, and headphone jack.
- Integrated Wi-Fi 6 and Bluetooth 5.2 for seamless connectivity.

WHAT'S IN THE BOX

Please verify that all items are present in your package:

- KOOFORWAY P8 Mini Laptop
- Power Adapter/Charger
- Stylus Pen
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the physical components and ports of your KOOFORWAY P8 Mini Laptop.

Device Layout



Image: The KOOFORWAY P8 Mini Laptop in laptop mode, displaying its key specifications and included stylus.

Ports and Connectors

WIDELY USED HIGH-END INTERFACES

UNIVERSAL APPLICATION EXPANSION PORT



Image: Detailed view of the left side of the KOOFORWAY P8 Mini Laptop, highlighting the various input/output ports including USB-C, HDMI, DC power, USB 3.0, speaker, and RJ45 Ethernet port.

- **USB-C Port:** For data transfer and charging.
- **HDMI Port:** Connect to external displays.
- **DC Power Input:** Dedicated port for charging.
- **USB 3.0 Port:** Connect USB devices.
- **Speaker:** Audio output.

- **RJ45 Ethernet Port:** For wired network connection.
- **Headphone Jack:** For audio output to headphones or external speakers.

INITIAL SETUP

1. Charging the Device

Before first use, fully charge your KOOFORWAY P8 Mini Laptop. Connect the provided power adapter to the DC power input port on the device and then to a power outlet. The charging indicator light will illuminate.

2. First Power On

Press and hold the power button (located on the keyboard, typically the rightmost key on the top row) until the screen illuminates. Follow the on-screen instructions to complete the Windows 11 Pro setup, including language, region, network connection, and user account creation.

3. Connecting Peripherals

Wi-Fi Connection:

During initial setup or via Windows settings, select your Wi-Fi network and enter the password to connect. The device supports Wi-Fi 6 for faster wireless connectivity.

Bluetooth Devices:

To pair Bluetooth devices (e.g., headphones, mouse), go to Windows Settings > Bluetooth & devices, turn on Bluetooth, and select "Add device."

Stylus Pen:

The included stylus pen is rechargeable. Ensure it is charged before use. It does not require Bluetooth pairing and is ready for use on the touchscreen once powered on.

OPERATING YOUR KOOFORWAY P8

Basic Navigation

The KOOFORWAY P8 offers multiple input methods:

- **Touchscreen:** Use gestures for navigation, tapping, swiping, and pinching to zoom.
- **Keyboard:** Standard QWERTY layout for typing. Note that some function keys (F1-F12) may require pressing the 'Fn' key simultaneously.
- **Trackpad:** The integrated trackpad allows for cursor control and multi-touch gestures.

Using 2-in-1 Modes

The 180° rotating screen allows for flexible usage modes:

HANDHELD COMPUTER

8-Inch Touch Screen/Tablet Laptop 2-in-1



intel@cpu
Nseries



12G
Lpddt5



0.78KG



2 Mogapixcl
Camrea



8-inch Sun
Screen



FLIP



NORMAL



TABLET

Image: The KOOFORWAY P8 Mini Laptop shown in three configurations: traditional laptop mode, flipped screen mode, and tablet mode, illustrating its 2-in-1 functionality.

- **Laptop Mode:** Standard configuration with keyboard and screen.
- **Tablet Mode:** Fold the screen back 180 degrees to use as a tablet. The keyboard will automatically disable.
- **Tent/Stand Mode:** Position the device in various angles for media consumption or presentations.

Stylus Pen Usage

The included stylus pen enhances interaction with the touchscreen for precise input, drawing, and note-taking.



Image: A hand using the stylus pen on the KOOFORWAY P8 Mini Laptop's touchscreen, demonstrating its touch-enabled capabilities for creative tasks or detailed input.

Connecting to an External Display

Use the HDMI port to connect your KOOFORWAY P8 to an external monitor or projector. Connect an HDMI cable from the laptop to the display, then configure display settings in Windows (right-click on desktop > Display settings).

Product Demonstration Video

Your browser does not support the video tag.

Video: A demonstration of the KOOFORWAY P8 Mini Laptop's features, including its compact design, 2-in-1 functionality, stylus input, and various connectivity options.

CARE AND MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. For stubborn marks, slightly dampen the cloth with water or a screen cleaner. Avoid harsh chemicals.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. For long-term storage, charge the battery to about 50-70%.
- **Software Updates:** Regularly update Windows and drivers to ensure optimal performance and security.

TROUBLESHOOTING COMMON ISSUES

- **Device does not power on:** Ensure the device is charged. Connect the power adapter and try again. If the battery is completely drained, it may take a few minutes before it can power on.
- **Screen is blank or unresponsive:** Try restarting the device. If unresponsive, press and hold the power button for 10-15 seconds to force a shutdown, then power on again.
- **Wi-Fi connection issues:** Check if Wi-Fi is enabled in Windows settings. Restart your router and the laptop. Ensure you are within range of the Wi-Fi signal.
- **Stylus not working:** Ensure the stylus is charged. If issues persist, check Windows settings for pen and touch input.
- **Device overheating:** Ensure proper ventilation. Avoid blocking air vents. Reduce heavy workload if overheating persists.

TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	KOOFORWAY
Model Name	P8
Operating System	Windows 11 Pro
Screen Size	8 Inches
Screen Resolution	1280 x 800 pixels
Processor	Intel N100 (up to 3.4GHz)
RAM	12 GB LPDDR5
Storage	512 GB M.2 SSD
Graphics	Intel UHD Graphics (Integrated)
Wireless Connectivity	Wi-Fi 6, Bluetooth 5.2
Ports	USB 3.0 (x2), USB-C, HDMI, RJ45, Headphone Jack

Battery Life	Approximately 4-5 hours (usage dependent)
Item Weight	1.7 pounds (0.78 kg)
Product Dimensions	7.8 x 5.5 x 0.8 inches

WARRANTY INFORMATION AND CUSTOMER SUPPORT

Your KOOFORWAY P8 Mini Laptop comes with a 1-year limited warranty. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external causes.

For technical assistance, warranty claims, or any questions regarding your device, please contact KOOFORWAY customer support. Refer to the contact information provided on the product packaging or the official KOOFORWAY website.

Please retain your proof of purchase for warranty service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

My KOOFORWAY P8 Mini Laptop, purchased in May, suddenly won’t turn on. How can I fix this or claim a warranty repair?

If your KOOFORWAY P8 Mini Laptop is not turning on after you have already tried charging and holding the power button, please try these specific steps from the manual:Force a Hard Reset: Press and...

[Read full answer](#)

