

[Manuals.plus](#) /

› [AISLPC](#) /

› AISLPC R36T Retro Gaming Console User Manual

AISLPC R36T

AISLPC R36T Retro Gaming Console User Manual

1. INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your AISLPC R36T Retro Gaming Console. Please read this manual thoroughly to ensure proper use and to maximize your gaming experience.

2. WHAT'S IN THE BOX

Verify that all items listed below are included in your package:

- 1 x Handheld Game Console (R36T)
- 1 x Portable Storage Bag
- 1 x Type-C Charging Cable
- 1 x Instruction Manual
- 1 x 64GB TF Card (pre-installed)

16 Adjustable Light Effects, 16 Million Colors RGB Colorful Light Ring, Lights Can Be Freely Turned ON or OFF.

Breathing Light Quick Settings:
Using the Frontend Interface - START - EmuELEC SETTINGS - LED MODE



Always mode



Breath
light fast



Simulator
Phantom



Joystick
Chasing light



Monochromatic
Rainbow



Multicolor
Rainbow

Customize Colors



Customize Brightness




Figure 2.1: Package contents including the console, case, charging cable, and manual.

3. PRODUCT OVERVIEW

The AISLPC R36T is a retro handheld gaming console designed for portable entertainment. It features a 3.5-inch IPS screen with a CRT-inspired display, a high-precision joystick with customizable RGB lighting, and supports a wide range of retro game emulators.

3.1 Console Layout



Figure 3.1: Front view of the R36T console, showing the screen, controls, and joystick.

- **3.5-inch IPS Screen:** Full-viewing angle display with 640*480 resolution, featuring CRT-inspired bezels.
- **Controls:** D-pad, A/B/X/Y buttons, SELECT/START buttons, FN button, and a high-precision joystick with RGB lighting.
- **Shoulder Buttons:** L1, L2, R1, R2 buttons located on the rear of the console for enhanced gameplay.
- **Ports:** Type-C charging port, OTG port (for external display/accessories), 3.5mm headphone jack.
- **TF Card Slot:** Supports a 64GB TF card for game storage.
- **Speakers:** Built-in speakers for audio output.

3500mAh 5V Li-Porechargeable Larger Battery Capacity and Long Battery Life

Support C2C charger, Enjoy to 6-8 Hours Gaming Time.



Type-C Charge Cable Fast charging
Input Power: MAX 5V 2A Fast Charging

Figure 3.2: The high-precision joystick features 16 million colors and 16 adjustable light effects.

PACKING LIST



R36T Retro Handheld
Game Console * 1



Storage Box * 1



TYPE-C Charging Cable
* 1



Manual
* 1



64GB TF CARD
*1

Figure 3.3: The console is equipped with a 3500mAh battery, providing 6-8 hours of gameplay.

3.2 Product Videos

Video 3.1: An overview of the R36T Retro Gaming Console, demonstrating its features and design. This video provides a general introduction to the device and its capabilities.

Video 3.2: A detailed look at the R36T Retro Gaming Console's 3.5-inch IPS screen, showcasing its display quality and retro aesthetic. This video highlights the visual aspects of the console.

4. SETUP

4.1 Charging the Console

1. Connect the provided Type-C charging cable to the DC port on the console.
2. Connect the other end of the cable to a compatible USB power adapter (not included).
3. The host's red light will turn on, indicating that the console is charging.
4. The red light will automatically turn off when the console is fully charged.
5. Do not press the reset button while charging. The charger must not exceed 5V/2A.

4.2 TF Card Installation

The 64GB TF card comes pre-installed with over 18000+ classic games. If you need to remove or reinsert the card:

- Gently push the TF card into its slot until it clicks to secure it.
- To remove, gently push the card again until it springs out.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Press and hold the power button for 5 seconds. Wait patiently for approximately 20 seconds for the operating interface to appear.
- **Power Off:** Press and hold the power button for 7 seconds to display the shutdown menu. Press the A button to confirm shutdown.
- Please exit the game before shutting down the console.

5.2 Navigation and Game Selection

The console runs on the EmuELEC System, supporting over 23 game simulators.

- Use the joystick or D-pad to navigate through the game menus.
- Press the A button to select a game or option.
- Press the B button to go back to the previous menu.
- The FN button provides additional function shortcuts.

5.3 Multiplayer Functionality

The R36T supports 5G WiFi and 2.4G OTG Wireless Controller connectivity for online multiplayer gaming.

1. **Connect to Wi-Fi:** From the main menu, go to START -> MAIN MENU -> Network Settings -> Connect to the SAME Wi-Fi network.
2. **Launch Game:** Both players should open the SAME game on their devices.
3. **Connecting Consoles:** Player 1 (Host) navigates to Netplay -> Host -> Start Netplay Host. Player 2 (Client) navigates to Netplay -> Connect to Netplay Host and manually enters Player 1's IP address.
4. **Start Fighting:** Once connected, Player 1 selects 'Multiplayer Mode' to begin. Player 1's controller is the 'Main Control Handle' by default.

R36T Retro Handheld Game Console Supports 4G/5G WiFi for Online Multiplayer

3 Core Steps, Enables Exciting Multiplayer Combat

STEP 1: Connect → STEP 2: Host/Join → STEP 3: FIGHT.

The R36T built-in connectivity makes versus battles effortless.
Challenge friends online or locally without extra dongles.



Note:

a: For multiplayer games with 2 or more players, all devices must be connected to the same Wi-Fi network.

b: Prioritize the setting to find the "host" as the main control of the game console to start the network game console and use it as the "Main Control Handle"

Figure 5.1: Illustration of two R36T consoles engaged in networked multiplayer gameplay.

6. GAME MANAGEMENT

6.1 Adding Games

To add more games, insert the TF card into your computer and open the EE_ROMs drive. Place downloaded games in the corresponding emulator folder. Put game images in /media/screenshot. Open gamelist.xml with a text editor, add the new game's info following existing entries, and save. Eject the TF card, insert it back into the device, and power-on the newly added games will now appear in your library.

6.2 Saving and Loading Games

- **Save Game Progress:** Press SELECT + R1.
- **Load Saved Game Progress:** Press SELECT + L1.

7. SYSTEM SETTINGS

The main menu provides access to various settings:

- **Game Settings:** Adjust game-specific options.
- **Controller Settings:** Configure controller inputs and mappings.
- **Sound Settings:** Adjust volume and audio output.
- **Network Settings:** Manage Wi-Fi connections.
- **System Settings:** General system configurations.

7.1 Adjusting Screen Brightness

1. Press the START button to open the selection menu.
2. Select System Settings and press A to enter.
3. Choose Brightness option.
4. Use Left D-pad to decrease brightness or Right D-pad to increase brightness.

8. MAINTENANCE

8.1 Battery Care

- Avoid fully discharging the battery frequently to prolong its lifespan.
- Charge the console using only the provided Type-C cable and a compatible 5V/2A adapter.
- Do not expose the console to extreme temperatures.

8.2 Cleaning

- Use a soft, dry cloth to clean the console's exterior.
- For the screen, use a microfiber cloth specifically designed for electronics.
- Avoid using harsh chemicals or abrasive materials.

9. TROUBLESHOOTING

- **Console does not power on:** Ensure the battery is charged. Connect the console to a charger and try again.
- **Games not loading:** Verify the TF card is properly inserted. Check if the game files are correctly placed in the emulator folders.
- **Screen issues:** If the screen is unresponsive or displays incorrectly, try restarting the console.
- **Connectivity problems:** Ensure the console is within range of a stable Wi-Fi network. Re-enter Wi-Fi credentials if necessary.

10. SPECIFICATIONS

Feature	Specification
Model Number	R36T
Screen Size	3.5 Inches
Display Type	IPS
Resolution	640*480
Memory Storage Capacity	64 GB
Battery Capacity	3500mAh
Battery Life	6-8 Hours
Power Source	Battery Powered
Controller Type	Joystick
Connectivity	5G WiFi, 2.4G OTG Wireless Controller

Material	Plastic
Item Weight	0.36 Kilograms (12.6 ounces)
Product Dimensions	5 x 2 x 6 inches

11. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact AISLPC customer service. Protection plans may be available for extended coverage.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question