

**GF6**

# Generic F6 Portable Oscillating Camping Fan User Manual

Model: GF6

## 1. SAFETY INSTRUCTIONS

Please read all instructions carefully before using the fan and retain this manual for future reference. Improper use may result in electric shock, fire, or serious injury.

- Do not immerse the fan in water or other liquids.
- Keep the fan away from children and pets.
- Do not block the fan blades or air inlets/outlets.
- Use only the specified charging cable and power adapter (5V/3A).
- Do not disassemble, repair, or modify the fan yourself. Contact qualified service personnel for assistance.
- Avoid exposing the fan to extreme temperatures, direct sunlight, or high humidity.
- Ensure the fan is placed on a stable surface when in use.
- This product is not water resistant. Avoid use in rain or wet conditions.

## 2. PACKAGE CONTENTS

Verify that all items are present upon unpacking:

- 1 x F6 Portable Oscillating Camping Fan
- 1 x USB Type-C Charging Cable
- 1 x Remote Control
- 1 x User Manual (this document)

## 3. PRODUCT OVERVIEW

The Generic F6 Portable Oscillating Camping Fan is designed for versatile outdoor and indoor use, featuring a powerful rechargeable battery, integrated LED lighting, and multiple operational modes.



Figure 3.1: Front view of the F6 Camping Fan, showcasing its octagonal design and integrated LED ring.


# Rechargeable & Portable outdoor Fan




Figure 3.2: Side and front views illustrating the fan's dimensions (8.7"L x 4.3"W x 12.6"H) and the 5V/3A Type-C input/output port for charging and power bank functionality.

# Large battery Capacity

A fully charged camping fan can charge your phone 4-5 times



Good evening, Mom! My friends and I are camping. The newly purchased camping fan makes me very safe. It's cool, my phone can be charged, and it also has strong lighting!



**8 Hours**  
Fully Charged



**16 Hours**  
Maximum wind



**40 Hours**  
Maximum lighting

Figure 3.3: The fan features a 20000mAh rechargeable battery, capable of providing extended operation and serving as a power bank to charge other devices.



Figure 3.4: The fan includes a 360° rotatable hanging hook for versatile placement and comes with a remote control for convenient operation.

Your browser does not support the video tag.

Video 3.1: An official product video demonstrating the portable camping fan's features, including its power bank functionality and LED light.

## 4. SETUP

Before first use, fully charge the fan's internal battery.

1. **Initial Charge:** Connect the provided USB Type-C cable to the fan's Type-C input port and a compatible 5V/3A USB power adapter (not included). The battery indicator lights will show charging progress. A full charge typically takes approximately 8 hours.
2. **Placement:** Place the fan on a flat, stable surface or use the integrated hanging hook to suspend it from a tent, RV, or other suitable structure.
3. **Remote Control:** Ensure the remote control has working batteries (if applicable, check for a battery tab to remove).

## 5. OPERATING INSTRUCTIONS

## 5.1 Fan Speed Control

The fan offers 4 adjustable speed settings.

- Press the fan speed button on the control panel or remote to cycle through speeds 1, 2, 3, and 4.
- Pressing again after speed 4 will turn the fan off.

## 5.2 LED Light Operation

The integrated LED light has 2 modes and 3 brightness levels.

- Press the light button on the control panel or remote to turn the light on.
- Continue pressing to cycle through brightness levels (Low, Medium, High).
- Pressing again after the highest brightness will turn the light off.

## 5.3 Oscillation and Rotation

The fan head can be manually rotated and features automatic oscillation.

- **Manual Rotation:** The fan head can be manually rotated 270 degrees vertically to direct airflow.
- **Automatic Oscillation:** Press the oscillation button on the control panel or remote to activate 45° or 90° automatic horizontal oscillation. Press again to stop.

## 5.4 Timer Function

Set the fan to automatically turn off after a specified period.

- Press the timer button on the control panel or remote to select a timer setting (1H, 2H, 4H, 8H).
- The corresponding indicator light will illuminate. The fan will turn off automatically after the set time.

## 5.5 Sleep Mode

For undisturbed rest, activate sleep mode.

- Press the sleep mode button (often combined with the timer or a dedicated button) on the remote control. This mode typically turns off all indicator lights for a darker environment.

## 5.6 Power Bank Function

Use the fan's internal battery to charge other devices.

- Connect your device's charging cable to the fan's USB output port (5V/3A).
- The fan will begin charging your device. Monitor the fan's battery level to ensure sufficient power for both fan operation and device charging.

## 6. CHARGING THE FAN

---

To recharge the fan's internal 20000mAh battery:

1. Connect the provided USB Type-C cable to the fan's Type-C input port.
2. Connect the other end of the USB cable to a 5V/3A USB power source, such as a wall adapter, power bank, or solar panel.
3. The battery indicator lights on the control panel will show the current charge level and flash during charging.
4. Once fully charged, all indicator lights will be solid. Disconnect the charging cable.

## 7. MAINTENANCE

---

Proper maintenance ensures the longevity and optimal performance of your fan.

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the fan. Do not use abrasive cleaners or solvents. For the fan blades, use a soft brush or compressed air to remove dust. Ensure the fan is turned off and unplugged before cleaning.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to charge the battery every 3-6 months to maintain its health.

## 8. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan fully.
	Power button not pressed correctly.	Ensure the power button is pressed firmly.
LED light does not work.	Light function not activated.	Press the light button to cycle through brightness levels.
	Battery is too low.	Charge the fan.
Fan is not charging.	Charging cable or adapter is faulty.	Try a different USB Type-C cable and 5V/3A adapter.
	Charging port is dirty or damaged.	Clean the port gently or contact support if damaged.
Remote control not working.	Remote battery is dead or missing.	Replace the remote control battery. Ensure no obstructions between remote and fan.

## 9. SPECIFICATIONS

Feature	Detail
Model Number	GF6
Product Dimensions	8.7"L x 4.3"W x 12.6"H
Battery Type	Rechargeable Lithium-Ion Polymer
Battery Capacity	20000mAh
Battery Life (Fan Only)	Up to 72 Hours (depending on speed setting)
Light Output Maximum	120 Lumens
Item Weight	2.76 pounds
Mounting Type	Tabletop Mount, Hanging Hook

Feature	Detail
Water Resistance Level	Not Water Resistant
Voltage	5 Volts
Wattage	15 Watts
Input/Output	5V/3A Type-C
Material	Plastic

## 10. WARRANTY AND SUPPORT

---

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact the seller directly. If you have any questions, require technical support, or need assistance with your product, please reach out to the customer service team of the retailer or manufacturer.