

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [ENUOSUMA](#) /
- › [ENUOSUMA Super Mini Projector User Manual](#)

## ENUOSUMA White-Mini

# Super Mini Projector User Manual

Model: White-Mini | Brand: ENUOSUMA

### INTRODUCTION

This manual provides essential information for the operation and maintenance of your ENUOSUMA Super Mini Projector. This compact device offers 4K 1080P support, built-in Android 11 OS, WiFi 6, and Bluetooth connectivity, designed for versatile entertainment and presentation needs. Its auto keystone correction and portable design make it suitable for various environments.

### WHAT'S IN THE BOX

- Super Mini Projector (White-Mini)
- Power Adapter
- Remote Control
- User Manual



Image: Contents of the Super Mini Projector package, including the projector, remote, and power adapter.

## SETUP

---

### 1. Placement and Power

Place the projector on a stable, flat surface. Ensure adequate ventilation around the device. Connect the power adapter to the projector's power input port and then to a power outlet. The projector is designed for portability, with dimensions of approximately 3.7 × 3.7 × 6.1 inches.



Image: Size comparison illustrating the compact design of the White-Mini projector, easily fitting into a bag.

## 2. Initial Power On and Focus

Press the power button on the projector or the remote control to turn it on. The projector features automatic keystone correction and manual focus adjustment to quickly achieve a clear and properly shaped image. The 210° rotatable lens allows for flexible projection angles, including ceiling projection.

# AUTO HORIZONTAL KEYSTONE CORRECTION & FOUR POINT CORRECTION



Image: The projector automatically adjusting its image for optimal display, showcasing auto keystone and four-point correction.

### 3. Network and Device Connectivity

Navigate to the settings menu to connect to your Wi-Fi network (supports WiFi 6, 2.4G, and 5G). For external devices, use the HDMI and USB ports. The projector also supports Bluetooth 5.2 for connecting external audio devices or other compatible accessories.



# ULTRA-FAST WIFI 6 & BLUETOOTH 5.2



Image: Illustration of the projector's ultra-fast WiFi 6 and Bluetooth 5.2 capabilities, enabling smooth streaming from a smartphone.

# LINK TO YOUR ENTERTAINMENT WORLD



Image: The projector's multi-device connectivity, showing compatibility with laptops, smartphones, headphones, and gaming devices.

## OPERATING INSTRUCTIONS

---

### 1. Navigating the Android TV 11 Interface

The projector runs on Android TV 11, providing access to over 4000 applications, including popular streaming services like Netflix, Prime Video, and YouTube. Use the provided remote control to navigate through the interface, select apps, and adjust settings.



# Android TV 11

Support 4000+ APP



Image: The projector's Android TV 11 interface, showing a selection of supported streaming applications.

## 2. Adjusting Projection Size and Distance

The projector can project a screen size from 40 to 130 inches. For optimal viewing, a distance of 5.2 feet is recommended for an 80-inch screen. Adjust the projector's distance from the projection surface to achieve your desired screen size.

# PROJECT A BIG SCREEN WITH ANY SETUP

For best viewing, recommend 5.2ft distance for 80" screen



Image: Visual guide for projecting different screen sizes based on distance from the projector to the wall.

## 3. Audio Output

The projector features a built-in 360-degree audio system for an immersive experience. For private listening or enhanced audio, connect Bluetooth headphones or external speakers via Bluetooth 5.2 or the audio output port.

## MAINTENANCE

### 1. Cleaning the Lens and Vents

Regularly clean the projector lens with a soft, lint-free cloth designed for optical surfaces. Do not use abrasive cleaners. Ensure the ventilation grilles are free from dust and obstructions to maintain optimal airflow and prevent overheating. The projector features a high-performance cooling system designed to keep noise levels below 25dB.

### 2. Storage

When not in use, store the projector in a cool, dry place away from direct sunlight and extreme temperatures. Use the



original packaging or a protective case to prevent dust accumulation and physical damage.

TROUBLESHOOTING

Issue	Possible Cause	Solution
No image or blurry image	Incorrect focus, obstructed lens, incorrect input source.	Adjust manual focus. Clean the lens. Verify the input source (HDMI, USB). Ensure auto keystone correction is enabled.
No sound or low volume	Volume too low, external audio device not connected properly, internal speaker disabled.	Increase volume. Check Bluetooth connection for external speakers/headphones. Ensure internal speaker is enabled in settings.
Projector overheats and shuts off	Blocked ventilation, prolonged use in high temperatures.	Ensure vents are clear. Allow projector to cool down. Operate in a well-ventilated area.
Wi-Fi/Bluetooth connectivity issues	Out of range, interference, incorrect password.	Move closer to the router/device. Restart projector and router/device. Re-enter Wi-Fi password.

SPECIFICATIONS

Feature	Detail
Brand	ENUOSUMA
Model	White-Mini
Item Weight	1.39 pounds
Package Dimensions	7.24 x 6.02 x 4.41 inches
Country of Origin	China
Special Features	Auto Keystone Correction
Connectivity Technology	Bluetooth, Wi-Fi 6 (2.4G/5G), HDMI, USB
Display Resolution	Native 1280x720 (4K Support)
Brightness	150 ANSI lumens
Contrast Ratio	1500:1
Operating System	Android 11 OS
Rotation Angle	210°






WARRANTY AND SUPPORT

ENUOSUMA is committed to providing quality service and support for your product. We offer:

- **24-hour online after-sales service:** Assistance is available around the clock for any inquiries or issues.
- **30-day free return and exchange:** If you are not satisfied with your purchase, you may return or exchange it within 30 days.
- **Lifetime permanent technical support:** Enjoy ongoing technical assistance for the lifespan of your projector.

For further assistance, please refer to the contact information provided on the product packaging or the official ENUOSUMA website.

Related Documents - White-Mini

	<p><a href="#">Sovboi VB6 Mini Video Projector User Manual - Setup, Features, and Troubleshooting</a></p> <p>Comprehensive user manual for the Sovboi VB6 Mini Video Projector. Learn about setup, features, input sources, wireless projection, settings, troubleshooting, and specifications. Get detailed instructions for optimal use.</p>
	<p><a href="#">iZEEKER iPL310 LED Projector User Manual</a></p> <p>iZEEKER iPL310 LED Projector User Manual: Get detailed setup, operation, and troubleshooting guides for your iPL310 projector. Learn about features, specifications, and warranty from iZEEKER.</p>
	<p><a href="#">Magcubic HY310X Mini Projector User Manual - Setup, Settings, and Safety</a></p> <p>Comprehensive user manual for the Magcubic HY310X Mini Projector. Learn about safety instructions, overview, remote control, settings (networking, Bluetooth, projection, applications, language, date/time), about information, other settings, screen casting, and regulatory compliance.</p>
	<p><a href="#">TOPTRO TR25 Projector User Manual</a></p> <p>User manual for the TOPTRO TR25 projector, covering setup, operation, features like WiFi and Bluetooth connectivity, and troubleshooting.</p>
	<p><a href="#">WEMAX Dice Portable Smart Projector User Manual</a></p> <p>User manual for the WEMAX Dice Portable Smart Projector (M055FGN). Learn about setup, operation, maintenance, troubleshooting, and product specifications for an optimal viewing experience.</p>

Home Theater Projector



USER MANUAL

### [Home Theater Projector User Manual](#)

User manual for the Home Theater Projector, covering setup, operation, connectivity, and troubleshooting.

