

[Manuals.plus](#) /

› [ASHATA](#) /

› ASHATA 4G LTE Portable WiFi Mobile Hotspot User Manual

ASHATA ASHATA 4G LTE Portable WiFi Mobile Hotspot

ASHATA 4G LTE Portable WiFi Mobile Hotspot User Manual

Model: ASHATA 4G LTE Portable WiFi Mobile Hotspot

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your ASHATA 4G LTE Portable WiFi Mobile Hotspot. Please read this manual thoroughly before using the device to ensure optimal performance and safety.

2. PRODUCT OVERVIEW

The ASHATA 4G LTE Portable WiFi Mobile Hotspot is a versatile device designed to provide high-speed internet access on the go. It supports LTE CAT4 standards, offering speeds up to 300Mbps, and features a built-in 10000mAh battery for extended usage. This hotspot allows up to 10 devices to connect simultaneously, making it ideal for travel, home, or outdoor activities.

4G WiFi hotspot:

Wi Fi modem router.

As long as you have a 3 or 4G SIM card, you can connect to the network

Supports LTE CAT4 standard, 300Mbps high speed internet access

If the WiFi dongle works for a long time, it needs to dissipate heat.

Compact and lightweight

Suitable for gatherings, travel, business trips, work, outdoor live streaming, gaming, car WiFi, etc.

Connect up to 10 devices simultaneously, supporting devices such as smartphones, tablets, laptops, etc.

The effective range of WiFi can arrive up to 10 meters.



Image 2.1: Front view of the ASHATA 4G LTE Portable WiFi Mobile Hotspot highlighting its 4G/5G WiFi capability and 10000mAh battery capacity.

High Flexibility

This 4G LTE USB modem supports multiple frequency bands, allowing connectivity anywhere. Connect up to 10 devices simultaneously, suitable for travel, gaming, or outdoor activities. Connect up to 10 devices simultaneously, supporting devices such as smartphones, tablets, laptops, etc.



Image 2.2: Angled view of the ASHATA 4G LTE Portable WiFi Mobile Hotspot, emphasizing its high flexibility and portability.

3. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x ASHATA 4G LTE Mobile Hotspot Router
- 1 x USB Cable (Type-C)
- 1 x User Manual (this document)



Image 3.1: The ASHATA 4G LTE Portable WiFi Mobile Hotspot shown with its accompanying USB charging cable.

4. SETUP

4.1 SIM Card Installation

1. Locate the SIM card slot on the device.

2. Insert a 3G or 4G SIM card into the slot. Ensure the SIM card is activated and its PIN is disabled before insertion.

4.2 Powering On/Off

1. To power on the device, press and hold the power button located on the side until the indicators light up.
2. To power off, press and hold the power button again until the indicators turn off.

Easy Setup and Usage

Simply insert your SIM card and press the power key to turn the router on. Even if your SIM card is compatible with the hotspot device, it may not be plug and play. You may need to disable the SIM card's PIN and modify the APN settings. Enter the router's IP address 192.168.100.1, click on Network, then APN, and enable it. Make sure your SIM card is activated for seamless connectivity.



Image 4.1: Close-up of the ASHATA 4G LTE Portable WiFi Mobile Hotspot illustrating the SIM card insertion area and power button for easy setup.

4.3 Initial Configuration (APN Settings)

Even if your SIM card is compatible, it may not be plug-and-play. You might need to modify the APN settings:

1. Connect a device (e.g., smartphone, laptop) to the hotspot's Wi-Fi network.
2. Open a web browser and enter the router's IP address: **192.168.100.1**
3. Navigate to the **Network** section, then select **APN**.
4. Enable APN settings and configure them according to your SIM card provider's specifications.
5. Ensure your SIM card is activated for seamless connectivity.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the general setup process for a portable WiFi hotspot, including connecting the USB cable and powering on the device. While the device shown may vary, the basic steps are applicable.

5. OPERATING INSTRUCTIONS

5.1 Connecting Devices

Once the hotspot is powered on and configured, you can connect up to 10 devices:

1. On your device (smartphone, tablet, laptop), search for available Wi-Fi networks.
2. Select the network name (SSID) corresponding to your ASHATA hotspot.
3. Enter the Wi-Fi password (usually found on a sticker inside the device or in the web interface).
4. Your device should now be connected to the internet via the hotspot.

5.2 Charging the Device

The hotspot features a built-in 10000mAh battery, providing over 18 hours of continuous usage. To charge:

- Connect the provided USB Type-C cable to the charging port on the hotspot.
- Connect the other end of the USB cable to a compatible USB power adapter or computer USB port.
- The charging indicator will show the charging status.

Long Lasting Battery Life

With a powerful built in 10,000mAh battery, this portable Wi Fi hotspot guarantees over 18 hours of continuous usage, ensuring fast internet access wherever you are.



Image 5.1: Top view of the ASHATA 4G LTE Portable WiFi Mobile Hotspot, highlighting its long-lasting 10000mAh battery life.

5.3 Heat Dissipation

If the WiFi hotspot operates for an extended period, it may generate heat. This is normal. Ensure the device is placed in a well-ventilated area to facilitate proper heat dissipation and maintain optimal performance.

6. SPECIFICATIONS

The following table details the technical specifications of the ASHATA 4G LTE Portable WiFi Mobile Hotspot:

Feature	Specification
Item Type	4G LTE Mobile Hotspot Router
Material	ABS
Color	White
Size	Approx. 14.6 x 7 x 1.9 cm / 5.75 x 2.76 x 0.75 in
Battery	Built-in 10000mAh Lithium-ion Battery
SIM Card Slot	1 x SIM Card (SIM card not included)
Network Bands	B1, 3, 5, 7, 8, 20, 28, 38, 40, 41
Sharing	Up to 10 users
Interfaces	Type-C and USB
WiFi Standard	802.11 b/g/n 2x2
Max WiFi Speed	Up to 300Mbps
Item Weight	9.3 ounces
Frequency Band Class	Tri-Band



Image 6.1: The ASHATA 4G LTE Portable WiFi Mobile Hotspot with its physical dimensions clearly indicated.

7. TROUBLESHOOTING

If you encounter issues with your ASHATA 4G LTE Portable WiFi Mobile Hotspot, please refer to the following common solutions:

- **No Internet Connection:**

- Ensure your SIM card is properly inserted and activated.
- Verify that the APN settings are correctly configured (refer to Section 4.3).
- Check for network signal strength on the device display.
- Restart the hotspot and the connected device.

- **Cannot Connect to Hotspot Wi-Fi:**

- Ensure the hotspot is powered on.
- Double-check the Wi-Fi password.
- Move closer to the hotspot to ensure you are within range (effective range up to 10 meters).
- Restart both the hotspot and your connecting device.

- **Slow Internet Speed:**

- Speed depends on network signal strength; try moving to an area with better reception.
- Reduce the number of connected devices.
- Ensure the device is not overheating (refer to Section 5.3).

- **Device Not Powering On:**
 - Ensure the battery is charged. Connect the device to a power source using the USB cable.
 - Press and hold the power button for a few seconds.

8. MAINTENANCE AND SAFETY INFORMATION

8.1 General Maintenance

- Keep the device clean and free from dust. Use a soft, dry cloth for cleaning.
- Avoid exposing the device to extreme temperatures, direct sunlight, or high humidity.
- Do not attempt to disassemble or repair the device yourself. This will void the warranty.

8.2 Safety Precautions

- Use only the provided or recommended charging cable.
- Keep the device away from water and flammable liquids.
- Do not drop or subject the device to strong impacts.
- Dispose of the battery and device according to local regulations.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the ASHATA official website. Keep your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FC6T7QY4>

More documents and user manuals: <https://manuals.plus/>