

## GOLD NOTE PSU-5

# GOLD NOTE PSU-5 Inductive Power Supply User Manual

Model: PSU-5 | Brand: GOLD NOTE

## 1. INTRODUCTION

The GOLD NOTE PSU-5 is an external inductive power supply specifically designed to enhance the performance of the Gold Note PH-5 phono stage. It provides ultra-clean power to optimize audio signal integrity and improve the overall vinyl reproduction experience.

Inspired by the design philosophy of other Gold Note external power supplies like the PSU-10 and PSU-1000, the PSU-5 features a linear power supply with custom-made transformers and an inductive filter to effectively prevent noise and interference from the AC power grid.



Figure 1: Front view of the GOLD NOTE PSU-5 Inductive Power Supply.

This manual provides essential information for the proper setup, operation, and maintenance of your PSU-5 unit.

## 2. WHAT'S IN THE BOX

Upon opening the packaging, please verify that all components are present and undamaged. The box should contain:

- 1 x GOLD NOTE PSU-5 Inductive Power Supply Unit
- 1 x Power Cable (region specific)
- 1 x Connection Cable for PH-5 Phono Stage
- 1 x User Manual (this document)

If any items are missing or damaged, please contact your authorized Gold Note dealer or customer support immediately.

### 3. SETUP

Follow these steps to properly set up your GOLD NOTE PSU-5 Inductive Power Supply:

1. **Placement:** Place the PSU-5 on a stable, level surface, away from direct sunlight, heat sources, and excessive moisture. Ensure adequate ventilation around the unit. Avoid placing it directly on top of or underneath other audio components to minimize potential interference.
2. **Power Off:** Before making any connections, ensure that both the PSU-5 and your Gold Note PH-5 phono stage are powered off and disconnected from the AC mains.
3. **Connect to PH-5:** Connect one end of the supplied connection cable to the dedicated power input port on the rear of your Gold Note PH-5 phono stage. Connect the other end of this cable to the corresponding output port on the rear of the PSU-5. Ensure a firm and secure connection.
4. **Connect to AC Mains:** Connect the supplied power cable to the AC inlet on the rear of the PSU-5. Then, plug the other end of the power cable into a suitable AC wall outlet. It is recommended to use a high-quality surge protector or power conditioner.
5. **Power On Sequence:** First, power on the PSU-5 using its power switch. Wait a few moments for the unit to stabilize. Then, power on your Gold Note PH-5 phono stage.

**Important:** Always ensure all connections are secure before powering on the units. Incorrect connections can lead to damage or improper operation.

### 4. OPERATION

The GOLD NOTE PSU-5 is designed for straightforward operation, primarily serving as a dedicated power source for the PH-5 phono stage.

- **Power Indicator:** A small LED indicator on the front panel of the PSU-5 illuminates when the unit is powered on and operating correctly.
- **Automatic Operation:** Once connected and powered on, the PSU-5 automatically provides the optimized, ultra-clean power to the PH-5 phono stage. There are no user-adjustable settings on the PSU-5 itself.
- **Power Off Sequence:** To power down your system, first power off the PH-5 phono stage, then power off the PSU-5. This sequence helps prevent any potential transient noises or stresses on the components.

For detailed operation of your PH-5 phono stage, please refer to its dedicated user manual.

### 5. MAINTENANCE

To ensure the longevity and optimal performance of your GOLD NOTE PSU-5, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the unit from the power outlet before cleaning. Use a soft, dry, lint-free cloth to wipe the exterior surfaces. Do not use abrasive cleaners, waxes, or solvents, as these can damage the finish.
- **Ventilation:** Ensure that the ventilation openings are not blocked. Do not place the unit in an enclosed cabinet without proper airflow.
- **Environmental Conditions:** Avoid exposing the unit to extreme temperatures, high humidity, or dusty environments.
- **Cable Connections:** Periodically check all cable connections to ensure they are secure. Loose connections can degrade performance.

The PSU-5 contains no user-serviceable parts. Do not attempt to open the chassis, as this will void the warranty and may expose you to dangerous voltages.

## 6. TROUBLESHOOTING

If you encounter issues with your GOLD NOTE PSU-5, please consult the following troubleshooting guide before contacting customer support:

Problem	Possible Cause	Solution
PSU-5 does not power on (no LED indicator).	Unit not plugged in. Power outlet is not active. Power cable is faulty. Internal fuse blown (rare).	Ensure power cable is securely plugged into the unit and wall outlet. Test the wall outlet with another device. Try a different power cable. Contact Gold Note customer support.
PH-5 phono stage does not receive power from PSU-5.	Connection cable loose or faulty. PSU-5 not powered on.	Check the connection cable between PSU-5 and PH-5. Ensure it is firmly seated at both ends. Verify the PSU-5 is powered on (LED indicator is lit).
Humming or buzzing sound from audio system after connecting PSU-5.	Ground loop issue. Interference from other components.	Ensure all audio components are plugged into the same power strip or wall outlet. Try relocating the PSU-5 away from sensitive audio components or signal cables. Consult a professional audio technician.

If the problem persists after trying these solutions, please contact Gold Note customer support or your authorized dealer for further assistance.

## 7. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Power Supply Type	Linear Power Supply with Inductive Filter
Dedicated For	Gold Note PH-5 Phono Stage
Transformer Circuit	2-transformer circuit for linear power stage
Voltage Regulators	3 ultra-low noise voltage regulators
Audio Grade Power Supply Rails	3 rail audio grade power supply
Maximum Variation of Output Voltage	0.05 %
Line Noise Rejection	>80dB
Common Mode Noise Rejection	>80dB
Full Power Response Time	<2.5μsec
Manufacturer	GOLD NOTE
ASIN	B0FC75H86B
Date First Available	June 6, 2025

*Specifications are subject to change without notice for product improvement.*

## 8. WARRANTY AND SUPPORT

GOLD NOTE products are manufactured to the highest quality standards. This product is covered by a limited warranty from the date of purchase. Please refer to the warranty card included with your product or visit the official Gold Note website for detailed warranty terms and conditions.

For technical support, service, or warranty claims, please contact your authorized Gold Note dealer or distributor. You can also visit the official Gold Note website for frequently asked questions (FAQs) and contact information:

**Gold Note Official Website:** [www.goldnote.it](http://www.goldnote.it)

When contacting support, please have your product model (PSU-5) and serial number (if applicable) ready.

© 2025 GOLD NOTE. All rights reserved.

This manual is for informational purposes only. GOLD NOTE assumes no responsibility for errors or omissions in this manual or for damages resulting from the use of the information contained herein.

# USER MANUAL

PSU-5

[\[pdf\] User Manual Installation Guide Instructions](#)

Download Gold Note PSU 5 goldnote it manual |||

EN DE IT FR USER MANUAL **PSU-5** EN DE IT FR Thank you for purchasing one of our units and welcome into the Gold Note world, where we turn High-End audio and music into a new experience. Maurizio Aterini, founder of Gold Note **IMPORTANT SAFETY INFORMATION** PLEASE NOTE 1 Do not disassemble any ...

lang:en score:35 filesize: 611.04 K page\_count: 44 document date: 2023-04-27

# USER MANUAL

PSU-5

[\[pdf\] User Manual Installation Guide Instructions](#)

User Manual 620 kB Gold Note PSU 5 VOIX Audio Cinema psu voix cz user related files |||

EN DE IT FR USER MANUAL **PSU-5** EN DE IT FR Thank you for purchasing one of our units and welcome into the Gold Note world, where we turn High-End audio and music into a new experience. Maurizio Aterini, founder of Gold Note **IMPORTANT SAFETY INFORMATION** PLEASE NOTE 1 Do not disassemble any ...

lang:en score:30 filesize: 620.04 K page\_count: 44 document date: 2024-03-05

PSU-7  
Dual Mono AC Power Supply Unit

Owner's Manual

MANUFACTURED IN ITALY  
TEL. +39 0571 675005 FAX. +39 0571 675013[\[pdf\] User Manual Owner's Manual Instructions Specifications Warranty](#)

GOLD NOTE PSU 7 01 MANUAL Manual Hub drive google file d


1UNaMeCbdqTjqqUIYTgIFsg8bKWWGBBy7 preview |||

GOLD NOTE PSU-7 Dual Mono AC Power Supply Unit Owner's Manual

MANUFACTURED IN ITALY TEL. 39.0571.675005 FAX. 39.0571.675013

<https://manual-hub.com/> PSU-7 Italian Prestige AC Power Supply Unit Table of Contents - Congratulations Introduction 3 - Box Content 4 - Installation Position...

lang:en score:26 filesize: 845.65 K page\_count: 8 document date: 2023-10-04



[\[pdf\]](#) User Manual Owner's Manual Instructions Troubleshooting Guide Specifications Warranty

M7 manual 2013 ENG Maurizio GOLD NOTE M 7 01 MANUAL drive google uc id

1lkTyif8Mv2JXAeENZmnUf9958fohAxEQ export |||


GOLD NOTE M-7 ITALIAN MONO BLOCK AMPLIFIER Owner's Manual

MANUFACTURED IN ITALY TEL. 39.0571.675005 FAX. 39.0571.675013 1 M-7

Italian Mono Block Amplifier Table Of Contents - Congratulations Introduction 3 -

Contents of Packaging 4 - Back Panel Features 4 - Operating Conditions Fr...

lang:en **score:25** filesize: 347.15 K page\_count: 9 document date: 2013-09-07



[\[pdf\]](#) User Manual Owner's Manual Instructions Troubleshooting Guide Specifications Warranty

PSU 9 manual 2017 Maurizio Aterini Gold Note Download goldnote it |||


GOLD NOTE PSU-9 Double Battery Power Supply Unit Owner's Manual

MANUFACTURED IN ITALY TEL. 39.0571.675005 FAX. 39.0571.675013 PSU-9

Italian Prestige Double Battery Power Supply Unit Table of Contents - Congratulations

Introduction 3 - Box Content 4 - Installation Positioning 4 - Op...

lang:en **score:25** filesize: 819.63 K page\_count: 8 document date: 2017-09-21



[\[pdf\]](#) User Manual Owner's Manual Instructions Specifications Declaration of Conformity Warranty

Microsoft Word PSU 7 manual 2013 doc Maurizio GOLD NOTE 01 MANUAL drive google u 0 uc id

1UNaMeCbdqTjqqUIYTgIFsfg8bKWWGBy7 export |||


GOLD NOTE PSU-7 Dual Mono AC Power Supply Unit Owner's Manual

MANUFACTURED IN ITALY TEL. 39.0571.675005 FAX. 39.0571.675013 PSU-7

Italian Prestige AC Power Supply Unit Table of Contents - Congratulations

Introduction 3 - Box Content 4 - Installation Positioning 4 - Operating the PS...

lang:en **score:25** filesize: 159.16 K page\_count: 8 document date: 2013-06-19



[\[pdf\]](#) User Manual Owner's Manual Instructions Troubleshooting Guide Specifications  
Declaration of Conformity Warranty

Microsoft Word PSU 9 manual 2013 doc Maurizio GOLD NOTE 01 MANUAL drive google u 0 uc id 1UgbyAZMSISAfYQ20s5HqZhoJCgsc s6W export |||

GOLD NOTE PSU-9 Double Battery Power Supply Unit Owner's Manual

MANUFACTURED IN ITALY TEL. 39.0571.675005 FAX. 39.0571.675013 PSU-9

Italian Prestige Double Battery Power Supply Unit Table of Contents - Congratulations

Introduction 3 - Box Content 4 - Installation Positioning 4 - Ope...

lang:en score:24 filesize: 156.32 K page\_count: 8 document date: 2013-06-19



## [\[pdf\]](#) Accessories

Scheda tecnica Gold note psu 5 Accessori per giradischi in vendita su Hi Fi Di Prinzipio 202305031149511  
hifidiprinzipio.it files 2023 05 |||

**PSU-5** Alimentazione esterna 50W di potenza dinamica Circuito a 2 trasformatori filtro induttivo a doppia bobina potenza ultra pulita telaio in ferro verniciato nero Il **PSU-5** l'alimentatore esterno dedicato allo stadio phono PH-5, l'aggiornamento perfetto per migliorare le prestazioni del tu...

lang:it score:15 filesize: 253.89 K page\_count: 1 document date: 2023-05-03