

LENRUE E-1103

LENRUE Computer Speakers Model E-1103 Instruction Manual

INTRODUCTION

Thank you for choosing the LENRUE Computer Speakers Model E-1103. This manual provides essential information for the proper setup, operation, and maintenance of your new speakers. Please read these instructions carefully before use to ensure optimal performance and longevity of your device.

PRODUCT OVERVIEW

The LENRUE E-1103 is a compact soundbar designed for desktop and laptop use, offering clear stereo sound and dynamic lighting. It features a single USB connection for both power and audio, simplifying your setup.

Key Features:

- **Crystal-Clear Stereo Sound:** Equipped with dual speakers and dual diaphragms for balanced audio.
- **Dynamic Colorful Touch Lighting:** Soft breathing light effects with touch-sensitive control for on/off functionality.
- **Space-Saving Soundbar Design:** Compact form factor fits conveniently under most monitors or laptops.
- **Universal USB-Powered Compatibility:** Connects via a single USB port (USB-A to USB-C adapter included).
- **Plug-and-Play Simplicity:** No drivers or additional software required for operation.

Components:

The package includes the LENRUE E-1103 speaker unit and a USB-C adapter.



Image: The LENRUE Computer Speakers Model E-1103, a sleek soundbar designed for desktop use.

SETUP INSTRUCTIONS

Follow these steps to connect your LENRUE E-1103 speakers to your device.

1. **Connect the USB Cable:** Locate the USB-A cable attached to the speaker. Plug this cable into an available USB-A port on your computer (desktop PC, laptop, or monitor).



Image: Illustration of connecting the speaker's USB cable to a laptop, showing the included USB-C adapter.

Note: If your device only has USB-C ports, use the included USB-C adapter by plugging the speaker's USB-A cable into the adapter, then plugging the adapter into your device's USB-C port.

2. **Power On:** The speakers will power on automatically once connected to a powered USB port.
3. **Select Audio Output:** On your computer, navigate to your sound settings and select "LENRUE E-1103" as the audio output device. This is typically found in the system's sound preferences or control panel.
4. **Positioning:** Place the soundbar directly under your monitor or laptop for optimal sound projection and to utilize its space-saving design.



Image: The speaker demonstrating compatibility with Windows, macOS, and Chrome OS devices. Not compatible with Xbox.

OPERATING INSTRUCTIONS

Volume Adjustment:

The LENRUE E-1103 features a rotary knob on the right side for convenient volume control. Rotate the knob clockwise to increase volume and counter-clockwise to decrease volume.



Image: A close-up of the speaker's rotary volume knob and a visual representation of adjusting volume on a computer interface.

Lighting Control:

The speakers are equipped with dynamic breathing lights on the sides. To turn the lights on or off, gently touch the designated touch-sensitive area located near the volume knob.

Gentle Breathing Lighting

Touch Control Trun on/off



Image: The speaker's side panel highlighting the touch control icon for managing the breathing light effects.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your speakers.

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the speakers. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Dust Removal:** Periodically use a soft brush or compressed air to remove dust from the speaker grilles and ports.
- **Storage:** When not in use for extended periods, store the speakers in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the USB cable excessively. Do not pull on the cable to disconnect it; always grasp the plug.

TROUBLESHOOTING

If you encounter issues with your LENRUE E-1103 speakers, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from speakers	<ul style="list-style-type: none"> • USB cable not properly connected. • Incorrect audio output selected on computer. • Volume too low. 	<ul style="list-style-type: none"> • Ensure USB cable is securely plugged into a powered port. • Verify "LENRUE E-1103" is selected as the default audio output in your computer's sound settings. • Increase volume using the speaker's rotary knob and your computer's system volume.
Lights are not working	<ul style="list-style-type: none"> • Lights are turned off. • Power issue. 	<ul style="list-style-type: none"> • Gently touch the lighting control area on the speaker to toggle the lights on. • Ensure the speaker is receiving power via the USB connection.
Sound is distorted or unclear	<ul style="list-style-type: none"> • Volume too high. • Interference. 	<ul style="list-style-type: none"> • Reduce the volume on both the speaker and your computer. • Ensure the speaker is not placed too close to other electronic devices that may cause interference.

If the problem persists after trying these solutions, please contact customer support.



Hi-Fi Stereo Sound Quality

Dual Speakers & Dual Diaphragms

Image: An exploded view illustrating the dual diaphragms and speaker units responsible for the Hi-Fi stereo sound quality.

SPECIFICATIONS

Feature	Detail
Model Number	E-1103
Brand	LENRUE
Connectivity Technology	USB
Audio Output Mode	Stereo
Speaker Maximum Output Power	5 Watts
Frequency Response	20 Hz
Product Dimensions (D x W x H)	6.3 x 37.5 x 6.3 cm (2.48 x 14.76 x 2.48 inches)
Item Weight	435 Grams
Enclosure Material	Plastic

Feature	Detail
Built-In Media	USB-C adapter
Country of Origin	China



Image: Diagram showing the dimensions of the speaker (37.5cm length, 6.3cm height/depth) and the 120cm USB cable length.

WARRANTY INFORMATION

The LENRUE Computer Speakers Model E-1103 comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product is free from defects in material and workmanship under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

CUSTOMER SUPPORT

For any questions, technical assistance, or warranty claims regarding your LENRUE Computer Speakers

Model E-1103, please contact LENRUE customer support. Refer to the contact information provided with your product packaging or visit the official LENRUE website for support details.