



[Manuals.plus](#) /

› [YITAHOME](#) /

› YITAHOME 5-Piece Outdoor Furniture Dining Set User Manual

YITAHOME MAYIH3BJv9

YITAHOME 5-Piece Outdoor Furniture Dining Set User Manual

Model: MAYIH3BJv9

INTRODUCTION

Thank you for choosing the YITAHOME 5-Piece Outdoor Furniture Dining Set. This set is designed to provide a comfortable and stylish outdoor dining experience, featuring durable materials and a thoughtful design. Please read this manual carefully before assembly and use to ensure proper setup and longevity of your furniture.



Image: The complete YITAHOME 5-Piece Outdoor Furniture Dining Set, showcasing the round dining table and four ergonomic armchairs.

PRODUCT OVERVIEW AND FEATURES

The YITAHOME 5-Piece Outdoor Furniture Dining Set is crafted for durability and comfort, making it an ideal addition to your deck, backyard, or patio. Key features include:

- **Rust-Resistant & Stable Construction:** Built with a rust-proof iron frame wrapped in stylish rattan, ensuring durability for outdoor use. Adjustable foot pads provide stability on various surfaces.
- **UV-Proof Dining Table:** The plastic wood tabletop is designed to resist fading and wear from UV exposure. It includes two umbrella holes for optional shade or rain cover.
- **Thick Cushioned Armchairs:** Four ergonomic armchairs come with plush cushions featuring removable covers for easy cleaning and maintenance.
- **Simple Assembly:** Designed for quick and easy setup with clear instructions and pre-labeled parts.



Image: Adjustable foot pads ensure stability on uneven outdoor surfaces, preventing wobbling and protecting your patio.

CROSS-FIXED UMBRELLA POLE

Evenly distributed force for
enhanced stability



Image: The dining table features a built-in umbrella hole, allowing for easy integration of a patio umbrella for shade.

ADJUSTABLE FOOT PADS

Abrasion and slip-resistant for outdoors



Image: The armchair cushions are equipped with removable covers, making them easy to clean and maintain.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. The package should include:

- 1 x Dining Table
- 4 x Armchairs
- 4 x Seat Cushions
- 4 x Back Cushions
- Assembly Hardware (screws, bolts, wrench)
- Instruction Manual

SETUP AND ASSEMBLY

Assembly of your YITAHOME dining set is designed to be straightforward. Follow these general steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface (like a blanket or cardboard) to prevent scratches.
2. **Identify Parts:** Refer to the included parts list and diagrams to identify each component. All parts are pre-labeled for ease of identification.
3. **Assemble Chairs:** Attach the chair legs to the chair frames using the provided hardware. Do not fully tighten screws until all parts are aligned.
4. **Assemble Table:** Attach the table legs to the tabletop frame. Ensure the cross-fixed umbrella pole support is correctly positioned if applicable.
5. **Final Tightening:** Once all components are loosely assembled and aligned, gradually tighten all screws and bolts securely.
6. **Attach Cushions:** Place the seat and back cushions onto the armchairs.
7. **Adjust Foot Pads:** Adjust the foot pads on the bottom of the table and chair legs to ensure the furniture is level and stable on your chosen surface.

For detailed, step-by-step instructions and diagrams, please refer to the separate assembly guide included in your package.

OPERATING INSTRUCTIONS

Your YITAHOME outdoor dining set is ready for use once assembled. Here are some tips for optimal enjoyment:

- **Placement:** Position the dining set on a flat, stable surface. The adjustable foot pads can help compensate for minor unevenness.
- **Umbrella Use:** If using an umbrella, insert the pole through the designated hole in the tabletop. Ensure the umbrella base is stable and secure, especially in windy conditions.
- **Cushion Comfort:** The thick cushions provide enhanced comfort. Adjust their position as needed for your preference.
- **Weight Distribution:** Distribute weight evenly on the table and chairs. Avoid standing on the furniture.



Image: The dining set positioned outdoors, demonstrating its use with a patio umbrella for shade.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your outdoor dining set:

- **Cleaning Rattan and Frame:** Wipe down the rattan and iron frame with a soft cloth dampened with mild soap and water. Rinse thoroughly and dry completely to prevent water spots and rust.
- **Cleaning Plastic Wood Tabletop:** The UV-proof plastic wood tabletop can be cleaned with a damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals that could damage the surface.
- **Cushion Care:** The cushion covers are removable for easy cleaning. Follow the care instructions on the cushion tags, typically machine wash cold and air dry. Store cushions indoors during inclement weather or prolonged periods of non-use to prevent fading and mildew.
- **Winter Storage:** During winter months or extended periods of non-use, it is recommended to cover the furniture with a weather-resistant cover or store it indoors in a dry, protected area to prevent damage from extreme

temperatures and moisture.

- **Regular Inspection:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten as necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Furniture wobbles or is unstable.	Uneven surface; loose assembly hardware.	Adjust the leveling foot pads on the bottom of the legs. Ensure all assembly bolts and screws are securely tightened.
Cushions appear dirty or stained.	Exposure to dirt, spills, or weather.	Remove cushion covers and wash according to care instructions. For minor spots, spot clean with mild soap and water.
Rattan or frame appears dull.	Accumulation of dirt or environmental residue.	Clean with mild soap and water, then rinse and dry thoroughly. Regular cleaning helps maintain appearance.

SPECIFICATIONS

Attribute	Detail
Brand	YITAHOME
Model Number	MAYIH3BJv9
Product Dimensions (L x W x H)	27.59 x 24.8 x 22.63 inches (packaged)
Item Weight	54.7 pounds
Color	Beige & Black
Material	Rattan, Plastic Wood, Iron Frame
UPC	199449621874



Image: Detailed dimensions of the YITAHOME dining table and armchair for reference.

WARRANTY AND SUPPORT

YITAHOME is committed to providing high-quality products. For any questions, concerns, or assistance with your dining set, please contact YITAHOME customer support. Please have your model number (MAYIH3BJv9) and purchase information ready when contacting support.

For the most up-to-date warranty information and contact details, please visit the official YITAHOME website or refer to the warranty card included with your product.

You can also visit the [YITAHOME Store on Amazon](#) for more information and support resources.