

AROEVE DH-XCD05

AROEVE DH-XCD05 Cordless Vacuum Cleaner User Manual

Model: DH-XCD05 | Brand: AROEVE

1. INTRODUCTION

Thank you for choosing the AROEVE DH-XCD05 Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read this manual thoroughly before first use and keep it for future reference.

2. SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance.

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up toxic material (e.g., chlorine bleach, ammonia cleaner, drain cleaner).
- Do not use without dust cup and/or filters in place.

- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to battery pack, picking up or carrying the appliance.
- Recharge only with the charger specified by the manufacturer.

3. PACKAGE CONTENTS

Carefully unpack your AROEVE DH-XCD05 and check that all items are present and in good condition. If any items are missing or damaged, please contact customer support.

- Main Vacuum Body
- Extension Wand
- Motorized Floor Brush
- Removable Battery
- Power Adapter
- Crevice Tool
- Dusting Brush
- Accessory Kit
- Wall Mount Bracket
- User Manual (this document)

4. PRODUCT OVERVIEW & ASSEMBLY

Familiarize yourself with the components of your AROEVE DH-XCD05 vacuum cleaner before assembly and operation.

Aspirapolvere Wireless Intelligente ed Efficiente
Sperimenta una pulizia intelligente e senza sforzo ogni giorno

500W 4 Modalità
45KPA 60 Minuti

Aspirapolvere Wireless Versatile
Tre livelli di potenza per ogni esigenza di pulizia

15KPA 22KPA 45KPA

The advertisement features a woman in a white dress using the purple and black AROEVE DH-XCD05 vacuum cleaner on a wooden floor. The background shows a bright room with large windows and white curtains. The text is in Italian. The top section highlights the vacuum's intelligence and efficiency, while the bottom section emphasizes its versatility with three power levels: 15KPA, 22KPA, and 45KPA. Icons represent power (500W), modes (4), suction (45KPA), and runtime (60 minutes).

Image: The AROEVE DH-XCD05 vacuum cleaner demonstrating its powerful 45KPA suction, effectively cleaning dust, pet hair, and food particles.

Assembly Steps:

1. **Attach the Extension Wand:** Insert the extension wand into the main vacuum body until it clicks securely into place.
2. **Connect the Floor Brush:** Attach the motorized floor brush to the other end of the extension wand, ensuring it locks firmly.
3. **Install the Battery:** Slide the removable battery into the designated slot on the main vacuum body until it clicks.
4. **Attach Accessories:** For handheld use or specific cleaning tasks, attach the crevice tool or dusting brush directly to the main vacuum body or the extension wand.



Image: A diagram illustrating the flexible design of the vacuum, including its ability to rotate 270 degrees for easy maneuverability.

5. CHARGING THE BATTERY

Before first use, fully charge the battery for approximately 5 hours. The LED display will indicate the charging status.

- Connect the power adapter to the charging port on the battery or the wall mount.
- Plug the adapter into a power outlet.
- The battery indicator on the LED display will show charging progress. Once fully charged, the indicator will show 100%.
- A full charge provides up to 60 minutes of runtime, depending on the selected power mode.

60 Minuti di Pulizia Ininterrotta

Energia di lunga durata per ogni stanza



Ricarica 5H



Autonomia 60Min



La durata effettiva dipende dalle dimensioni delle particelle, stato della batteria, ecc.

Image: Visual representation of the vacuum's battery performance, highlighting a 5-hour recharge time and up to 60 minutes of continuous operation.

6. OPERATING INSTRUCTIONS

Power On/Off:

Press the power button on the handle to turn the vacuum cleaner on or off.

Mode Selection:

The AROEVE DH-XCD05 offers four cleaning modes: Automatic, Low, Medium, and High. Use the mode selection button on the LED display to cycle through these options.

- **Automatic Mode:** The vacuum intelligently adjusts suction power based on dust levels and floor type, optimizing cleaning efficiency and battery life.
- **Low Mode:** Suitable for light cleaning and extending runtime.

- **Medium Mode:** For everyday cleaning tasks.
- **High Mode:** Provides maximum suction for stubborn dirt and deep cleaning.



Image: The vacuum's intelligent automatic mode, showing how it adjusts suction (e.g., 22000Pa for hard floors, 45000Pa for carpets) based on surface and debris.

LED Display:

The smart LED touchscreen display provides real-time information about the vacuum's status.

- **Battery Indicator:** Shows the remaining battery percentage.
- **Mode Display:** Indicates the current cleaning mode (Auto, Low, Mid, High).
- **Error Alerts:** Provides notifications for blockages or other issues, aiding in troubleshooting.

Display LED Intelligente

Tutte le informazioni in un unico schermo,
controllo a portata di mano



Indicatore
Batteria



Avvisi
Guasti



Cambio
Modalità

Image: A close-up of the intelligent LED display, showing battery percentage, current mode, and indicators for potential malfunctions.

Using Attachments:

The vacuum comes with various attachments for versatile cleaning.

- **Motorized Floor Brush:** Ideal for hard floors and carpets, featuring LED lights to illuminate dust.
- **Crevice Tool:** For narrow gaps, corners, and hard-to-reach areas.
- **Dusting Brush:** For delicate surfaces, upholstery, and removing dust from furniture.

Pulizia Versatile con 3 Testine

Progettato per pulire facilmente tutte le superfici



Image: The AROEVE DH-XCD05 vacuum cleaner being used with different attachments for versatile cleaning, including the main floor brush, crevice tool, and dusting brush on various surfaces like floors, car interiors, and sofas.

7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying the Dustbin:

The dustbin has a capacity of 1 liter. Empty it regularly to maintain strong suction.

1. Press the dustbin release button to detach it from the main body.
2. Position the dustbin over a trash can.
3. Press the dustbin release lever to open the bottom flap and empty the contents.
4. Close the flap and reattach the dustbin to the vacuum cleaner.

Cleaning the Filters:

The AROEVE DH-XCD05 features a 7-stage HEPA filtration system. Clean the filters regularly to prevent clogging and maintain air quality.

1. Remove the dustbin and locate the filter components.
2. Separate the HEPA filter and other filter elements.
3. Tap off loose dirt over a trash can.
4. Rinse the washable filters under cold running water until the water runs clear. Do not use detergent.
5. Allow all filter parts to air dry completely for at least 24 hours before reassembling. Do not use a hairdryer or other heating methods.
6. Reassemble the filters and place them back into the dustbin, then reattach the dustbin to the vacuum.



Image: An exploded view of the AROEVE DH-XCD05's advanced 7-stage filtration system, designed to capture 99% of allergens and micro-particles.

Cleaning the Brush Roll:

The V-shaped anti-tangle brush roll minimizes hair tangles, but occasional cleaning may be necessary.

1. Turn off the vacuum and detach the motorized floor brush.
2. Locate the brush roll access cover, usually on the bottom of the brush head.
3. Open the cover and remove the brush roll.
4. Use scissors or the cleaning tool provided to cut and remove any tangled hair or debris from the brush roll.
5. Clean the brush roll housing.
6. Reinsert the brush roll and close the access cover securely.

Rullo a Forma di V

Pulizia facile e scorrevole
senza grovigli



Rullo a V



Rullo standard

Image: A comparison showing the V-shaped anti-tangle brush roll of the AROEVE DH-XCD05, designed to prevent hair tangles, next to a standard brush roll that often accumulates hair.

8. TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery not charged or not installed correctly.	Ensure battery is fully charged and properly inserted.
Reduced suction power	Dustbin full, filters clogged, or blockage in nozzle/hose.	Empty dustbin, clean filters, check for and remove blockages.
Brush roll not spinning	Hair/debris tangled in brush roll, or brush roll blocked.	Turn off vacuum, remove brush roll, and clear any obstructions.
Battery not charging	Power adapter not connected properly or faulty.	Ensure adapter is securely plugged into both vacuum/charger and outlet. Check outlet functionality.
Unusual noise	Blockage in airflow path or foreign object in brush roll.	Check for and remove any blockages or foreign objects.

9. SPECIFICATIONS

Technical specifications for the AROEVE DH-XCD05 Cordless Vacuum Cleaner.

Model Number	DH-XCD05
Brand	AROEVE
Motor Power	500W Brushless Motor
Suction Power	Up to 45KPA
Battery Voltage	25.9V
Runtime	Up to 60 minutes
Charging Time	Approx. 5 hours
Dustbin Capacity	1 Liter
Filter Type	7-Stage HEPA Filtration
Cleaning Modes	4 (Automatic, Low, Medium, High)
Special Features	Smart LED Display, V-shaped Anti-tangle Brush, LED Headlights, Flexible Tube
Dimensions (L x W x H)	25 x 15 x 100 cm (approx.)

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact AROEVE customer service. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question