

Hetoy B0FCF6K5HJ

Hetoy 24V 2 Seater Ride on UTV Kids Car Instruction Manual

Model: B0FCF6K5HJ

IMPORTANT SAFETY INFORMATION

This product is designed for children aged 3 years and up. Adult supervision is required at all times. Ensure all safety belts are securely fastened before operation. Do not operate near roads, steep inclines, or bodies of water. Always follow local regulations regarding ride-on toy usage.

Maximum load capacity: 110 lbs (50 kg). Only one child aged 4-8 or two children aged 3-4 should ride at a time. This product is certified with ASTM and CPSIA standards for safety.

PRODUCT OVERVIEW

The Hetoy 24V 2 Seater Ride on UTV is an electric vehicle designed for children, offering both manual operation and parental remote control. It features a robust design with powerful motors, spring suspensions, and various entertainment options.



Image: The Hetoy 24V 2 Seater Ride on UTV Kids Car in black, showcasing its robust design and remote control.

Key Features:

- **Electric UTV with Parent Remote Control:** Offers two driving modes for different age groups, allowing parents to control for younger children or children to operate independently.
- **Spacious 2-Seater Design:** Features real 20-inch seats with adjustable safety belts, accommodating one child aged 4-8 or two children aged 3-4.
- **24V 400W Powerful Performance:** Equipped with a 24V 7AH battery and 2x200W motors, providing up to 50 minutes of ride time and a max speed of 4.35 mph. Includes 4 spring suspensions for smooth riding.
- **Multifunctional Control Console:** Easy one-button start, music playback, LED headlights & rear pathfinder lights, high/low speed function, and Bluetooth connectivity for playing music or stories.
- **Anti-Skid Enlarged Wheels:** Designed for various terrains, including asphalt, country roads, board roads, sand beaches, and mountain roads.

WHAT'S IN THE BOX

Upon opening the package, please verify that all components are present and undamaged.

- 1 x 24V Kids UTV
- 1 x Remote Control
- 1 x Charger
- 1 x User Manual (This document)
- Assembly Hardware (Screws, washers, etc.)

ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 2 hours. It is recommended to assemble the UTV in a spacious, well-lit area. Refer to the included assembly diagram for detailed steps.

1. **Wheel Installation:** Attach the wheels to the axles, ensuring all washers and nuts are securely fastened. The anti-skid enlarged wheels are designed for various terrains.
2. **Steering Wheel Assembly:** Connect the steering column to the vehicle's chassis and attach the steering wheel. Ensure it rotates freely.
3. **Seat Installation:** Place the two seats into their designated positions and secure them with the provided screws. Ensure the safety belts are accessible and functional.
4. **Battery Connection:** Locate the battery compartment. Connect the battery terminals, ensuring correct polarity (red to red, black to black).
5. **Accessory Attachment:** Install any additional accessories such as the roll bar, lights, or rear storage net pocket as per the diagram.

PRODUCT DETIAL



Rear Storage Net Pocket



Metal Body Frame



Control Panel



Image: Detailed view of the UTV's rear storage net pocket, robust metal body frame, and the multifunctional control panel.

OPERATING INSTRUCTIONS

Driving Modes:

2 MODES CONTROL

Manual mode

Children can use the accelerator pedal to operate

Remote Mode

Parents can use the remote control to ensure their children's driving safety



Image: Illustration of the two control modes: Manual mode for child operation and Remote mode for parental control.

- **Manual Mode:** For children aged 3-8 years. The child can operate the UTV using the accelerator pedal and steering wheel.
- **Remote Control Mode:** For younger children or when parental supervision is desired. Parents can use the included remote control to steer, accelerate, brake, and select high/low speed.

Starting the UTV:

1. Ensure the battery is fully charged.
2. Press the "Start/Stop" button on the multifunctional control console to power on the vehicle.
3. Select desired speed (High/Low) using the switch on the dashboard or remote control.
4. For manual mode, press the accelerator pedal. For remote mode, use the remote control.

Multifunctional Dashboard:



Image: Detailed view of the UTV's multifunctional dashboard, highlighting controls for lights, volume, music, USB port, power switch, high/low speed, forward/reverse, and Bluetooth.

- **Lights:** Toggle LED headlights and rear pathfinder lights.
- **Volume:** Adjust audio output.
- **Music/Story Player:** Play pre-loaded tunes or connect via Bluetooth/USB for custom audio.
- **USB Port:** For connecting external media devices.
- **Power Switch:** On/Off for the vehicle.
- **High/Low Speed:** Select driving speed.
- **Forward/Reverse:** Control driving direction.
- **Bluetooth:** Pair with a mobile phone to play music or stories.

BATTERY CHARGING

The UTV is powered by a 24V 7AH battery. For optimal performance and battery life, follow these charging guidelines:

- Connect the charger to the charging port on the UTV.
- Plug the charger into a standard wall outlet.
- Charging time is typically 8-10 hours for a full charge. Do not overcharge.
- A full charge provides approximately 50 minutes of playtime.
- Always charge the battery in a dry, well-ventilated area, away from flammable materials.

MAINTENANCE

- **Cleaning:** Wipe the UTV with a soft, damp cloth. Do not use abrasive cleaners or solvents. Avoid spraying water directly onto electrical components.
- **Battery Care:**
 - Charge the battery fully before first use.
 - Recharge the battery after each use.
 - If storing for extended periods, charge the battery every 30 days to maintain its life.
 - Do not allow the battery to completely discharge.
- **Tire Inspection:** Regularly check the anti-skid enlarged wheels for wear and tear. Ensure they are free from debris that could affect performance.

- **General Inspection:** Periodically check all screws, bolts, and connections to ensure they are tight and secure. Inspect the spring suspensions for any damage.
- **Storage:** Store the UTV in a dry, cool place, away from direct sunlight and moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
UTV does not move.	Battery is low or not connected; Power switch is off; Loose wire connection; Overload.	Charge the battery; Turn on the power switch; Check all wire connections; Reduce load (max 110 lbs).
Short playtime.	Battery not fully charged; Old battery; Overloaded.	Charge battery for 8-10 hours; Replace battery if old; Ensure load is within limits.
Slow speed.	Low battery; Overload; Operating on rough terrain.	Charge battery; Reduce load; Operate on smoother surfaces.
Remote control not working.	Remote control battery low; Not paired correctly.	Replace remote control battery (1 AAA battery required); Refer to remote pairing instructions in the full manual (if applicable).
Lights or music not working.	Loose connection; Malfunctioning component.	Check connections to the dashboard; Contact customer support if issue persists.

SPECIFICATIONS

- **Model:** B0FCF6K5HJ
- **Brand:** Hetoy
- **Motor:** 2 x 200W (Total 400W)
- **Battery:** 24V 7AH
- **Speed:** 3.10 - 4.35 mph
- **Overall Size (L x W x H):** 47.24 x 31.89 x 32.68 inches
- **Wheel Diameter:** 12.6 inches
- **Maximum Load:** 110 lbs (50 kg)
- **Playtime:** Approximately 50 minutes
- **Charging Time:** 8-10 hours
- **Item Weight:** 66.7 pounds
- **Recommended Age:** 3 years and up
- **Country of Origin:** China
- **Certifications:** ASTM, CPSIA

PERFECT SIZED

Can accommodate 2 children with a height of 35-45"



Image: Dimensional diagram of the UTV, indicating its length, width, height, and wheel diameter for size reference.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Hetoy customer service. Refer to the product packaging or the seller's information on the purchase platform for contact details.





This product is subject to hazardous materials regulation for transportation and is non-returnable in some cases. Please review the seller's return policy at the time of purchase.

Protection plans may be available for purchase separately. Check with your retailer for details on extended warranty options.

© 2025 Hetoy. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Related Documents

	<p>AHL011 Kids Ride-On Jeep Owner's Manual</p> <p>Owner's manual for the AHL011 ride-on toy vehicle, providing assembly instructions, operating guidelines, maintenance tips, and troubleshooting for a 12V battery-powered electric car for children.</p>
	<p>Hetoy XMX627 Mercedes-Benz G-Wagon Ride-On Car User Manual</p> <p>Comprehensive user manual for the Hetoy XMX627 licensed Mercedes-Benz G-Wagon ride-on electric car. Includes assembly instructions, safety guidelines, operation, charging, and troubleshooting.</p>
	<p>Hetoy HL-2888 Four-Wheel Electric Children Car User Manual and Assembly Guide</p> <p>Comprehensive user manual and assembly guide for the Hetoy HL-2888 four-wheel electric children's ride-on car. Includes specifications, operating instructions, charging, maintenance, troubleshooting, and safety warnings.</p>
	<p>Battery Operated Motorcycle SX2328 Assembly and User Manual</p> <p>Assembly instructions, product specifications, safety warnings, usage directions, charging information, maintenance, and troubleshooting for the SX2328 battery-operated motorcycle.</p>