

[Manuals.plus](#) /

> [eeTao](#) /

> eeTao Replacement Charger Instruction Manual for JELLYPIG X100 Cordless Vacuum

eeTao JELLYPIG X100 Charger

eeTao Replacement Charger Instruction Manual

Compatible with JELLYPIG X100 Motorized Brush Cordless Vacuum Cleaner

1. PRODUCT OVERVIEW

This eeTao replacement charger is designed to provide reliable power to the JELLYPIG X100 Motorized Brush Cordless Vacuum Cleaner. It ensures efficient charging of the DC29.6V 2500mAh battery, allowing for consistent performance of your vacuum cleaner.



Image 1.1: The eeTao Replacement Charger unit. This compact power adapter is designed for durability and efficient charging.

eeTao[®] Power Supply Adapter Compatible with:



Machine Not Included

Image 1.2: Visual representation of the charger's compatibility with the JELLYPIG X100 Motorized Brush Cordless Vacuum Cleaner. Note: The vacuum cleaner is not included with the charger.

2. WHAT'S IN THE BOX

The package contains the following item:

- 1 x eeTao Replacement Charger Adapter

3. SETUP

3.1 Safety Information

Please read and understand the following safety precautions before using the charger:

- **OVP (Over Voltage Output Protection):** The charger is equipped with protection against excessive output voltage.
- **OCP (Over Current Output Protection):** The charger includes protection against excessive output current.
- **SCP (Short Circuit Output Protection):** The charger is protected against short circuits.
- Ensure the charger is used in a dry environment. Avoid exposure to moisture or liquids.

- Do not attempt to disassemble or modify the charger.
- Keep out of reach of children.

Security Protection

Multiple professional protection, so that fast charge more safe



Image 3.1: Diagram illustrating the multiple protection features of the charger, including temperature, overcharge, short circuit, anti-interference, and lightning protection.

3.2 Connecting the Charger

1. Locate the charging port on your JELLYPIG X100 Cordless Vacuum Cleaner.
2. Insert the barrel connector of the eeTao charger into the vacuum's charging port. Ensure a secure connection.
3. Plug the charger's AC power cord into a standard 100-240 VAC 50/60 Hz wall outlet.

4. OPERATING INSTRUCTIONS

4.1 Charging the Battery

Once connected, the charger will begin to supply power to the vacuum's battery. The charging status is typically indicated by an LED light on the charger or the vacuum itself.

eeTao[®] AC Adapter Power Supply
Compatible with:

Charging



Charged



Image 4.1: Example of charging status indicators. A red light typically indicates charging, while a green light indicates a full charge.

- A red indicator light usually signifies that the battery is currently charging.
- A green indicator light typically means the battery is fully charged.
- Charging time may vary depending on the battery's current charge level.
- Unplug the charger from the wall outlet and the vacuum once charging is complete or when the vacuum is not in use.

Note: Rechargeable batteries are consumable items and have a finite lifespan, typically 1 to 3 years. If the

vacuum's battery is damaged or has reached the end of its life, it may not be able to charge, even with a functional charger.

5. MAINTENANCE

- Keep the charger clean and free from dust and debris. Use a soft, dry cloth for cleaning.
- Store the charger in a cool, dry place when not in use.
- Avoid bending or crimping the power cord excessively to prevent internal damage.
- Regularly inspect the charger and its cable for any signs of damage. Discontinue use if damage is observed.

6. TROUBLESHOOTING

Issue	Possible Cause	Solution
Vacuum is not charging.	Charger not properly connected.	Ensure the barrel connector is fully inserted into the vacuum's charging port and the AC plug is securely in the wall outlet.
Vacuum is not charging.	Wall outlet is not active.	Test the wall outlet with another device to confirm it has power.
Vacuum is not charging.	Damaged charger or cable.	Inspect the charger and cable for visible damage. If damaged, replace the charger.
Vacuum is not charging.	Vacuum battery is faulty or at end of life.	If the charger is confirmed to be working, the vacuum's battery may need replacement. Consult the JELLYPIG X100 vacuum manual or support.

7. SPECIFICATIONS

Feature	Specification
Brand	eeTao
Model Number	JELLYPIG X100 Charger
Compatible Devices	JELLYPIG X100 Cordless Vacuum Cleaner
Input Voltage	100-240 VAC, 50/60 Hz
Output Voltage	33.2 Volts (DC)
Output Current	0.96 Amps
Connector Type	Barrel Connector

Feature	Specification
Special Features	OVP, OCP, SCP Protection (Over Voltage, Over Current, Short Circuit Protection)
Item Weight	4 Ounces
Included Components	1 adapter

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This eeTao Replacement Charger comes with a warranty:

- **30 Days Refund:** If you are not satisfied with the product, you may be eligible for a refund within 30 days of purchase.
- **24 Months Exchange:** The product is covered by a 24-month exchange policy for manufacturing defects.

Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, concerns, or support regarding your eeTao Replacement Charger, please refer to the seller's contact information provided at the time of purchase or visit the eeTao store on Amazon for further assistance.