

[Manuals.plus](#) /

› [Philips](#) /

› Philips Cordless Table Lamp Model 8507502012 Instruction Manual

Philips 8507502012

Philips Cordless Table Lamp Instruction Manual

Model: 8507502012

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Philips Cordless Table Lamp. Please read these instructions carefully before operating the product and retain them for future reference.

SAFETY INFORMATION

- Do not expose the lamp to extreme temperatures or direct sunlight for prolonged periods.
- Use only the provided USB-C cable for charging.
- Keep the lamp away from flammable materials.
- Do not attempt to disassemble or modify the lamp. This may void the warranty and pose a safety risk.
- Ensure the silicone cover for the charging port is properly sealed when not charging to maintain water resistance.

WHAT'S IN THE BOX

- Philips Cordless Table Lamp (2 units)
- Adjustable Rods (2 sets)
- USB-C Charging Cables (2 units)
- Instruction Manual

ASSEMBLY AND SETUP

The Philips Cordless Table Lamp requires minimal assembly. Follow these steps:

1. Screw the first rod securely into the lamp's base.

2. For increased height, screw the second rod onto the first rod.
3. Screw the lamp head onto the top rod. Ensure all connections are firm.



Image: Easy assembly steps for the Philips Cordless Table Lamp.

OPERATING INSTRUCTIONS

Power and Light Control

- **Turn On/Off:** Press the touch button located on the top of the lamp head.
- **Change Color Temperature (CCT):** While the lamp is on, short-press the touch button to cycle through the three available color temperatures: 3000K (warm white), 4500K (neutral white), and 6500K (cool white).
- **Adjust Brightness (Stepless Dimming):** While the lamp is on, long-press the touch button to continuously adjust the brightness level from 10% to 100%. Release the button when the desired brightness is reached. The lamp will memorize your last brightness setting.

Smooth Dimming and 3 CCT Settings




Image: Demonstrating touch control for dimming and CCT settings.

Adjustable Height

The lamp offers two height options to suit different lighting needs. You can assemble the lamp with one or two rods to achieve the desired height.

- **Short Height:** Use one rod for a compact lamp (approximately 7.48 inches).
- **Tall Height:** Use both rods for an extended lamp (approximately 12.99 inches).

Rechargeable Battery



Image: Philips lamps illustrating adjustable height options.

CHARGING

The Philips Cordless Table Lamp is equipped with a high-capacity rechargeable battery. To charge the lamp:

1. Locate the concealed USB-C charging port on the underside of the lamp head. It is protected by a silicone cover.
2. Gently open the silicone cover.
3. Connect the provided USB-C charging cable to the port and a suitable USB power adapter (not included).
4. The charging indicator will illuminate. Once fully charged, the indicator may change color or turn off.
5. Ensure the silicone cover is securely closed after charging to maintain water resistance.

The lamp can be used while charging. Battery runtime varies based on brightness settings: up to 8 hours at 100% brightness and up to 72 hours at 5% brightness.

Easy to install



Accessories included



x2



x2

Image: Charging the Philips Cordless Table Lamp via USB-C.

Video: Demonstrating the features and versatility of the Philips Portable Wireless Table Lamp, including its dimming, color temperature settings, adjustable height, and suitability for various indoor and outdoor environments.

MAINTENANCE AND CARE

Water Resistance

The Philips Cordless Table Lamp is designed to be water-resistant and corrosion-resistant, making it suitable for both indoor and outdoor use. It can withstand exposure to rain and humidity up to 85%.

- To clean the lamp, wipe it with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.
- Ensure the USB-C charging port's silicone cover is always closed when not charging to maintain its water-resistant properties.

Portable Cordless Table Lamp



Image: Philips lamp demonstrating water resistance in an outdoor setting.

TROUBLESHOOTING

- **Lamp does not turn on:** Ensure the battery is charged. Connect the lamp to a power source using the USB-C cable.
- **Light is dim or flickers:** The battery may be low. Recharge the lamp.
- **Cannot change CCT or brightness:** Ensure you are using the correct touch gestures (short-press for CCT, long-press for dimming).
- **Charging issue:** Check if the USB-C cable is properly connected to both the lamp and the power adapter. Try a different USB-C cable or power adapter.

SPECIFICATIONS

Feature	Detail
Brand	Philips
Model Name	Philips Table Lamp 2PK Black 929004754603

Item Model Number	8507502012
UPC	046677609221
Product Dimensions	4.73"D x 4.73"W x 13"H (adjustable)
Item Weight	1.32 Pounds
Material	Metal, Plastic
Finish Type	Matte
Light Source Type	LED
Wattage	2.1 watts
Brightness	110 Lumen (Max)
Light Color	3000K-4500K-6500K (Adjustable)
Control Method	Touch
Power Source	Battery Powered (Rechargeable)
Water Resistance Level	Water Resistant
Indoor/Outdoor Usage	Indoor, Outdoor

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Philips website. Keep your proof of purchase for warranty claims.