Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave FST00225-F-AB1

Bellemave Full Size Floor Bed Frame with LED Lights

Model: FST00225-F-AB1

Instruction Manual

1. Introduction

Thank you for choosing the Bellemave Full Size Floor Bed Frame with LED Lights. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed frame. Please read these instructions carefully before beginning assembly and retain them for future reference.



Figure 1: Assembled Bellemave Full Size Floor Bed Frame with LED Lights.

2. Safety Information

WARNING: Failure to follow these safety guidelines may result in injury or damage to the product.

- Do not exceed the maximum load capacity of**350 pounds (158 kg)**.
- Always follow the assembly instructions carefully to prevent instability or collapse.
- Adult assembly is required. Keep all small parts and packaging materials away from children during assembly.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten hardware as needed.
- Do not allow children to climb on the roof structure or use it for hanging objects, as this may cause the bed to tip or damage the frame.
- Place the bed on a flat, level surface.

3. Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Bed Frame Components (Metal beams, posts, roof sections)
- Slats (for mattress support)
- Hardware Pack (Screws, bolts, washers, Allen wrench)
- LED Light Strip with Controller
- Assembly Instructions Manual

4. Assembly Instructions

Assembly is designed to be straightforward. We recommend two adults for efficient and safe assembly. Please refer to the included detailed assembly instructions and component labels for specific steps.

4.1. Required Tools

- Allen wrench (usually included in hardware pack)
- Phillips head screwdriver (not always included, may be needed for some screws)

4.2. General Assembly Steps

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Match each part to the component list in the separate assembly guide.
2. **Assemble the Base Frame:** Connect the side rails and end rails to form the rectangular base of the bed. Secure with the provided hardware.
3. **Attach Vertical Posts:** Secure the vertical posts to the corners of the base frame.
4. **Install Roof Structure:** Assemble the angled roof beams and attach them to the top of the vertical posts, creating the house shape.
5. **Insert Slats:** Place the metal slats across the bed frame to create a sturdy mattress support. Ensure they are evenly spaced and secured according to the specific instructions.
6. **Install LED Lights:** Carefully attach the LED light strip to the roof structure. Refer to the 'Operating Instructions' section for details on connecting and using the lights.
7. **Final Check:** Ensure all bolts and screws are tightened. Do not overtighten.




Figure 2: Product dimensions for the Full Size Floor Bed Frame.



Figure 3: Detail of the metal slat support system.

5. Operating Instructions (LED Lights)

Your Bellemave Floor Bed Frame includes a colorful LED light strip to enhance the room's ambiance. The LED lights offer four colors and various dynamic lighting modes.

5.1. Connecting the LED Lights

1. Ensure the LED strip is securely attached to the bed frame's roof structure.
2. Connect the LED strip to the provided controller.
3. Plug the controller's power adapter into a standard electrical outlet.

5.2. Using the LED Lights

Use the included remote control (if applicable) or buttons on the controller to:

- **Power On/Off:** Press the power button to turn the lights on or off.
- **Change Colors:** Select from four available colors.
- **Adjust Dynamic Modes:** Cycle through various lighting effects (e.g., fade, flash, strobe).
- **Adjust Dynamic Speed:** Increase or decrease the speed of dynamic lighting modes.



Figure 4: Features of the Smart LED Light system.




Figure 5: Close-up of the LED light strip.

6. Maintenance

6.1. Cleaning

- Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- For the LED lights, gently wipe with a dry, soft cloth. Do not use liquids directly on the lights or electrical components.

6.2. Regular Checks

- Periodically inspect all bolts and screws to ensure they remain tight. Re-tighten if necessary to maintain stability and prevent creaking.
- Check the LED light strip and wiring for any signs of wear or damage. If damage is found, discontinue use and contact customer support.

7. Troubleshooting

Problem	Possible Cause	Solution
Bed frame creaks or is unstable.	Loose hardware connections.	Check and tighten all bolts and screws. Ensure all parts are correctly aligned.

Problem	Possible Cause	Solution
LED lights do not turn on.	Power connection issue; faulty LED strip/controller.	Ensure the power adapter is securely plugged into an outlet and the controller. Check for any visible damage to the wiring. If issues persist, contact customer support.
Missing parts during assembly.	Packaging error.	Review the package contents list. Contact customer support with details of the missing parts.

8. Specifications

Feature	Detail
Brand	Bellemave
Model Number	FST00225-F-AB1
Size	Full
Product Dimensions (L x W x H)	78.5" x 55.91" x 58.4"
Color	Black With Led
Material	Metal
Finish Type	Lacquered
Included Components	Slat, LED Light Strip
Compatible Mattress Size	Full
Assembly Required	Yes
Item Weight	25 pounds (11.3 kg)
Form Factor	House Floor Bed with Rooftop
UPC	197793819664

9. Warranty and Support

Bellemave products are designed for quality and durability. For specific warranty information, please refer to the documentation included with your purchase or contact Bellemave customer service directly.

9.1. Returns

This product is eligible for 90-day easy returns. Please refer to your retailer's return policy for detailed instructions.

9.2. Customer Support

If you have any questions, require assistance with assembly, or need replacement parts, please contact Bellemave customer support. Contact information can typically be found on the Bellemave official website or through your

purchase platform.

© 2025 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FCFJGSCK

More documents and user manuals: **https://manuals.plus/**