

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [JMBricklayer](#) /

› JMBricklayer Pirate Ship Models 40001 and 40002 Instruction Manual

JMBricklayer 40001, 40002

JMBricklayer Pirate Ship Models 40001 & 40002

INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the JMBricklayer Pirate Ship building block models. This manual provides essential information for the assembly, operation, and maintenance of your **Model 40001 (Ghost Ship)** and **Model 40002 (The Black Pearl)**. These intricate building sets feature detailed designs and integrated LED lighting systems to enhance your display.

Please read these instructions carefully before beginning assembly to ensure a smooth and enjoyable building experience.

2. Safety Information

- **Small Parts Warning:** This product contains small parts and is not suitable for children under 3 years old due to choking hazards.
- **Recommended Age:** These models are recommended for ages 14 and up due to their complexity.
- **Battery Safety (Model 40002):** If using batteries, ensure they are inserted with correct polarity (+/-). Do not mix old and new batteries, or different types of batteries. Remove exhausted batteries promptly.
- Keep all packaging materials away from children.

3. Package Contents

Each JMBricklayer Pirate Ship model package typically includes:

- Building blocks (sorted by step or type)
- Detailed instruction manual (physical booklet)
- LED light kit (specific to model)
- Battery box (for Model 40002)
- Sticker sheet (for Model 40001 glow-in-the-dark elements)

Note: Batteries (3x AA for Model 40002) are not included and must be purchased separately.

4. Assembly Instructions

Follow the step-by-step instructions provided in the physical instruction booklet included with your model. Pay close attention to the diagrams and part lists for each step.

4.1. General Assembly Tips

- Organize your blocks: Before starting, sort the blocks by color, size, or type as suggested in your manual.
- Follow the sequence: Assemble the model strictly according to the numbered steps.
- Press firmly: Ensure all blocks are securely connected to prevent parts from detaching.

4.2. LED Light Installation (Model 40001 - Ghost Ship)

Model 40001 is equipped with 9 green LED beads. Integrate the LED wiring as indicated in the specific steps of your physical manual. The wiring is designed to be discreetly hidden within the model's structure.



Image: JMBricklayer Model 40001, the Mysterious Ghost Ship, illuminated with its vivid green LED lights.

The side stickers for Model 40001 also feature a glow-in-the-dark design. Apply these stickers carefully according to the manual's instructions to enhance the ship's eerie appearance in low light.

Turn on the Lights by Simply Connecting the Power Source



Image: Close-up of JMBricklayer Model 40001, illustrating the simple connection of the power source to activate the green LED lights.

4.3. LED Light Installation (Model 40002 - The Black Pearl)

Model 40002 is equipped with 11 warm LED lights. Follow the assembly steps in your manual to correctly integrate the LED wiring and the battery box into the ship's structure.

Classic Black Pearl Pirate Ship



Image: JMBricklayer Model 40002, the Classic Black Pearl Pirate Ship, showcasing its charming warm LED illumination.

11 LED LIGHTS POWERED BY USB VIA BATTERY BOX (3 AA NEEDED)



Image: Illustration of Model 40002's 11 LED lights being powered by USB via the battery box, which requires 3 AA batteries.



Image: Detailed views of Model 40002, highlighting the simulated interior, integrated lighting, exquisite design elements, and textured sails.

5. Operating Instructions (LED Lights)

5.1. Model 40001 (Ghost Ship)

To activate the green LED lights on Model 40001, simply connect the provided power source to the designated port on the model. The lights will illuminate, creating a mysterious green radiance.

5.2. Model 40002 (The Black Pearl)

For Model 40002, insert 3 AA batteries (not included) into the battery box, ensuring correct polarity. Connect the battery box to the model's LED wiring. Locate the switch on the battery box and turn it ON to activate the warm LED lights. The battery box can also be powered via a USB connection.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth or a small brush to gently remove dust from the model. Avoid using water or

chemical cleaners, as these may damage the blocks or electronic components.

- **Storage:** Store the model in a cool, dry place away from direct sunlight to prevent discoloration or warping of the plastic blocks.
- **Battery Replacement (Model 40002):** When the LED lights dim or stop working, replace all 3 AA batteries in the battery box. Ensure the model is turned OFF before replacing batteries.

7. Troubleshooting

- **LED Lights Not Working:**
 - Check all wiring connections to ensure they are secure.
 - For Model 40002, verify that the batteries are correctly inserted and are not depleted. Try replacing them with fresh batteries.
 - Ensure the power switch (for Model 40002) or power source (for Model 40001) is turned ON.
- **Loose Parts:** If any blocks become loose, gently press them back into place. Refer to the instruction manual for correct placement.

8. Specifications

Model 40001: Ghost Ship The Flying Dutchman

Pieces: 1100+

LEDs: 9 Green LED beads

Special Features: Glow-in-the-dark side stickers

Dimensions (L x W x H): Approximately 16.54 x 4.92 x 12.83 inches

Civilization - Medieval Times
Ghost Ship The Flying Dutchman

40001

1100+pcs




Image: Dimensional overview of JMBricklayer Model 40001.

Model 40002: Age of Exploration - The Black Pearl

Pieces: 1713+

LEDs: 11 Warm LED lights

Power: 3 AA batteries (not included) or USB

Dimensions (L x W x H): Approximately 21.65 x 7.87 x 16.14 inches

Civilization- Medieval Times
Age of Exploration-The Black Pearl

40002
1713+PCS



Image: Dimensional overview of JMBricklayer Model 40002.

14

+AGES

1713 PCS

Image: JMBricklayer Model 40002, highlighting the recommended age of 14+ and the piece count of 1713+.

9. Warranty and Support

JMBricklayer products are designed for quality and enjoyment. For any missing parts, assembly difficulties, or other inquiries, please contact JMBricklayer customer service. Refer to the contact information provided in your product packaging or visit the official JMBricklayer website for support.

Please retain your purchase receipt as proof of purchase for any warranty claims.