

Anna Bella PF1007

Anna Bella 10.1-inch Digital Photo Frame (Model PF1007) User Manual

Comprehensive Instructions for Setup, Operation, and Maintenance

1. INTRODUCTION

This manual provides detailed instructions for the Anna Bella 10.1-inch Digital Photo Frame, Model PF1007. Please read this manual thoroughly before using the device to ensure proper operation and to maximize your experience. Keep this manual for future reference.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1x Anna Bella Digital Photo Frame (Model PF1007)
- 1x Stand
- 1x User Manual
- 1x DC Adapter

Packing List

- 1x Digital photo frame
- 1x Stand
- 1x User Manual
- 1x DC adapter



Image: The package contents include the digital photo frame, a stand, a user manual, and a DC power adapter.

3. PRODUCT OVERVIEW

The Anna Bella Digital Photo Frame PF1007 features a 10.1-inch 1280x800 HD IPS touch screen, designed for displaying photos and short videos with clarity and vibrant colors. It includes 32GB of internal storage and supports external memory via Micro SD card up to 128GB.



Image: The Anna Bella digital photo frame shown in both vertical and horizontal orientations, displaying family photos.

Key Features:

- **High-Resolution IPS Touch Screen:** 10.1-inch 1280x800 HD display with wide viewing angles and accurate color reproduction.
- **Ample Storage:** 32GB built-in storage, expandable up to 128GB via Micro SD card.
- **Remote Sharing:** Share photos and 15-second videos wirelessly via the free AiMOR app (iOS/Android).
- **Multi-User Sharing:** Invite friends and family to share photos directly to the frame.
- **Flexible Placement:** Auto-rotating bracket supports both portrait and landscape modes.
- **Smart Features:** Displays current time and temperature, includes a sleep mode for energy saving.
- **Customizable Slideshows:** Adjust photo duration, order, add captions, and select display modes.

10.1 Inch

FHD 16:10

WIFI Digital Picture Frame

AiMOR

WIFI

Video Calls

Weather

Sleep Mode

User Connect

Adjust Brightness

IPS touch screen

32GB Momery

Automatic Switch on/off

Image: An illustration highlighting the frame's features such as Wi-Fi connectivity, AiMOR app compatibility, video call support, weather display, sleep mode, user connection, brightness adjustment, IPS touch screen, 32GB memory, and automatic on/off.

AnnaBella

10.1 inch Digital Photo Frame

Share your wonderful world

WIFI

32GB

Screen Touch

10.1 Inch

HD

Sleep Mode

Image: A banner showcasing the Anna Bella 10.1-inch Digital Photo Frame with icons representing its core features: Wi-Fi, 32GB storage, touch screen, 10.1-inch display, HD resolution, and sleep mode.

4. SETUP

4.1 Initial Power On

1. Connect the DC adapter to the frame's power port and then to a power outlet.
2. The frame will automatically power on. Follow the on-screen prompts to select your language and time zone.

4.2 Wi-Fi Connection

1. On the frame's screen, navigate to **Settings > Wi-Fi**.
2. Select your Wi-Fi network from the list.
3. Enter your Wi-Fi password and tap **Connect**.

4.3 AiMOR App Installation

The AiMOR app is required for wireless photo and video sharing.

1. Download the free AiMOR app from the App Store (iOS) or Google Play Store (Android) on your smartphone or tablet.
2. Install and open the app.
3. Create a new account or log in if you already have one.




Image: A sequence of smartphone screens illustrating how to download the AiMOR app from an app store, register or log in, and access the app's main interface.

4.4 Frame Pairing

1. On your Anna Bella Digital Photo Frame, go to **Settings > My Frame** to find your unique Frame ID.
2. In the AiMOR app, tap **Add Frame** and enter the Frame ID displayed on your device.
3. Confirm the connection on both the app and the frame.

5. OPERATION

5.1 Adding Photos and Videos

You can add media to your frame using the AiMOR app, a Micro SD card, or a USB drive.

5.1.1 Via AiMOR App (Wireless Sharing)

1. Open the AiMOR app on your smartphone.
2. Select the photos or 15-second videos you wish to send.
3. Choose the connected frame as the recipient.
4. Optionally, add a caption to your media.
5. Tap **Send**. The media will appear on your frame once uploaded.




Image: A step-by-step visual guide showing how to select photos from a gallery, choose recipients, add a caption, and select the important part of the photo before sending it to the frame via the AiMOR app.

5.1.2 Via Micro SD Card or USB Drive

1. Insert a Micro SD card or USB drive containing your media into the corresponding slot on the frame.
2. The frame will detect the external storage. Navigate to the storage option on the screen.
3. Select the photos or videos you wish to import to the frame's internal memory.
4. Confirm the import.

Built-in 32GB Memory

Keeping your precious memories close at hand

Mirco SD Card

USB drivers



Image: The digital photo frame displaying a family photo, with text indicating support for Micro SD cards and USB drives for memory expansion.

5.2 Display Modes and Settings

5.2.1 Auto-Rotate Function

The frame automatically adjusts the display orientation (portrait or landscape) based on its physical position. The included stand allows for flexible placement.

With Your child



Image: The digital photo frame displayed in horizontal and vertical positions, illustrating its auto-rotate feature and suitability for both desk placement and wall mounting. Note: While the product description may mention wall mounting, the frame is primarily designed for desk placement with its auto-rotating stand.

5.2.2 Slideshow Customization

Access **Settings** on the frame to customize your slideshow:

- **Photo Duration:** Set display time from 3 to 60 seconds.
- **Order:** Choose between shuffle or chronological order.
- **Display Mode:** Select fill or fit to screen.

5.2.3 Brightness and Volume Adjustment

You can adjust the screen brightness and playback volume directly from the frame's settings or via the touch screen interface.




Image: A visual representation of adjusting the brightness and volume controls on the digital photo frame, emphasizing that videos with sound enhance memories.

5.2.4 Sleep Mode

To conserve energy, enable Sleep Mode in **Settings**. You can set specific times for the frame to automatically turn off and on (e.g., auto off 11 PM - 7 AM).

5.3 Multi-User Connection

The AiMOR app allows you to invite multiple users to share photos and videos to your frame. Each user will need to download the app and connect using your frame's unique ID.




Image: A screen on the digital photo frame showing a prompt to add friends using a unique frame ID, emphasizing private and secure sharing.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and frame. Avoid abrasive cleaners or solvents.
- **Placement:** Place the frame on a stable, flat surface away from direct sunlight, heat sources, and moisture.
- **Software Updates:** Periodically check for software updates in the frame's settings to ensure optimal performance and new features.
- **Backup:** Regularly export important photos and videos to an SD card or computer for safekeeping.

7. TROUBLESHOOTING

Issue	Possible Cause	Solution
Frame does not power on	Power adapter not connected or faulty.	Ensure the power adapter is securely connected to the frame and a working power outlet. Try a different outlet.
Cannot connect to Wi-Fi	Incorrect password, weak signal, or network issue.	Verify Wi-Fi password. Move the frame closer to the router. Restart your router and the frame.
Photos not appearing on frame	App not connected, media not sent, or incorrect format.	Ensure the AiMOR app is connected to the frame. Verify media was successfully sent. Check if media format is supported (JPEG, PNG for photos; MP4 for videos).
Screen is unresponsive	Temporary software glitch.	Restart the frame by unplugging and re-plugging the power adapter.

Issue	Possible Cause	Solution
Limited photo uploads via app	Free app version limitations.	The free version of the AiMOR app may have limitations on the number of photos uploaded at once. Consider sending in smaller batches or exploring premium app options if available.

8. SPECIFICATIONS

Feature	Detail
Brand	Anna Bella
Model	PF1007
Screen Size	10.1 Inches
Resolution	1280x800 HD (WXGA)
Display Type	IPS Touch Screen
Internal Storage	32GB
External Storage	Micro SD card (up to 128GB)
Connectivity	Wi-Fi
Compatible Devices	Smartphone (via AiMOR app)
Product Dimensions	17.98 x 25.98 x 2.51 cm
Weight	760 g
Color	Black
Country of Origin	China

9. WARRANTY AND SUPPORT







9.1 Manufacturer's Warranty

The Anna Bella Digital Photo Frame (Model PF1007) is covered by a**1-year manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external causes.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your Anna Bella Digital Photo Frame, please contact Anna Bella customer support through the retailer where the product was purchased or refer to the contact information provided in your product packaging.

Related Documents - PF1007

 The image shows a technical drawing of a glass greenhouse structure. It includes a main perspective view and two smaller side-view diagrams. The text 'Vægdrivhus' and 'Samlevejledning' is at the top.	<p>Vægdrivhus Samlevejledning: Bella & Anna Modeller</p> <p>Komplet samlevejledning til Vægdrivhus modellerne Bella (18730) og Anna (18731) fra Harald Nyborg. Indeholder trin-for-trin instruktioner, deleoversigt og tips til montering.</p>
 The image is the cover of a user manual for the Klarstein Bella Food Processor. It features the product name 'Bella' and 'KLARSTEIN' at the bottom. The cover has a white background with orange and red accents.	<p>Klarstein Bella Food Processor User Manual</p> <p>User manual for the Klarstein Bella Food Processor, detailing safety instructions, assembly, operation, cleaning, and disposal. Includes technical specifications and a sample recipe.</p>
 The image shows a product and fitting guide for the ResMed Swift FX Bella Series nasal pillows system. It includes a photograph of a person using the device and a diagram of the nasal pillows.	<p>ResMed Swift FX Bella Series Nasal Pillows System: Product and Fitting Guide</p> <p>Comprehensive guide to the ResMed Swift FX Bella Series nasal pillows system, detailing fitting instructions, features, components, and product codes for optimal comfort and performance in sleep apnea therapy.</p>
 The image shows the cover of a user manual for the Jydepejsen Bella Brændeovn. It features a photograph of the fireplace and the brand name 'Bella' at the bottom.	<p>Jydepejsen Bella Brændeovn: Betjeningsvejledning og Installationsguide</p> <p>Komplet brugervejledning til Jydepejsen Bella brændeovnen. Lær om installation, sikker brug, vedligeholdelse og fejlfinding for din brændeovn. Find alt om din Jydepejsen Bella her.</p>
 The image shows the cover of a user manual for the Bella Pro Series 8 Cup Food Processor. It features the product name 'Bella Pro Series' and '8 CUP FOOD PROCESSOR' at the bottom.	<p>Bella Pro Series 8 Cup Food Processor Instruction Manual</p> <p>User manual for the BELLA PRO SERIES 8 Cup Food Processor (Model 90111), providing detailed instructions on safety, assembly, operation, maintenance, cleaning, and recipes.</p>
 The image shows the cover of an assembly instruction manual for the Canopia Bella Series greenhouse. It features a photograph of the greenhouse and the text 'HOW TO ASSEMBLE' and 'Bella Series'.	<p>Canopia Bella Series Greenhouse Assembly Instructions</p> <p>This assembly instruction manual provides detailed guidance for constructing the Canopia Bella Series greenhouse. It includes essential information on site preparation, safety advice, required tools, and step-by-step assembly procedures for various models.</p>