

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Sweetcrispy](#) /
- › [Sweetcrispy Computer Gaming Chair C-2892-1B-BN-1 User Manual](#)

## Sweetcrispy C-2892-1B-BN-1

# Sweetcrispy Computer Gaming Chair User Manual

MODEL: C-2892-1B-BN-1

## Introduction

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your Sweetcrispy Computer Gaming Chair. Designed for ergonomic support and comfort, this high-back chair features adjustable height, flip-up armrests, and a durable PU leather finish. Please read this manual thoroughly before assembly and use to ensure safe and optimal performance.

## Safety Information

To prevent injury or damage to the chair, observe the following safety guidelines:

- Ensure the chair is properly assembled according to the instructions before use.
- Do not exceed the maximum weight capacity of **275 pounds (125 kg)**.
- Use the tilt function with the position lock engaged to maintain stability when reclining.
- Avoid standing on the chair or using it as a step stool.
- Keep hands and feet clear of moving parts during adjustment.
- Regularly inspect all bolts and screws to ensure they are tight. Retighten as necessary.
- Keep children away from the chair during assembly and adjustment.

## Package Contents

Verify that all components are present before beginning assembly. The package should contain:

- 1 x Sweetcrispy Computer Gaming Chair (disassembled)
- All necessary hardware (screws, washers, etc.)
- Assembly tools (e.g., Allen wrench)

## Setup and Assembly

---

Assembly typically takes 15-20 minutes. It is recommended to have a second person for assistance, especially when attaching the backrest.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Casters to Base:** Insert the five casters into the holes on the star base until they click securely into place.
3. **Install Gas Lift:** Place the gas lift cylinder into the center hole of the star base. Cover it with the telescopic cover.
4. **Assemble Seat and Backrest:** Attach the seat cushion to the backrest using the provided screws. Ensure proper alignment.
5. **Attach Armrests:** Secure the flip-up armrests to the seat and backrest using the designated screws. Ensure they are firmly attached.
6. **Connect Mechanism to Seat:** Attach the control mechanism to the underside of the seat cushion using the appropriate screws. Ensure the front of the mechanism faces the front of the seat.
7. **Mount Assembled Seat to Gas Lift:** Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered and stable.

# Product Dimension

Bigger and wider & Seat depth:20"

275  
LBS



Figure 1: Product Dimensions. This image illustrates the overall dimensions of the chair, including seat depth, width, and adjustable height range, along with the 275 lbs weight capacity.



Figure 2: Flip-up Armrest and Ergonomic Features. This image highlights the soft high headrest, thickened cushion, padded armrests, and S-shape backrest design.

## Operating Instructions

Your Sweetcrispy chair offers several adjustable features for personalized comfort:

- **Height Adjustment:** To raise the seat, lift the lever on the right side of the chair while taking your weight off the seat. To lower the seat, lift the lever while seated. Release the lever at the desired height.
- **Tilt Function and Lock:** Pull the lever on the right side outwards to enable the rocking function. Push the lever inwards to lock the chair in an upright position. The chair allows for a 90° to 135° tilt range.
- **Tilt Tension Adjustment:** Rotate the round knob located under the seat at the front to adjust the tension of the tilt mechanism. Turn clockwise to tighten (less rocking effort) or counter-clockwise to loosen (more rocking effort).
- **Flip-up Armrests:** The armrests can be flipped up by rotating them upwards, allowing the chair to be pushed closer to a desk or for increased mobility.
- **360° Swivel:** The chair base allows for full 360-degree rotation.

# Adjustment Function

Bigger and wider & Seat depth: 20"



Figure 3: Adjustment Functions. This image details the various ways to adjust the chair for optimal comfort and posture.



Figure 4: Space-Saving Flip-up Armrests. This image illustrates how the armrests can be flipped up to allow the chair to slide under a desk, optimizing space.



Figure 5: Tilt Adjustment Details. Images showing the tilt tension knob and the rocking/lock lever.

## Maintenance

To maintain the appearance and longevity of your chair:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the PU leather.
- **Inspection:** Periodically check all screws and bolts for tightness and re-tighten as needed to ensure stability.
- **Caster Care:** Keep casters free of hair and debris to ensure smooth rolling.

## Troubleshooting

Problem	Possible Cause	Solution
Chair does not adjust height.	Gas lift cylinder malfunction or lever not fully engaged.	Ensure the height adjustment lever is fully pulled up. If the issue persists, the gas lift may need replacement.
Chair wobbles or feels unstable.	Loose screws or improper assembly.	Check and tighten all screws and bolts. Verify that all parts are correctly assembled according to the manual.
Casters do not roll smoothly.	Debris (hair, dust) caught in casters.	Remove any debris from the casters. Clean them regularly.
Chair squeaks when moving.	Loose connections or lack of lubrication.	Tighten all screws. Apply a small amount of silicone lubricant to moving parts if necessary.

## Specifications

**Brand:** Sweetcrispy

**Model Name:** Ergonomic Computer Gaming Chair

**Item Model Number:** C-2892-1B-BN-1

**Color:** Dark Brown

**Material:** Faux Leather (PU Leather), Foam Fill

**Product Dimensions:** 20"D x 21.85"W x 44.48"H

**Item Weight:** 36.8 pounds

**Maximum Weight Recommendation:** 275 Pounds

**Back Style:** High Back

**Arm Style:** Flip-up

**Reclining Position Count:** 2 (90-135 degrees tilt)

**Indoor/Outdoor Usage:** Indoor

UPC: 781434688827

## Product Overview (Video)

---

Watch this video for a visual comparison and overview of the Sweetcrispy Computer Gaming Chair.

Your browser does not support the video tag.

Video 1: Sweetcrispy Chair Comparison. This video provides a comparison between two office chairs, including the Sweetcrispy model, highlighting features like rolling and padding.

## Warranty and Support

---

This product comes with a manufacturer's limited warranty. For specific warranty details, claims, or technical support, please refer to the warranty card included in your package or contact Sweetcrispy customer service through their official website or the retailer where the product was purchased.