

[Manuals.plus](#) /

› [PAXA](#) /

› PAXA Clipbuds7 Open Ear Clip-On Earbuds User Manual

PAXA Clipbuds715

PAXA Clipbuds7 Open Ear Clip-On Earbuds User Manual

Model: Clipbuds715

1. PRODUCT OVERVIEW

The PAXA Clipbuds7 are innovative open-ear clip-on earbuds designed for comfort, style, and high-quality audio. They feature a unique detachable butterfly earring design, an ultra-lightweight build, and advanced audio technology for an immersive listening experience while maintaining environmental awareness.



The PAXA Clipbuds7 earbuds with their charging case, showcasing the elegant butterfly earring attachments.

Your fashionable earbuds accessories, versatile style



Detachable earring design



Sparkling Crystal Butterfly Earrings




The detachable butterfly earring design allows for versatile styling, easily switching between a minimalist look and a fashionable accessory.


Ergonomic Clip-On Earbuds for All-Day Comfort

Designed with a lightweight open-loop structure, these clip-on earbuds gently attach to your ears

Wearing Tips



1. Clip the earbuds on the thinnest part of your ear



2. Adjust the earbud tip to align with your ear canal for optimal sound

Ergonomic clip-on design ensures comfortable, all-day wear. The image also illustrates proper wearing tips for optimal fit and sound.

Next-Gen Bluetooth 5.4

Stable connection with zero dropouts or lag across all your devices - phones, laptops, tablets




Equipped with Next-Gen Bluetooth 5.4 technology, the Clipbuds7 provide stable connections with zero dropouts across various devices, including phones, laptops, and tablets.

Long-Lasting Listening Experience

44 hours of battery life, you only need to charge it once a week

44 Hrs



Fast Charging

⚡ 10Mins Fast Charging = ⏮ 3Hrs Playtime

Enjoy up to 44 hours of total playtime with the charging case, including 8 hours on a single charge. Fast charging provides 3 hours of playtime from just 10 minutes of charge.

2. WHAT'S IN THE BOX

- PAXA Clipbuds7 Earbuds
- Butterfly-Style Ear Clip (Removable)
- Charging Case
- USB-C Charging Cable
- User Manual

The PAXA logo is displayed in a bold, black, sans-serif font.

PAXA Clip on earbuds Clipbuds 7

Snug & Secure Clip-On Earbuds – Comfort
That Lasts Through Every Workout!



All components included in the PAXA Clipbuds7 package.

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge the PAXA Clipbuds7 and their charging case. Connect the provided USB-C charging cable to the charging port on the case and a power source. The LED display on the case will indicate the battery level. A full charge for the case takes approximately 0.5 hours.

The earbuds charge automatically when placed inside the charging case. The case provides multiple charges, extending total listening time to 44 hours.

3.2 Initial Pairing

1. Ensure both earbuds are in the charging case and the lid is open to activate pairing mode.
2. Turn off and on Bluetooth on your device.
3. Forget "PAXA Clipbuds7" from your device's Bluetooth list and try pairing again.
4. Ensure the earbuds and case have sufficient charge.

The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

3.3 Wearing the Earbuds


The PAXA Clipbuds7 feature an ergonomic clip-on design for secure and comfortable wear.

1. **Clip the earbuds:** Gently clip the earbuds onto the thinnest part of your ear.
2. **Adjust for optimal sound:** Adjust the earbud tip to align with your ear canal for the best audio experience.


Ergonomic Clip-On Earbuds for All-Day Comfort

Designed with a lightweight open-loop structure, these clip-on earbuds gently attach to your ears

Wearing Tips



1. Clip the earbuds on the thinnest part of your ear



2. Adjust the earbud tip to align with your ear canal for optimal sound

Visual guide for correctly wearing the PAXA Clipbuds7 earbuds.

The detachable butterfly earrings can be easily attached or removed to suit your style. To attach, open the ear cuff, clip it onto the stem of the earbud, and then slip it onto your ear.



Instructions for attaching the butterfly earring accessory.

4. OPERATING INSTRUCTIONS

4.1 Touch Controls

The PAXA Clipbuds7 feature intuitive touch controls on each earbud for easy management of calls and music playback.

Function	Action
Answer/End Call	Double click either earbud
Reject Call	Press and hold either earbud for 2 seconds
Voice Assistant	Hold both earbuds for 2 seconds
Play/Pause	Double click either earbud
Previous Song	Triple-click the left (L) earbud
Next Song	Triple-click the right (R) earbud
Volume +	Click the right (R) earbud
Volume -	Click the left (L) earbud

What's in the Box

Clipbuds 7 Earbuds
Butterfly-Style Ear Clip
Charging Case
USB-C Charging Cable



Detailed overview of touch control functions for the PAXA Clipbuds7.

4.2 Audio Features

- **Immersive Sound:** Engineered for rich, balanced audio with crisp podcasts, smooth vocals, and appropriate bass. Crystal-clear audio with dynamic range for a theater-like experience.
- **Directional Sound Transmission:** Delivers precise audio directly to your ears while minimizing sound leakage, ensuring private listening without compromising quality.
- **Open-Ear Awareness:** Allows you to hear your music and surroundings simultaneously, providing full environmental awareness for safer activities like running, cycling, or commuting.
- **ClearCall ENC Technology:** Dual microphones with Environmental Noise Cancellation (ENC) filter out 90% of background noise, ensuring clear calls even in windy conditions.
- **Bluetooth 5.4:** Features instant-pairing technology with ultra-low latency, enhanced processing, and optimized battery efficiency for seamless wireless performance.



Experience immersive sound quality with crystal-clear audio.

Open-Ear Awareness

Hear your music and surroundings simultaneously - crystal-clear audio with full environmental awareness for safer runs, rides, and commutes

Directional sound technology ensures private listening while minimizing sound leakage.



Total 44-Hour Battery Life Long, Lasting Listening

8H

Single
Charge

36H

with Charging
Case

3H


Fast Charging
10 mins

Maintain environmental awareness for safety during outdoor activities.

ClearCall ENC Technology

Dual mics with noise reduction ensure crisp calls by filtering out wind and background noise, so you're always heard clearly

ClearCall ENC Technology ensures crisp calls by filtering out background noise.



Bluetooth 5.4

Featuring instant-pairing technology with ultra low latency, enhanced processing, and optimized battery efficiency for seamless wireless performance

Bluetooth 5.4 provides stable, low-latency wireless performance.

4.3 Official Product Videos

Your browser does not support the video tag.

This video demonstrates the PAXA Clipbuds7 Earbuds, highlighting their design and the removable butterfly earring feature. It shows the earbuds being taken out of the case, the butterfly attachment being removed, and the earbuds being used for calls and music. It also shows the earbuds being placed on an ear model and back into the charging case, demonstrating the LED battery display. The video concludes by comparing the silver and black versions of the earbuds.

Your browser does not support the video tag.

This video provides an unboxing and overview of the PAXA Clipbuds7 Open Ear Clip On Earbuds. It showcases the packaging for both the black and silver versions, the unboxing process, and a close-up of the earbuds and charging case. The video demonstrates how the earbuds fit onto an ear model, emphasizing their lightweight and comfortable design. It highlights the open-ear design for environmental awareness and the IP45 waterproof rating.

5. MAINTENANCE

5.1 Cleaning

To maintain optimal performance and hygiene, regularly clean your PAXA Clipbuds7 earbuds and charging case.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Ensure charging contacts on both the earbuds and the case are clean and free of debris.
- The earbuds are IP45 waterproof, meaning they are protected against splashes and sweat. However, do not submerge them in water.

Let Your Charisma Shine



The IP45 waterproof rating protects against rain and sweat, making them ideal for workouts and outdoor use.

5.2 Storage

When not in use, store the earbuds in their charging case to protect them and ensure they are charged for your next use. Store the case in a cool, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you encounter any issues with your PAXA Clipbuds7, please refer to the following common solutions:

- **Earbuds not pairing:**

- Ensure both earbuds are in the charging case and the lid is open to activate pairing mode.
- Turn off and on Bluetooth on your device.
- Forget "PAXA Clipbuds7" from your device's Bluetooth list and try pairing again.
- Ensure the earbuds and case have sufficient charge.

- **No sound or low volume:**

- Check the volume level on both your device and the earbuds (using touch controls).
- Ensure the earbuds are properly seated in your ears.
- Reconnect the earbuds to your device.
- Clean any debris from the earbud speakers.

- **Charging issues:**

- Ensure the USB-C cable is securely connected to both the case and the power source.
- Try a different USB-C cable or power adapter.
- Clean the charging contacts on the earbuds and inside the case.

- **Earbuds frequently disconnecting:**

- Ensure you are within the Bluetooth range (up to 50 feet).
- Minimize interference from other wireless devices.
- Ensure the earbuds are fully charged.

If the issue persists, please contact PAXA customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Model Name	Clipbuds715
Brand	PAXA
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Bluetooth Range	Up to 50 Feet
Ear Placement	Open Ear
Control Type	Touch Control
Water Resistance Level	IP45 (Waterproof)
Single Charge Playtime	Up to 8 hours
Total Playtime (with case)	Up to 44 hours
Carrying Case Battery Capacity	250 Milliamp Hours
Carrying Case Charging Time	0.5 Hours
Item Weight	2.89 ounces
Material	Plastic
Noise Control	Hybrid Noise Cancellation (ENC)
Included Components	Cable, User Manual

8. WARRANTY AND SUPPORT

PAXA products are designed for durability and performance. For information regarding product warranty, please refer to the documentation included with your purchase or visit the official PAXA website.

Optional protection plans are available for extended coverage, such as 2-Year and 3-Year Protection Plans, which can be purchased separately.

For technical support or customer service inquiries, please contact PAXA Direct through their official channels.

© 2025 PAXA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question