Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nitemode 21333

Nitemode LED Light Kit for Lego 21333 Starry Night

Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Nitemode LED Light Kit, specifically designed for the Lego 21333 Vincent Van Gogh Starry Night model. This product is an accessory to enhance your Lego model with lighting effects; **the Lego model itself is not included.**



Image: Clarification that only the LED lighting kit is included, not the Lego model.

What's in the Box

Please verify that all components listed below are present in your package:



Image: Visual representation of the kit contents, including instructions, light kits, tweezers, and a battery box.

- **Instructions for Use:** A guide to help you with the installation process.
- **LED Light Kits:** Various light components designed for specific sections of the Lego 21333 model.
- **Tweezers:** A tool to assist with precise placement of small light components and wires.
- **Battery Box:** Power source for the LED lights. Requires AAA batteries (not included).

Setup and Installation

The Nitemode LED Light Kit is designed for straightforward installation. Due to the intricate nature of integrating lighting with Lego models, detailed step-by-step instructions are provided online to ensure clarity and precision.

1. **Access Online Instructions:** Scan the QR code provided in your package or visit the official support website: http://support.nitemodetoy.com.
2. **Prepare Your Lego Model:** Ensure your Lego 21333 Starry Night model is fully assembled before beginning the light kit installation.

3. **Follow Step-by-Step Guide:** The online instructions will guide you through disassembling specific sections of your Lego model, routing wires, and attaching LED components. Use the included tweezers for delicate parts.
4. **Connect Power:** Insert AAA batteries (not included) into the battery box and connect it to the light kit system as per the online instructions.



Image: Steps for accessing electronic instructions, including scanning a QR code and visiting the support website.

Operating Instructions

Once installed, operating your Nitemode LED Light Kit is simple.

- **Power On/Off:** Use the switch on the battery box to turn the LED lights on or off.
- **Brightness Adjustment:** The light kit features adjustable brightness. Refer to the online instructions for specific details on how to control the light intensity, if applicable to your model.




Image: Demonstrates the visual difference between the light kit being turned on and off on the Lego model.

Image: Illustrates the adjustable brightness feature of the LED light kit.

Your browser does not support the video tag.

Video: A demonstration of the Nitemode LED light kit illuminating the Lego 21333 Starry Night model, showcasing the dynamic lighting effects.

Maintenance

To ensure the longevity and optimal performance of your Nitemode LED Light Kit, follow these maintenance guidelines:

- **Dusting:** Regularly dust your illuminated Lego model and light components with a soft, dry cloth or a soft brush to prevent dust buildup, which can affect light output.
- **Battery Replacement:** When lights dim or cease to function, replace the AAA batteries in the battery box. Ensure

correct polarity.

- **Wire Care:** Avoid tugging or sharply bending the wires. Ensure they are securely routed within the Lego model to prevent damage.
- **Storage:** If storing the model for an extended period, remove the batteries from the battery box to prevent leakage.

Troubleshooting

If you encounter issues with your Nitemode LED Light Kit, refer to the following common solutions:

Problem	Possible Cause	Solution
Lights do not turn on.	No batteries, dead batteries, incorrect battery polarity, loose connection, damaged wire.	Check if batteries are inserted and correctly oriented. Replace batteries if necessary. Ensure all connectors are firmly seated. Inspect wires for visible damage.
Lights are dim or flickering.	Low battery power, loose connection.	Replace batteries. Check all connections for secure fit.
Specific lights are not working.	Damaged LED, loose connection to that specific light.	Carefully check the connection for the non-working light. If the issue persists, contact support.

For further assistance, please visit our online support portal.

Specifications



Image: Detailed views of the light kit's components and their application within the Lego model.

- **Brand:** Nitemode
- **Model Compatibility:** Lego 21333 Vincent Van Gogh - The Starry Night
- **Light Source Type:** Light Emitting Diode (LED)
- **Power Source:** Battery Powered (AAA batteries, not included)
- **Material:** Plastic
- **Color:** Multicolor
- **Mounting Type:** Freestanding (within the Lego model structure)
- **Special Features:** Creative Lighting, Interactive with Model

Support

For additional support, detailed installation guides, or to report any issues, please visit our official support website:

Nitemode Support Website

Our online resources provide comprehensive assistance to ensure you have the best experience with your Nitemode LED Light Kit.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FCLTBB99

More documents and user manuals: **https://manuals.plus/**