

OMOTON TP02

OMOTON TP02 360° Rotating Magnetic Phone Tripod User Manual

Model: TP02 | Brand: OMOTON

INTRODUCTION

This manual provides detailed instructions for the OMOTON TP02 360° Rotating Magnetic Phone Tripod. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. Please read this manual thoroughly before using the product.

KEY FEATURES

- **Ultra Strong Magnet:** Features N52 large magnets for a secure hold, attaching your device in approximately 1 second. The sturdy clamp with anti-slip pads grips surfaces up to 1.57 inches thick.
- **Full Range Adjustment:** Offers 360° rotation and 3-axis adjustment up to 990° for versatile viewing angles in both landscape and portrait modes.
- **Portable and Lightweight:** Constructed from durable aluminum alloy, weighing 158g. Folds into a compact size with an innovative climbing buckle design for easy portability.
- **Multi-Functional & Expandable:** Easily switches between modes and extends up to 9 inches in tripod mode. Features a strong magnetic back for attachment to metal surfaces and 1/4" screw holes for additional accessories.
- **Wide Compatibility:** Compatible with iPhone 12-17 Pro Max series and Mag-Safe cases. Includes a magnetic metal ring for compatibility with all Android phones and non-magnetic cases.

PACKAGE CONTENTS

- OMOTON TP02 Magnetic Phone Tripod
- User Manual
- Magnetic Metal Ring (for non-MagSafe devices)

SETUP

1. Attaching Your Phone

The OMOTON TP02 features a powerful N52 magnet for secure attachment. Ensure your phone or phone case is MagSafe compatible. If not, use the included magnetic metal ring.

- **For MagSafe Compatible Devices:** Simply align your iPhone (12-17 Pro Max series) or MagSafe-compatible case with the magnetic ring on the tripod. The strong magnet will securely attach the phone.
- **For Non-MagSafe Devices:**
 1. Clean the back of your phone or non-MagSafe case thoroughly.
 2. Peel off the adhesive backing from the included magnetic metal ring.
 3. Carefully center and press the metal ring onto the back of your phone or case. Ensure it is firmly adhered.
 4. Once the ring is attached, you can then align your phone with the magnetic ring on the tripod for a secure connection.



Image: Demonstrates the strong magnetic attachment and compatibility with both MagSafe and non-MagSafe devices using the included metal ring.

2. Unfolding the Tripod

The OMOTON TP02 is designed for quick deployment.

- Gently pull the two main arms of the tripod outwards until they form a stable base.
- Extend the central support arm to your desired height.



Image: Shows the tripod in its fully extended and folded states, illustrating its versatility.

OPERATING MODES

1. Desktop Tripod Mode

For stable, hands-free viewing or recording on flat surfaces.

- Unfold the tripod legs and place the device on a flat surface.
- Adjust the height and angle of your phone using the 3-axis adjustment.
- Rotate your phone 360° to switch between landscape and portrait orientations as needed.

2. Handheld/Selfie Stick Mode

Ideal for vlogging, selfies, or capturing dynamic shots.

- Fold the tripod legs inward to form a comfortable grip.
- Extend the central arm to achieve desired reach for selfies or wider shots.

3. Clamp Mode

Attach the tripod to various surfaces for unique perspectives.

- Locate the sturdy clamp at the base of the tripod.
- Open the clamp and secure it onto a surface up to 1.57 inches thick. The anti-slip pads ensure stability.
- This mode is suitable for airplane tray tables, desk edges, or shelves.




Image: Close-up of the stabilized clamp mechanism, showing its ability to grip surfaces up to 1.57 inches.

4. Magnetic Mount Mode

Utilize the strong magnetic back to attach your phone to metal surfaces.

- Ensure the metal surface is clean and flat.
- Press the magnetic back of the tripod firmly against the metal surface.
- This is ideal for gym equipment, refrigerators, or metal doors.

Magnetic Back Sticks to Metal Surfaces



Gym



Fridge



Forklift



Golf Car

Image: Illustrates the magnetic back feature being used to attach the phone to different metal surfaces in various environments.

ADJUSTMENTS

- **360° Rotation:** The magnetic head allows for full 360-degree rotation, enabling seamless switching between landscape and portrait modes without re-positioning the tripod.
- **3-Axis Adjustment:** The multi-joint design provides up to 990° of 3-axis adjustment, allowing you to find the perfect viewing or shooting angle.
- **Height Extension:** In tripod mode, the central arm can extend up to 9 inches to meet various shooting needs.



Any Angle Adjustment



Pocket-Sized

Image: Details the extensive 360° rotation and multi-axis adjustment range, emphasizing the flexibility for various angles.

MAINTENANCE

- **Cleaning:** Wipe the tripod with a soft, dry cloth to remove dust and debris. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, fold the tripod into its compact form and store it in a dry place away from extreme temperatures.
- **Joints:** The metal joints are designed for durability. Avoid excessive force when adjusting to prevent damage.

TROUBLESHOOTING

- **Phone not securely attaching:**
 - Ensure your phone or case is MagSafe compatible.
 - If using a non-MagSafe device, verify the magnetic metal ring is correctly installed and centered.
 - Check for any obstructions or debris between the phone and the tripod's magnetic surface.
- **Tripod instability:**

- Ensure the tripod legs are fully extended and placed on a flat, stable surface.
- If using clamp mode, ensure the clamp is securely fastened to a surface within the 1.57-inch thickness limit.

- **Difficulty adjusting angles:**

- The joints are designed to be firm for stability. Apply gentle, consistent pressure when adjusting.

SPECIFICATIONS

Feature	Detail
Product Dimensions	5.2 x 3 x 2 inches
Item Weight	5.6 ounces
Model Number	TP02
Brand	OMOTON
Material	Aluminum Alloy
Magnetic Strength	N52 Magnets
Clamp Thickness	Up to 1.57 inches
Extension Length (Tripod Mode)	Up to 9 inches
Compatibility	iPhone 12-17 Pro Max Series, Mag-Safe Cases, All Android Phones (with metal ring)

WARRANTY AND SUPPORT

For any issues encountered during use, please contact OMOTON's after-sales support team. They are committed to providing satisfactory solutions.

Note: Specific warranty details may vary. Please refer to the product packaging or manufacturer's official website for the most current warranty information.