

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [Yuposl](#) /
- › Yuposl Automatic Cat Feeder User Manual

Yuposl YPF01-PW20

Yuposl Automatic Cat Feeder User Manual

Model: YPF01-PW20

Brand: Yuposl

1. INTRODUCTION

Thank you for choosing the Yuposl Automatic Cat Feeder. This device is designed to provide convenient and consistent feeding for your pets, ensuring they receive meals on a regular schedule. It features a 3L capacity, anti-jam design, and flexible meal programming, suitable for both cats and small dogs.

Package Contents:

- Yuposl Automatic Cat Feeder Main Unit
- Stainless Steel Food Bowl
- Power Adapter (Type-C)
- Desiccant Bag
- User Manual (this document)



Image: The Yuposl Automatic Cat Feeder, showing its main unit and the stainless steel bowl where food is dispensed.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions carefully before using the feeder.
- This appliance is for indoor use only. Do not expose to rain or moisture.
- Use only dry pet food. Do not use wet, canned, or moist food.
- Keep the feeder on a level surface to prevent tipping.
- Do not allow children or pets to play with or chew on the power cord.
- Always unplug the feeder before cleaning or performing maintenance.
- Do not immerse the main unit in water.
- If using batteries, ensure they are inserted with correct polarity. Do not mix old and new batteries or different types of batteries.
- Dispose of used batteries properly.

3. SETUP GUIDE

3.1 Unpacking and Assembly

1. Remove all components from the packaging.
2. Place the main feeder unit on a stable, flat surface.
3. Attach the stainless steel food bowl to the base of the feeder. Ensure it clicks securely into place.

3.2 Powering the Feeder

The feeder supports dual power supply: AC adapter or D-size batteries.

- **AC Power:** Connect the Type-C power adapter to the port on the back of the feeder and plug it into a wall outlet.
- **Battery Power:** Open the battery compartment on the bottom of the feeder. Insert 3 D-size alkaline batteries (not included), ensuring correct polarity. Close the compartment securely. Battery power provides over 180 days of operation.

Long Battery Life over 180-Day

Take care of your pet anytime, anywhere



Image: Illustration of the dual power options for the feeder, including the Type-C power adapter and the compartment for 3 D-size batteries.

3.3 Filling the Food Hopper

1. Open the top lid of the feeder.
2. Pour dry pet food into the hopper. The feeder has a 3L (12 cups) capacity.
3. Place the desiccant bag into the designated slot under the lid to help keep food fresh. Replace the desiccant bag every 1-2 months.
4. Close the lid securely. The spring-lock lid and silicone sealing rotor help prevent pets from accessing food and maintain freshness.

Keep Kibble Fresh and Crunchy

Ant, no way in, no way out



Image: The feeder's top lid open, revealing the food hopper and the desiccant bag slot, emphasizing its ability to keep kibble fresh and prevent ants.

4. OPERATING THE FEEDER

4.1 Control Panel Overview

The control panel features a digital display and several buttons for programming.



User-Friendly Control Panel

Easily schedule meals with clear and straightforward controls




Image: Close-up of the feeder's control panel, showing the digital display with time and portion settings.

4.2 Setting Time and Meals

The feeder allows you to program up to 6 meals per day, with 1 to 16 portions per meal.

1. **Set Current Time:** Press and hold the 'Set' button until the time display flashes. Use the '+' and '-' buttons to adjust the hour and minute. Press 'Set' again to confirm.
2. **Program Meal Times:** Press the 'Meal' button to enter meal programming mode. The meal number (e.g., '1') will flash. Use '+' and '-' to set the desired feeding time for that meal. Press 'Meal' to confirm the time and move to the next meal number or portion setting.
3. **Set Portions:** After setting the meal time, the portion number (e.g., 'P-01') will flash. Use '+' and '-' to adjust the number of portions (1-16) for that specific meal. Press 'Meal' to confirm and move to the next meal setting.
4. Repeat for all desired meals (up to 6). If you only need fewer meals, simply exit the programming mode after setting your last meal.

Feeding on Schedule Every Time

Prevent obesity with a balanced, healthy diet

05:00AM

09:00AM

04:00PM

09:00PM

Meal 1

Meal 2

Meal 3

Meal 4

2 Portion

1 Portion

2 Portion

1 Portion



1-6
Meals /day




1-16
Portions/meal

Image: A visual representation of scheduled feeding times (e.g., 05:00 AM, 09:00 AM, 04:00 PM, 09:00 PM) with corresponding portion sizes, demonstrating the feeder's timed dispensing capability.

4.3 Manual Feeding

To dispense food instantly, press the 'Manual Feed' button. This will dispense one portion of food. You can press it multiple times for additional portions.



Convenient Manual Feeding

Feed your pet with the press of a button, perfect for unscheduled treats

Image: A hand pressing the manual feed button on the feeder, illustrating the convenient option for unscheduled treats.

4.4 Kibble Size Compatibility

The anti-jam design accommodates dry food sizes ranging from 2mm to 15mm (0.07-0.6 inches), ensuring smooth dispensing even with larger kibble types.

Anti-clog Design

Suitable for dry food sizes 2-15mm



Dry food



Mixed food



Freeze dried food

Image: A diagram illustrating the feeder's anti-clog design and its compatibility with various dry food types and kibble sizes, from 2mm to 15mm.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your feeder.

5.1 Disassembly for Cleaning

1. Ensure the feeder is unplugged and/or batteries are removed.
2. Remove any remaining food from the hopper.
3. Detach the stainless steel food bowl from the base.
4. The food hopper and dispensing mechanism can be separated from the main unit for thorough cleaning. Refer to the diagrams for specific release points.

5.2 Cleaning Instructions

- **Stainless Steel Bowl:** The stainless steel bowl is dishwasher safe for easy cleaning. Alternatively, wash it with

warm soapy water and rinse thoroughly.

- **Food Hopper and Dispensing Mechanism:** Wash these components with warm soapy water. Rinse thoroughly to remove all soap residue. Ensure they are completely dry before reassembling.
- **Main Unit:** Wipe the exterior of the main unit with a soft, damp cloth. Do not immerse the main unit in water or allow water to enter the electronic components.
- **Desiccant Bag:** Replace the desiccant bag every 1-2 months to maintain optimal food freshness.

5.3 Reassembly

Once all components are clean and dry, reassemble the feeder in reverse order of disassembly. Ensure all parts are securely in place before adding food and powering on.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Feeder not dispensing food.	Food hopper is empty. Food jam. No power.	Refill food hopper. Clear any food blockages in the dispensing mechanism. Check power adapter connection or replace batteries.
Incorrect portion size dispensed.	Incorrect programming. Kibble size too large/small.	Re-program meal portions according to instructions. Ensure kibble size is within 2-15mm range.
Display is blank or not working.	No power. Batteries drained.	Check power adapter connection. If using batteries, replace them.
Lid not staying closed.	Lid not properly aligned or locked.	Ensure the lid is correctly aligned and the spring-lock mechanism is engaged.

7. SPECIFICATIONS



Model Number	YPF01-PW20
Capacity	3 Liters (approx. 12 cups)
Dimensions (L x W x H)	19.5 x 17.5 x 24 cm (7.68 x 6.89 x 9.45 inches)
Weight	1.45 kg (3.2 lbs)
Power Supply	AC Adapter (Type-C) / 3 x D-size Batteries (not included)
Recommended Kibble Size	2mm - 15mm (0.07 - 0.6 inches)
Meals Per Day	1-6 meals
Portions Per Meal	1-16 portions
Material	Food-grade ABS, 304 Stainless Steel

Color

White

Recommended Daily Feeding Portions

2L ≈ 8 cups, 1 portion ≈ 10.4ml ≈ 1/24 cup ≈ 2/3 tbsp ≈ 2 tsp

 Daily intake	1/8cup (2tbsp) (6tsp)	1/6cup (2.5tbsp) (8tsp)	1/4cup (4tbsp) (8tsp)	1/3cup (5tbsp) (8tsp)	1/2cup (8tbsp) (8tsp)	1cup (16tbsp) (8tsp)
 Recommended portions	3 portions	4 portions	6 portions	8 portions	12 portions	24 portions

Note: We recommend feeding your pet 3-6 times a day. Please set up their meals according to the table above.
For a more detailed Feeding Plan, refer to the User Manual.

Image: A table providing recommended daily feeding portions based on daily intake, suggesting 3-6 meals per day.

8. WARRANTY AND SUPPORT

Specific warranty information for the Yuposl Automatic Cat Feeder (Model YPF01-PW20) is not provided in this document. For detailed warranty terms, product support, or any inquiries, please contact the manufacturer directly.

Manufacturer: Yuposl

Please refer to the product packaging or the official Yuposl website for contact information and the most up-to-date support resources.