

manuals.plus /

› [Maxfree](#) /

› [Maxfree Dual Portable Monitor M4 User Manual](#)

Maxfree M4

Maxfree Dual Portable Monitor M4 User Manual

Model: M4

INTRODUCTION

Thank you for choosing the Maxfree Dual Portable Monitor M4. This manual provides essential information for setting up, operating, and maintaining your new dual monitor system. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

PRODUCT OVERVIEW

The Maxfree Dual Portable Monitor M4 is designed to expand your workspace with two 15.6-inch 1080P FHD IPS displays. Its folding design enhances portability, making it ideal for travel and various work environments.



Image: The Maxfree Dual Portable Monitor M4, featuring two 15.6-inch screens in an open, stacked configuration, ready for use.

Key Features:

- Dual 15.6-inch 1080P FHD IPS Displays
- Plug & Play USB-C Connectivity
- Folding Design for Portability
- Matte Screen with Anti-glare, No Flicker, and Eye Care Functions
- 100% sRGB Color Gamut
- Multiple Display Modes and 330° Rotation

15.6" DUAL PORTABLE MONITOR

Experience Portability, Enjoy Efficiency



Wide
compatibility



Multiple
Modes



300%
Efficiency



330°
Rotation



120%
sRGB



1000:1
contrast ratio

Image: The Maxfree Dual Portable Monitor M4 connected to a laptop, illustrating its plug-and-play functionality and various display modes.

SETUP INSTRUCTIONS

- Unpack the Monitor:** Carefully remove the monitor and all accessories from the packaging.
- Position the Monitor:** Place the monitor on a stable, flat surface. Adjust the integrated stand to your desired viewing angle.
- Connect to Power (Recommended):** For optimal performance, connect the monitor to a power source using the provided USB-C power adapter (if included) or a compatible USB-C port on your device that supports power delivery.
- Connect to Device:**
 - USB-C Connection:** Connect one end of the provided USB-C cable to the monitor's USB-C port and the other end to a full-featured USB-C port on your laptop or PC. This single cable can transmit video, audio, and power.
 - HDMI + USB-A Connection (if applicable):** If your device does not have a full-featured USB-C port, you may need to use an HDMI cable for video and a USB-A to USB-C cable for power and touch functionality (if

supported by your model). Refer to your device's manual for specific port requirements.

5. **Power On:** Press the power button on the monitor. Your device should automatically detect and extend the display.
6. **Adjust Display Settings:** On your computer, navigate to Display Settings to configure the dual monitors (e.g., extend, duplicate, arrange displays).

OPERATING INSTRUCTIONS

Display Modes:

The Maxfree Dual Portable Monitor supports various display modes to enhance productivity:

- **Extended Mode:** Expands your desktop across both screens, providing a larger workspace. This is ideal for multitasking.
- **Duplicate Mode:** Mirrors your primary display onto the portable monitors. Useful for presentations or sharing content.
- **Vertical Layout:** The unique vertical stacking design minimizes scrolling and page switching, reducing eye and neck fatigue, especially for document review or coding.

Triple Screen, **300%** Efficiency




Image: A user demonstrating the Maxfree Dual Portable Monitor M4 in a vertical stacked setup, illustrating how it creates an efficient triple-screen workspace.

On-Screen Display (OSD) Menu:

Use the buttons on the side of the monitor to access and navigate the OSD menu. This menu allows you to adjust settings such as:

- Brightness and Contrast
- Color Settings (e.g., sRGB, color temperature)
- Input Source Selection
- Aspect Ratio
- Volume (if applicable)

Refer to the on-screen prompts for specific button functions (e.g., Menu, Up, Down, Exit).

SPECIFICATIONS

Feature	Detail
Screen Size	Dual 15.6 Inches
Resolution	1920 x 1080 (FHD 1080p)
Panel Type	IPS
Aspect Ratio	16:9
Screen Surface	Matte
Image Brightness	300 Candela
Color Gamut	100% sRGB
Connectivity	USB-C (Full-featured), HDMI (if applicable)
Total USB Ports	1 (USB-C for main connection)
Voltage	5 Volts
Product Dimensions	0.5 x 14 x 9 inches
Item Weight	3.5 pounds
Model Number	M4

TROUBLESHOOTING

- **No Display:**
 - Ensure the USB-C cable is securely connected to both the monitor and your device.
 - Verify that your device's USB-C port supports video output (DisplayPort Alternate Mode).
 - Connect the monitor to an external power source if your device cannot provide sufficient power.
 - Check your computer's display settings to ensure the external monitor is detected and enabled.
- **Flickering Screen:**
 - Ensure the cable connections are secure.
 - Try a different USB-C cable.
 - Reduce the display resolution or refresh rate on your computer.
- **Image Quality Issues (Blurry, Incorrect Colors):**
 - Adjust the brightness, contrast, and color settings via the OSD menu.
 - Ensure your computer's display resolution matches the monitor's native resolution (1920x1080).
- **Monitor Not Powering On:**
 - Confirm the power cable is properly connected and the power outlet is functional.
 - Press the power button firmly.

MAINTENANCE

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a screen-cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Cleaning the Casing:** Use a soft, dry cloth to wipe the monitor's casing.
- **Storage:** When not in use, fold the monitor and store it in a cool, dry place, preferably in its original packaging or a protective case to prevent damage.
- **Avoid Extreme Conditions:** Do not expose the monitor to extreme temperatures, humidity, or direct sunlight.

WARRANTY AND SUPPORT





For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Maxfree website.


Manufacturer: Shenzhen Baijiayoupu Technology CO., Ltd.



© 2025 Maxfree. All rights reserved.


Related Documents - M4

	<p>Maxfree M2 User Guide: Dual Portable Monitor Setup and Operation</p> <p>Comprehensive user guide for the Maxfree M2 dual portable monitor, detailing setup, connection types (USB-C, HDMI), hub usage for Mac OS, troubleshooting tips, and key definitions for optimal use.</p>
	<p>MAXFREE F1 Portable Monitor User Guide & Installation Instructions</p> <p>Comprehensive user guide for the MAXFREE F1 portable laptop screen extender. This document details installation, connection options via Type-C, HDMI, and Type-A, and essential transportation, storage, and usage requirements for optimal performance and safety.</p>
	<p>MAXFREE T2 Portable Triple Screen User's Guide</p> <p>This user guide provides comprehensive instructions for setting up and using the MAXFREE T2 portable triple screen monitor. It covers installation, connection methods for various devices, display settings for Windows and macOS, OSD operations, and answers frequently asked questions.</p>
	<p>Maxfree K3 Foldable Touchscreen Mechanical Gaming Keyboard User Guide</p> <p>User guide for the Maxfree K3 foldable touchscreen mechanical gaming keyboard, detailing product contents, installation steps, connection methods for various devices, touch screen settings for Windows and Mac, and essential usage tips.</p>



[Maxfree F1 User's Guide: Portable Dual Screen Monitor](#)

Comprehensive user guide for the Maxfree F1 portable dual screen monitor, covering installation, connection, audio and display settings for Windows and macOS, OSD settings, and storage recommendations.



MAXFREE F2 Triple Screen Laptop Extender User's Guide

Comprehensive user's guide for the MAXFREE F2 triple screen laptop extender. Learn about installation, connection, audio/display settings for Windows and macOS, OSD operations, and storage.