

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DOGLinsen](#) /

› [DOGLinsen 2-in-1 Bark and Shock Collar \(Model PD 523-TIO-1\) Instruction Manual](#)

DOGLinsen PD 523-TIO-1

DOGLinsen 2-in-1 Bark and Shock Collar Instruction Manual

Model: PD 523-TIO-1

INTRODUCTION

Thank you for choosing the DOGLinsen 2-in-1 Bark and Shock Collar. This device is designed to assist in training your dog and managing excessive barking through various modes including beep, vibration, and static shock. Please read this manual thoroughly before use to ensure proper and safe operation.

WHAT'S INCLUDED

The package for your DOGLinsen 2-in-1 Bark and Shock Collar includes the following items:

- Remote Control (1)
- Receiver (1)
- Collar Strap (1)
- Lanyard (1)
- USB Charging Cable (1)
- User Manual (1)
- Box (1)
- Metal Contact Points (4)
- Black Rubber Sleeves (4)
- Test Lamp (1)

Package Included



Image: All components included in the DOGLinsen 2-in-1 Bark and Shock Collar package, laid out neatly.

Video: A detailed unboxing of the DOGLinsen 2-in-1 Bark and Shock Collar, showing each item included in the package.

SETUP

Pairing the Remote Control with the Receiver

Before using the collar, ensure the remote control and receiver are paired. If they are not already paired, follow these steps:

1. Hold down the power switch button on the receiver until the indicator light starts flashing.
2. Press the Vibration button on the remote control. The receiver will receive the signal.
3. Press the Tone button on the remote control. The receiver will receive the signal again.


Successful pairing is indicated when the receiver responds to both vibration and tone commands from the remote.

Video: A step-by-step guide on how to pair the remote control with the receiver unit of the DOGLinsen training collar.

Fitting the Collar

The collar strap is adjustable to fit dogs with neck sizes from 8 to 27 inches and weights from 10 to 110 lbs. Ensure the collar is snug but not too tight, allowing two fingers to fit comfortably between the strap and your dog's neck. The contact points should touch your dog's skin for effective operation.

Adjustable for All Size Dogs



Quick Release



Reflective



Image: The adjustable collar strap shown with various dog breeds and sizes, indicating its suitability for different weights and neck circumferences.

OPERATING MODES

The DOGLinsen 2-in-1 Bark and Shock Collar offers three main collar modes and four effective training functions:

Collar Modes:

- **Bark Control Mode:** The collar automatically detects and responds to dog barking.

- **Dog Training Mode:** Use the remote control to manually apply training functions.
- **All Modes:** Combines both bark control and remote training functionalities.



Image: A dog wearing the collar, with an overlay illustrating the three available collar modes: Bark Control, Dog Training, and All Mode.

Training Functions:

- **Beep:** An audible tone.
- **Vibration:** Adjustable from 1-100 levels.
- **Safety Shock:** Adjustable from 1-100 levels.

- **Automatic Mode:** Features 5 levels of adjustable sensitivity for bark detection.

4 Effective Training Modes



Image: The remote control displaying the four effective training modes: Beep, Vibration (1-100 levels), Safe Shock (1-100 levels), and Auto mode with adjustable sensitivity (1-5 levels).

Automatic Bark Collar & Protection Mode

In automatic bark control mode, the collar detects dog barking and activates corrective stimuli. To protect your dog from over-correction, if the bark collar is triggered 7 times in a row, it will temporarily stop working for 30 seconds.

Automatically Detects Dog Barking

No Remote Control needed



Beep



Vibration



Shock

7 Activation Sequences



2: + Level 10

3: + Level 40

4: + Level 80

5: + Level 80 + Level 10

6: + Level 80 + Level 40

7: + Level 80 + Level 80

Image: A dog wearing the collar, illustrating how it automatically detects barking and the sequence of corrective actions (Beep, Vibration, Shock) with increasing intensity.

Turning Auto Mode On or Off

To activate or deactivate the Auto Mode on the receiver:

1. Press and hold the power button on the remote for about 3 seconds.
2. When you hear a single 'beep' sound from the receiver, Auto Mode is turned on.
3. To turn it off, press and hold the power button again for 3 seconds. You will hear two 'beeps' from the receiver, indicating Auto Mode is off.

Video: Instructions on how to turn the Auto Mode on and off for the DOGLinsen receiver.

ADJUSTING SENSITIVITY

The automatic mode has 5 levels of adjustable sensitivity. The higher the sensitivity level, the easier the device can be triggered by barking. You can choose the appropriate sensitivity for your dog's barking habits.

To Adjust Sensitivity:

1. Ensure the receiver is powered on.
2. Press the power button on the receiver 3 times in a row.
3. Each press will cycle through the sensitivity levels, indicated by a number of beeps:
 - 1 Beep: Level 1 (Lowest Sensitivity)
 - 2 Beeps: Level 2
 - 3 Beeps: Level 3
 - 4 Beeps: Level 4
 - 5 Beeps: Level 5 (Highest Sensitivity)

Video: Demonstrates how to adjust the sensitivity levels of the automatic bark control mode on the DOGLinsen receiver.

BATTERY LIFE & CHARGING

The DOGLinsen collar features a long-lasting battery. When fully charged, the receiver can operate for up to 90 days, and the remote control for up to 30 days. The device uses a USB Type-C charging cable for convenient charging from various sources like laptops, PCs, power banks, or phone chargers.

Long Battery Life



Image: Visual representation of the long battery life for both the remote (30 days) and receiver (90 days), along with various USB-C charging options.

Checking Receiver Battery Level

To check the battery level of the receiver:

1. Press the power button on the receiver twice in a row.
2. You will hear a series of beeps indicating the battery charge level:
 - 1 Beep: Below 20%
 - 2 Beeps: Above 20%

- 3 Beeps: Above 40%
- 4 Beeps: Above 60%
- 5 Beeps: Above 80%

Video: A demonstration of how to test the power level of the DOGLinsen receiver by pressing the power button twice and interpreting the beep signals.

WATERPROOFING

The receiver unit of the DOGLinsen collar is IP67 waterproof, making it suitable for use in various weather conditions and environments, including rain, seaside, and even swimming. Please ensure the remote control is kept away from water as it is not waterproof.

100% IP67 Waterproof

Waterproof



Dust-proof



IP67



Seaside



Rainy



Swimming

Image: The collar receiver submerged in water and covered in sand, demonstrating its IP67 waterproof and dust-proof capabilities for use in various outdoor settings.

SPECIFICATIONS

Feature	Detail
Item Weight	8.4 ounces

Feature	Detail
Model Number	PD 523-TIO-1
Batteries	1 Lithium Polymer battery (included)
Item Package Dimensions	5.98 x 3.9 x 2.24 inches
Brand Name	DOGLinsen
Target Audience	Dog, Dogs
Color	Pink
Size	Adjustable (Neck sizes 8-27 inches, Weights 10-110 lbs)
Material	Nylon, Polyester
Age Range	All Life Stages
Care Instructions	Hand Wash
Number of Items	10 (as per included components)
Specific Uses	Dog behavior correction (chasing cars, running away, jumping, barking), follow commands, Indoor, outdoor
Waterproof Rating	IP67 (Receiver)
Remote Range	Up to 2800Ft

MAINTENANCE

- Regularly check the collar for wear and tear.
- Clean the collar strap with a damp cloth and mild soap. Hand wash only.
- Ensure the contact points are clean and free of debris for optimal performance.
- Charge the device regularly to maintain battery health.

TROUBLESHOOTING

- **Collar not responding:** Ensure both the remote and receiver are charged and powered on. Re-pair the devices if necessary.
- **Ineffective correction:** Check that the contact points are making proper contact with your dog's skin. Adjust collar tightness or use longer contact points if your dog has thick fur.
- **Accidental triggers in Auto Mode:** Adjust the sensitivity level to a lower setting.
- **Short battery life:** Ensure the device is fully charged. Battery life can vary based on usage frequency.

WARRANTY AND SUPPORT

The DOGLinsen 2-in-1 Bark and Shock Collar comes with a **2-Year Manufacturer Warranty**. For any

questions, concerns, or support needs regarding your product, please contact DOGLinsen customer service. Refer to the contact information provided in your product packaging or visit the official DOGLinsen store online.

DOGLinsen Store: [Visit the DOGLinsen Store on Amazon](#)