

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Canslab](#) /

> [Canslab IRON Rechargeable Electric Can Opener User Manual](#)

## Canslab IRON

# Canslab IRON Rechargeable Electric Can Opener User Manual

Model: IRON

## 1. IMPORTANT SAFEGUARDS

Please read all instructions carefully before using the Canslab IRON Electric Can Opener. Retain this manual for future reference.

- This appliance is intended for household use only.
- Keep fingers away from the blade area during operation to avoid injury.
- Do not immerse the can opener in water or other liquids. Clean with a damp cloth only.
- Ensure the device is fully charged before initial use.
- Do not attempt to open rimless soda cans or cans with unusual shapes.
- Keep out of reach of children.
- Do not expose the product to extreme temperatures.

## 2. WHAT'S IN THE BOX

- Canslab IRON Rechargeable Can Opener
- Wall-mount bracket
- USB-C charging cord (wall-plug not included)
- User Manual

## 3. PRODUCT OVERVIEW

The Canslab IRON Electric Can Opener features a sleek design with intuitive controls and a robust stainless steel blade for efficient can opening.



Image: Canslab IRON Electric Can Opener, showing the main unit, USB-C charging cable, and the magnetic wall-mount bracket.

### Key Components:

- **Power Button:** One-touch activation and auto-stop control.
- **LED Digital Monitor:** Displays real-time battery level.
- **Professional-Grade Blade:** Stainless steel side-cutting mechanism.
- **Undermount Magnet:** Securely holds the lid after cutting.
- **Integrated Slide-Out Lid Removal Tool:** For stubborn vacuum-sealed lids.
- **USB-C Charging Port:** For convenient recharging.

#### 4. CHARGING INSTRUCTIONS

The Canslab IRON is equipped with a rechargeable battery, offering cordless operation.

1. Locate the USB-C charging port on the device.
2. Connect the provided USB-C charging cord to the can opener and to a compatible USB power source (e.g., wall adapter, computer, power bank).
3. The LED digital monitor will indicate the charging status. A full charge typically takes 1.5 hours and provides enough power to open over 200 standard cans.
4. Once fully charged, disconnect the charging cord.



Image: The Canslab IRON Electric Can Opener being charged via its USB-C port, with the LED display showing battery

## **5. OPERATING INSTRUCTIONS**

The Canslab IRON is designed for effortless, hands-free can opening.

### **5.1 Opening a Can**

1. Place the can opener on top of the can, ensuring the cutting blade is aligned with the can's rim.
2. Press the power button once to activate. The can opener will automatically grip the can and begin cutting along the side.
3. The device will automatically stop once the cutting cycle is complete.
4. To remove the lid, simply lift the can opener straight up. The undermount magnet will hold the lid securely.

# Small in Hands, **Strong** on Cans

From Sealed to Served in **16** Seconds



Image: The Canslab IRON Electric Can Opener positioned on top of a can, ready to begin the opening process.

## 5.2 Using the Lid Removal Tool

For lids that are difficult to remove, utilize the integrated slide-out lid removal tool.

1. After the can is opened, slide out the small tool located on the side of the can opener.
2. Gently hook the tool under the edge of the lid and lift to detach.

## Smooth Edge & Easy Lid Removal



Image: A hand demonstrating the use of the retractable lid removal tool on the Canslab IRON Electric Can Opener to lift a can lid.

### 5.3 Wall Mount Storage

The included magnetic wall-mount bracket allows for convenient and space-saving storage.

1. Attach the wall-mount bracket to a clean, flat surface in your kitchen.
2. The can opener can then be magnetically attached to the bracket for easy access and clutter-free countertops.



Image: The Canslab IRON Electric Can Opener is shown neatly stored on its magnetic wall mount in a kitchen setting.

## 6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Canslab IRON Electric Can Opener.

- **Cleaning:** Wipe the exterior of the can opener with a damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Blade Care:** The stainless steel blade is designed for durability. If food particles accumulate, carefully clean the area around the blade with a small brush, ensuring the device is off.

- **Storage:** Store the can opener in a dry place, ideally on its wall mount, when not in use.

## 7. TROUBLESHOOTING

If you encounter any issues with your Canslab IRON Electric Can Opener, please refer to the following common solutions:

Problem	Possible Cause	Solution
Can opener does not start.	Low battery or improper placement.	Charge the device fully. Ensure the can opener is correctly positioned on the can's rim.
Lid is not fully removed.	Can opener stopped prematurely or lid is vacuum-sealed.	Ensure the can opener completes its full cycle. Use the integrated lid removal tool for stubborn lids.
Can opener gets stuck.	Can is dented or has an irregular rim.	Remove the can opener and try on a different can. The device is not suitable for severely dented or rimless cans.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Canslab
Model Number	IRON
Color	Stainless Steel
Material	Acrylonitrile Butadiene Styrene, Stainless Steel
Operation Mode	Automatic
Wattage	20 watts
Item Weight	0.38 Kilograms (13.4 ounces)
Battery	1 Lithium Ion battery (included)
Charging Time	Approx. 1.5 hours for 200+ cans

## 9. OFFICIAL PRODUCT VIDEOS

Watch these official videos for a visual guide on using your Canslab IRON Electric Can Opener.

### **Canslab Iron Electric Can Opener Overview**

Your browser does not support the video tag.

Video: A comprehensive overview of the Canslab IRON Electric Can Opener, demonstrating its features and ease of use.

### **LED Display | Rechargeable Can Opener | Auto Shut Off**

Your browser does not support the video tag.

Video: Demonstrates the LED battery display, rechargeable feature, and automatic shut-off function of the Canslab Electric Can Opener.

### **Easy Kitchen Upgrade: USB-C Rechargeable Can Opener with Safety Edge**

Your browser does not support the video tag.

Video: Highlights the convenience of USB-C charging and the safety edge cutting feature of the Canslab Electric Can Opener.

## **10. WARRANTY & SUPPORT**

Canslab offers a 12-month limited warranty for any defective or malfunctioning parts. This warranty does not apply to routine maintenance, consumables, damage, or malfunction due to negligence, abuse, or use not in accordance with the user's guide.

For customer service, warranty claims, or any questions regarding your Canslab IRON Electric Can Opener, please contact Canslab US directly.

**Canslab US:** [Visit the Canslab Store on Amazon](#)