

Niiyen 304 Stainless Steel Adult Bento Lunch Box (B0FCMC1VJG)

Niiyen 304 Stainless Steel Adult Bento Lunch Box Instruction Manual

Model: B0FCMC1VJG

PRODUCT OVERVIEW

The Niiyen 304 Stainless Steel Adult Bento Lunch Box is designed for convenient and healthy meal transport. Constructed from durable 304 stainless steel and food-grade PP plastic, it offers a safe and hygienic solution for storing both hot and cold foods. This portable lunch box features multiple compartments, integrated utensils, and a secure latch system, making it ideal for various daily activities.

KEY FEATURES

- **Premium Materials:** Made from 304 stainless steel for the inner layer, ensuring durability, rust resistance, and easy cleaning. The outer layer is constructed from high-temperature resistant, food-grade PP plastic.
- **Multi-Compartment Design:** Features a removable 4-grid stainless steel tray (available in 900ml and 1500ml capacities) for separating different food items, preventing odor mixing.
- **Integrated Utensils:** Includes food-grade spoons and chopsticks conveniently stored in the lid, eliminating the need to carry separate cutlery.
- **Leak-Proof Soup Bowl:** Equipped with a 300ml leak-proof soup bowl for transporting liquids without spills.
- **Secure Closure:** Designed with a fashionable short buckle and safety latches on both sides to ensure the lid remains securely fastened during transport.
- **Portable Handle:** Features a portable concealed double curved handle for easy carrying.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, wash all parts of the lunch box, including the stainless steel tray, lid, and utensils, with warm soapy water. Rinse thoroughly and dry completely.
3. **Inspect Components:** Ensure all parts, including the silicone sealing ring and latches, are properly seated and free from damage.

OPERATING INSTRUCTIONS

1. Filling the Lunch Box:

- Open the side latches and lift the lid.
- Place food items into the 4-grid stainless steel tray. Use the separate compartments to keep different foods from mixing.
- For liquids, use the included 300ml leak-proof soup bowl. Ensure its lid is securely closed before placing it in the main compartment.

2. Securing the Lid:

- Align the lid with the base of the lunch box.
- Press down firmly on the lid to engage the silicone sealing ring.
- Close the side latches until they click into place, ensuring a secure seal.

3. Using the Utensils:

- The lid features a dedicated slot for the included spoon and chopsticks.
- To access, slide open the cover on the lid and remove the utensils.

4. Microwave Usage (Outer Shell Only):

- The **stainless steel inner tray is NOT microwave safe**. Always remove the stainless steel tray before microwaving.
- Only the outer PP plastic shell can be used in the microwave.
- When microwaving, open the exhaust valve on the lid and ensure the side buckles are open to prevent pressure buildup.
- Heat over medium-low heat for no more than 3 minutes.

MAINTENANCE AND CARE

- **Cleaning:** Hand wash all components with warm soapy water. Do not immerse the entire lunch box in warm water for extended periods.
- **Dishwasher Safety:** This product is **NOT dishwasher safe**. Hand wash only to preserve its integrity and sealing properties.
- **Drying:** Ensure all parts are completely dry before reassembling and storing to prevent odors or mildew.
- **Storage:** Store the lunch box in a clean, dry place when not in use.

TROUBLESHOOTING

- **Difficulty Opening/Closing:** Ensure the silicone sealing ring is properly seated and clean. If food is hot, open the exhaust valve to release pressure before opening.
- **Leakage:** Verify that the lid is correctly aligned and all side latches are securely closed. Check the silicone sealing ring for any damage or misalignment. The internal compartments are not individually leak-proof; use the dedicated soup bowl for liquids.
- **Food Not Staying Warm/Cold:** Ensure the lid is tightly sealed. For optimal temperature retention, pre-warm or pre-chill the stainless steel tray before adding food.

SPECIFICATIONS

Brand	Niiyen
Model	B0FCMC1VJG
Material	Polypropylene, 304 Stainless Steel
Color	Pink (other colors may be available)
Capacity	1500 Milliliters (also available in 900ml style)
Number of Compartments	4 (removable tray)
Included Components	Utensil (spoon & chopsticks), 300ml Soup Bowl
Special Feature	Leak Resistant (outer seal)
Closure Type	Latch
Recommended Age Range	Little Kid (Recommended for children over 3 years old)

PRODUCT VISUALS



Dimensions of the 1500ml Niiyen Lunch Box, showing its length, width, and height.

Note: 1500 ml food containers are similar in size to A4 paper.



Size comparison of the 1500ml lunch box with an A4 notebook, illustrating its portable size.

Lunch Box

4-grid lunch box, sorted and placed, not afraid of odor, integrated molding, easy and convenient to clean.



The 4-grid stainless steel tray filled with a balanced meal, including a separate soup bowl.



Upgrade buckle



Vent hole



304 stainless steel liner



Silicone sealing ring

Detailed view of the lunch box's secure buckles, vent hole, 304 stainless steel liner, and silicone sealing ring for leak resistance.

Note: Heat over medium-low heat for no more than 3 minutes
Open the lunch box exhaust valve, 4 sides of the buckle open



Demonstration of microwaving the outer plastic shell (stainless steel tray removed), highlighting the exhaust valve and open buckles.

Instructional Videos

Video demonstrating the assembly and use of a single-layer food lunch box, showcasing its features and ease of use.

Video illustrating the stackable design of the lunch boxes, showing how different food items can be organized.

Video showcasing the stainless steel insulated food storage box, including a leak-proof test and feature overview.

Video demonstrating the leak-proof capabilities and two-compartment design of a stainless steel bento lunch box.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the packaging or contact the manufacturer directly through their official website or customer service channels. Keep your purchase receipt for any warranty claims.