

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Frigidaire](#) /

› [Frigidaire Professional 30-inch Induction Cooktop PCCI3080AF User Manual](#)

Frigidaire PCCI3080AF

Frigidaire Professional 30-inch Induction Cooktop

Model: PCCI3080AF - User Manual

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Frigidaire Professional 30-inch Induction Cooktop, model PCCI3080AF. Please read all instructions carefully before installation and operation. Keep this manual for future reference.



Image: Top-down view of the Frigidaire Professional 30-inch Induction Cooktop, showcasing its sleek black glass surface and four silver control knobs.

IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using this appliance to reduce the risk of fire, electric shock, or injury to persons. This cooktop is designed for household use only.

- Read all instructions before using the appliance.
- Ensure proper installation by a qualified technician in accordance with all local codes and ordinances.
- Do not leave children unattended near the cooktop.
- Use only dry pot holders. Moist or damp pot holders on hot surfaces may result in burns from steam.
- Never use your appliance for warming or heating the room.
- Do not store flammable materials in or near the cooktop.
- Use only induction-compatible cookware.

SETUP AND INSTALLATION

The Frigidaire Professional PCCI3080AF is a built-in induction cooktop. Proper installation is crucial for performance and safety.

Unpacking

Carefully remove all packaging materials and protective films from the cooktop. Inspect the appliance for any shipping damage. Report any damage immediately to your dealer.

Dimensions and Cutout Requirements

Ensure your countertop cutout meets the specified dimensions for this 30-inch model.

- **Product Dimensions:** 21.38" Depth x 30" Width x 2.88" Height
- **Minimum Cutout Width:** 28 1/2"
- **Minimum Cutout Depth:** 19 5/8"
- **Maximum Cutout Width:** 29 7/8"
- **Maximum Cutout Depth:** 20 1/2"




Image: A diagram illustrating the precise height, width, and depth measurements of the cooktop, including the 30-inch width and 20 5/8-inch depth.

Electrical Requirements

The cooktop requires a 240 Volts electrical supply with a wattage of 12400 watts. Consult a qualified electrician for proper wiring and connection.

Frigidaire Fit Promise

Frigidaire guarantees that your new 30-inch Frigidaire Professional induction cooktop will fit your existing countertop cutout of the same width and configuration. If it does not, Frigidaire will reimburse you for cabinet modification costs up to \$100. Refer to the official Frigidaire website or warranty documentation for full terms and conditions.

What's in the Box

The product package includes the Frigidaire Professional 30-inch Induction Cooktop.

OPERATING INSTRUCTIONS

Your Frigidaire Professional Induction Cooktop offers advanced features for precise and efficient cooking.

Induction Technology Overview

Induction cooking uses electromagnetic fields to directly heat the cookware, not the cooktop surface. This results in faster heating, precise temperature control, and a cooler cooktop surface around the cooking zones.

How induction works

Electric currents directly heat your pots and pans




Image: A diagram illustrating the principle of induction cooking, showing electric currents creating an electromagnetic field that directly heats a magnetic pot, while the surrounding cooktop remains cool.

Cookware Compatibility

Only induction-compatible cookware will work on this cooktop. To check compatibility, use a magnet: if it sticks firmly to the bottom of your pot or pan, it is induction-ready.

- Stainless steel
- Cast iron
- Porcelain enamel on metal
- Cookware containing magnetic iron or steel
- Cookware with an induction symbol on the bottom (often a coil icon)

What types of cookware are induction compatible?

- Stainless steel
- Cast iron
- Porcelain enamel on metal
- Cookware containing magnetic iron or steel
- Cookware with an induction symbol on the bottom 

Image: A graphic listing various types of cookware compatible with induction cooktops, including stainless steel, cast iron, and those with an induction symbol.

Controls and Features

- **PrecisionPro Controls:** Use the backlit LED knobs to precisely adjust heat levels for simmering, sautéing, searing, or boiling. The knobs illuminate when an element is in use.
- **5,200-Watt PowerPlus Burner:** The 11-inch PowerPlus Burner, located in the lower right-hand corner, offers high power for rapid boiling, up to 50% faster than gas.
- **Power Boost:** Activate Power Boost on any burner to temporarily increase power for even faster heating.
- **2-in-1 Bridge Element:** Connects two cooking elements to create a larger cooking zone, ideal for griddle pans or oversized cookware.
- **Auto Pan Detection:** The cooktop automatically detects the presence and size of induction-compatible cookware.



Image: A close-up view of the four silver control knobs on the Frigidaire Professional cooktop, showing their ergonomic design and clear markings for heat settings.

Cooking Tips

- Start with lower heat settings and gradually increase as needed. Induction heats very quickly.
- For best results, use cookware with flat, smooth bottoms that fully cover the cooking zone.
- The cooktop surface around the pan remains cooler, allowing for easier cleanup of spills during cooking.

CARE AND MAINTENANCE

Regular cleaning and proper care will ensure the longevity and optimal performance of your induction cooktop.

Cleaning the Cooktop Surface

The smooth glass surface is easy to clean. For best results:

- Allow the cooktop to cool completely before cleaning.
- For light soil, wipe with a damp cloth and mild dish soap. Rinse and dry thoroughly.

- For stubborn stains or burned-on food, use a ceramic cooktop cleaner and a non-abrasive pad. Follow the cleaner manufacturer's instructions.
- Avoid using abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage the glass surface.

Smudge-Proof Stainless Steel

The stainless steel accents are designed to resist fingerprints and are easy to clean with a soft cloth and mild cleaner.

TROUBLESHOOTING GUIDE

Before contacting customer service, refer to this section for common issues and solutions.

Problem	Possible Cause	Solution
Cooktop does not turn on.	No power supply; control lock engaged.	Check circuit breaker. Ensure cooktop is properly connected. Deactivate control lock if present.
Burner not heating.	Non-induction compatible cookware; pan not centered; pan too small.	Use induction-compatible cookware. Center the pan on the cooking zone. Ensure pan covers at least 80% of the cooking zone.
Unusual noises during operation.	Normal induction sounds (humming, buzzing); fan operation.	Light humming or buzzing is normal with induction technology, especially at high power settings or with certain cookware. The cooling fan may also produce a sound.
Cooktop displays an error code.	Internal malfunction; sensor issue.	Refer to the full user manual for specific error code meanings. If the issue persists, contact customer support.

For issues not covered here, or if troubleshooting steps do not resolve the problem, please contact Frigidaire Customer Service.

SPECIFICATIONS

Feature	Detail
Brand	Frigidaire
Model Number	PCCI3080AF
Installation Type	Built-In
Product Dimensions (D x W x H)	21.38" x 30" x 2.88"

Feature	Detail
Item Weight	50 pounds
Voltage	240 Volts
Wattage	12400 watts
Fuel Type	Induction
Number of Heating Elements	4
Burner Type	Smooth Glass
Special Features	Auto Pan Detection, Power Boost, 2-in-1 Bridge Element
Color	Professional (Black with Stainless Steel Accents)
Material Type	Glass
Certification	ADA Compliant

PRODUCT VIDEOS

Watch these official videos for additional information and demonstrations of your Frigidaire Professional Induction Cooktop.

Frigidaire Induction Cooktop Overview

Your browser does not support the video tag.

Video: A general overview of the Frigidaire Induction Cooktop, highlighting its key features and benefits. (Duration: 0:55)

Detailed Features and Operation

Your browser does not support the video tag.

Video: A more in-depth look at the cooktop's functionalities, including demonstrations of its controls and cooking performance. (Duration: 2:56)

WARRANTY INFORMATION

Your Frigidaire Professional Induction Cooktop is covered by a manufacturer's warranty. For specific details regarding coverage duration, terms, and conditions, please refer to the warranty card included with your appliance or visit the official Frigidaire website. Keep your proof of purchase for warranty claims. As mentioned in the setup section, the [Frigidaire Fit Promise](#) ensures reimbursement for cabinet modification costs up to \$100 if the cooktop does not fit an existing cutout of the same width and configuration.

CUSTOMER SUPPORT

If you require assistance with installation, operation, maintenance, or troubleshooting that is not covered in this manual, please contact Frigidaire Customer Service.

- Visit the official Frigidaire website for support resources, FAQs, and contact information.
- Have your model number (PCCI3080AF) and serial number ready when contacting support.

© 2025 Frigidaire. All rights reserved.