

Philips SPT6338

Philips SPT6338 Wireless Turkish Q Keyboard and Mouse Set

Model: SPT6338

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Philips SPT6338 Wireless Turkish Q Keyboard and Mouse Set. This set offers a silent and comfortable typing experience with membrane key technology and a precise 1600 DPI optical mouse, designed for seamless plug-and-play functionality across various devices.



Image: Top view of the Philips SPT6338 Wireless Turkish Q Keyboard and Mouse Set, showcasing the full keyboard layout and the ergonomic mouse.

PACKAGE CONTENTS

- Philips SPT6338 Wireless Turkish Q Keyboard
- Philips Wireless Mouse
- USB Receiver
- AAA Batteries (for keyboard)
- AA Battery (for mouse)
- User Manual (this document)

SETUP

1. Installing Batteries

For the Keyboard:

1. Locate the battery compartment on the underside of the keyboard.
2. Open the battery cover.
3. Insert two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery cover securely.

For the Mouse:

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery cover.
3. Insert one AA battery, ensuring correct polarity (+/-).
4. Close the battery cover securely.



Image: Underside view of the Philips wireless keyboard and mouse, highlighting the battery compartments and the USB receiver storage slot on the mouse.

2. Connecting the USB Receiver

1. Locate the USB receiver, typically stored in the mouse's battery compartment or a dedicated slot.
2. Plug the USB receiver into an available USB port on your computer (desktop, laptop, tablet, or smart TV).
3. The system will automatically detect and install the necessary drivers. No additional software installation is required.

The keyboard and mouse are now ready for use.

OPERATING INSTRUCTIONS

Keyboard Usage

- **Typing:** The keyboard features a Turkish Q layout for standard text input.
- **Function Keys (F1-F12):** These keys provide multimedia and system control functions. They may require pressing the **Fn** key simultaneously for secondary functions, depending on your operating system settings.
- **Caps Lock Indicator:** A small LED light indicates when Caps Lock is active.



Image: Angled view of the Philips wireless keyboard and mouse, showcasing the compact design and key layout.

Mouse Usage

- **Left Click:** Primary selection and activation.
- **Right Click:** Accesses contextual menus.
- **Scroll Wheel:** Scrolls through documents and web pages. Can also function as a middle click.
- **DPI:** The mouse operates at 1600 DPI for precise tracking.
- **Silent Clicks:** Designed for quiet operation.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth can be used, ensuring no liquid enters the devices.
- **Battery Replacement:** Replace batteries when performance degrades (e.g., delayed response, erratic cursor movement). Refer to the "Installing Batteries" section for instructions.
- **Storage:** When not in use for extended periods, remove batteries to prevent leakage. Store the USB receiver in its designated slot within the mouse.
- **Environmental Conditions:** Avoid exposing the devices to extreme temperatures, direct sunlight, or high humidity.

TROUBLESHOOTING

- **No Response from Keyboard/Mouse:**
 - *Check Batteries:* Ensure batteries are correctly installed and not depleted. Replace if necessary.
 - *Check USB Receiver:* Ensure the USB receiver is securely plugged into a working USB port. Try a different USB port.
 - *Proximity:* Ensure the keyboard and mouse are within the operating range of the USB receiver (typically up to 10 meters).
 - *Interference:* Move away from other wireless devices that might cause interference.
- **Erratic Cursor Movement or Typing:**
 - *Clean Sensor:* Ensure the mouse's optical sensor is clean and free from obstructions.

- *Surface*: Use the mouse on a suitable, non-reflective surface.
- *Battery Level*: Low battery can cause erratic behavior. Replace batteries.
- **Keyboard Layout Incorrect:**
 - *Operating System Settings*: Verify that your computer's operating system is set to the correct keyboard layout (e.g., Turkish Q).

SPECIFICATIONS

Feature	Description
Model	SPT6338
Brand	Philips
Connectivity	Wireless (USB Receiver)
Keyboard Layout	Turkish Q, Compact
Keyboard Key Technology	Membrane, Silent
Keyboard Key Lifetime	10 million presses
Mouse DPI	1600 DPI
Mouse Buttons	Silent click buttons
Power Source	Battery Powered (Keyboard: 2x AAA, Mouse: 1x AA)
Compatibility	Laptop, Personal Computer, Tablet, Smartphone (with USB-A port)
Dimensions (Keyboard)	389.69 mm width (approx.)
Color	Grey

WARRANTY AND SUPPORT

This Philips product comes with a Philips Turkey Warranty. For warranty claims, technical support, or service inquiries, please refer to the warranty card included in your package or visit the official Philips support website.

For further assistance, you may contact Philips customer service through their official channels. Keep your proof of purchase for warranty validation.

Official Philips Store: [Philips Store on Amazon.com.tr](#)

SAFETY INFORMATION

- Do not attempt to disassemble or modify the product.
- Keep the product away from water and other liquids.
- Dispose of batteries according to local regulations.
- Avoid dropping or subjecting the product to strong impacts.