Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aramox Aramoxgyrudx5fhz-11

Aramox Water Powered LED Digital Alarm Clock User Manual

Model: Aramoxgyrudx5fhz-11

1. Introduction

Thank you for choosing the Aramox Water Powered LED Digital Alarm Clock. This innovative clock operates without traditional batteries, utilizing water as its power source. It is designed to provide reliable timekeeping with an eco-conscious approach. This manual provides essential information for the proper setup, operation, and maintenance of your device.

2. Important Safety Information

- Do not immerse the entire clock in water. Only the designated water reservoir should be filled.
- Keep the device away from extreme temperatures and direct sunlight.
- Use only clean tap water for filling the reservoir.
- Keep out of reach of children to prevent accidental ingestion of water or small parts.
- Do not attempt to disassemble or modify the clock, as this may void the warranty and cause damage.

3. Product Overview

Components

The Aramox Water Powered LED Digital Alarm Clock features a clear LED display, control buttons, and a water reservoir for power generation.



Image 3.1: Front View. This image displays the front of the clock, highlighting the LED display area and the 'MODE' and 'SET' buttons used for adjustments.



Image 3.2: Back View with Water Cap. This image shows the rear of the clock, featuring the water filling cap. Instructions for adding water and salt are visible on the cap.



Image 3.3: Side View. This image provides a side perspective of the clock, illustrating its compact and curved design.

4. Setup

Filling with Water

The clock requires water to generate power. Follow these steps to fill the reservoir:

1. Locate the white cap on the back of the clock.
2. Carefully open the lid of the water reservoir.
3. Add approximately half a teaspoon (about 2-3g) of salt into the reservoir. This is crucial for the clock's operation.
4. Fill the reservoir with clean tap water.
5. Securely close the lid.
6. The display should activate shortly after filling. You will need to change the water every few weeks for continuous operation.



Image 4.1: Water Cap Instructions. This close-up shows the text on the water cap, instructing the user to add salt when filling the reservoir.

5. Operating Instructions

Setting the Time and Date

Use the 'MODE' and 'SET' buttons on the front of the clock to adjust the time and date.



Image 5.1: Control Buttons. This image provides a detailed view of the 'MODE' and 'SET' buttons on the clock's front panel.

1. Press the **SET** button twice to enter the setting mode. The display will indicate the adjustable segment.
2. Press the **MODE** button to cycle through and set the month.
3. Press the **SET** button to move to the next setting: day of the week, hour, and then minute.
4. While a segment is flashing, press the **MODE** button repeatedly to adjust the value to your desired setting.
5. After completing all adjustments, press the **SET** button to exit the setting mode.

6. Maintenance

Water Refill

To ensure continuous operation, the water in the reservoir should be changed every few weeks. Refer to Section 4, 'Filling with Water', for detailed instructions.

Cleaning

To clean the exterior of the clock, use a soft, dry cloth. Do not use abrasive cleaners or immerse the clock in water. Ensure the water reservoir cap is securely closed before cleaning.

7. Troubleshooting

Common Issues

- **No Display:** Ensure the water reservoir is filled with water and that the recommended amount of salt (2-3g) has been added. If the display remains off, try replacing the water and salt mixture.
- **Incorrect Time/Date:** Refer to Section 5, 'Setting the Time and Date', to re-adjust the clock settings.
- **Display Fading:** This may indicate that the water needs to be changed. Replace the water and salt mixture in the reservoir.

8. Specifications

Feature	Specification
Model Number	Aramoxgyrudx5fhz-11
Power Source	Water Powered
Display Type	LED Digital
Item Weight	Approx. 112g (3.95 ounces)
Size (Diameter)	8.5 cm (3.3 inches)
Material	ABS

9. Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For warranty details, technical support, or any inquiries regarding your Aramox Water Powered LED Digital Alarm Clock, please contact the manufacturer or your point of purchase directly.

You may be able to find additional support information by visiting the Aramox store online:Aramox Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FCNR224M

More documents and user manuals: **https://manuals.plus/**