

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Energizer](#) /

› [Energizer PAW Patrol Kids LED Lantern and Handheld Flashlight Combo Pack Instruction Manual](#)

Energizer 039800139603

Energizer PAW Patrol Kids LED Lantern and Handheld Flashlight Combo Pack Instruction Manual

Model: 039800139603

PRODUCT OVERVIEW

The Energizer PAW Patrol Combo Pack provides a fun and functional lighting solution for children. This pack includes one LED handheld flashlight and one LED lantern, both featuring popular PAW Patrol characters. Designed for small hands, these lightweight devices offer a gentle glow suitable for various activities, from indoor play to outdoor adventures.



SPECIAL EDITION CHARACTER DESIGN

Image: The Energizer PAW Patrol LED Lantern, featuring a blue base and top with a white body adorned with various PAW Patrol characters.

KEY FEATURES

- **Combo Pack:** Includes one LED lantern and one LED handheld flashlight.
- **Easy Operation:** Both devices are designed for simple, child-friendly use.
- **Durable Design:** Impact-resistant up to 1 meter. The lantern is also IPX4 water-resistant.
- **Shatterproof Lens:** Ensures lasting use and safety.
- **Extended Battery Life:** Lantern provides up to 17 hours of light, while the flashlight offers up to 72 hours.
- **Child-Safe Battery Compartment:** Features a tiny screw to secure batteries, preventing accidental access by children.
- **Portable:** Lightweight design with a retractable clip on the lantern and a lanyard loop on the flashlight for easy carrying.

SETUP AND BATTERY INSTALLATION

The Energizer PAW Patrol Combo Pack comes with batteries included. To install or replace batteries, follow these steps:

1. Locate the battery compartment on the device (flashlight or lantern).
2. Identify the small screw securing the battery cover. A small, glasses-sized screwdriver is required to open this compartment.
3. Carefully unscrew the screw and remove the battery cover.
4. Insert the required batteries (2 AAA for the flashlight, 2 AAA for the lantern, totaling 4 AAA batteries for the combo pack) ensuring correct polarity (+/-).
5. Replace the battery cover and securely fasten the screw.

Note: The safety screw is a feature designed to prevent young children from accessing the batteries, enhancing product safety.



BATTERIES INCLUDED

Image: The Energizer PAW Patrol Flashlight and Lantern displayed next to AAA batteries, illustrating the included components and approximate sizes.

OPERATING INSTRUCTIONS

Handheld Flashlight:

- To turn the flashlight ON, press the red power button located on the side of the flashlight.
- To turn the flashlight OFF, press the red power button again.



EASY TO USE PUSH BUTTON

LED FLASHLIGHT

Image: Two children are shown reading a book, illuminated by the bright beam of an Energizer PAW Patrol LED flashlight.

LED Lantern:

- To turn the lantern ON, press the yellow power button located on the side of the lantern.
- To turn the lantern OFF, press the yellow power button again.
- The lantern features a retractable clip for hanging and a sturdy base for tabletop use.



EASY TO HANG

RETRACTABLE HANGING CLIP

Image: An Energizer PAW Patrol LED lantern hangs from the ceiling of a tent, providing ambient light for two children reading.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the devices with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Battery Replacement:** Replace batteries when the light dims significantly. Always use new batteries of the specified type (AAA).
- **Storage:** If storing the devices for an extended period, remove the batteries to prevent leakage and damage.
- **Durability:** The flashlight and lantern are designed to be impact-resistant up to 1 meter. The lantern is also IPX4 water-resistant, meaning it can withstand splashes from any direction.



SPLASHPROOF & SHATTERPROOF

Image: The Energizer PAW Patrol LED Lantern is shown being splashed by mud, highlighting its water-resistant and durable construction.

TROUBLESHOOTING

- **Device not turning on:**
 - Check if batteries are correctly inserted with the proper polarity.
 - Ensure batteries are not depleted and replace if necessary.
 - Verify the battery compartment screw is securely fastened.
- **Dim light:** Replace batteries with new ones.

SPECIFICATIONS

Brand	Energizer
Model Number	039800139603
Product Dimensions	3.46" L x 6.14" W x 7.36" H

Item Weight	0.34 Kilograms (11.8 ounces)
Material	Plastic
Light Source Type	Light Emitting Diode (LED)
Power Source	Battery Powered
Battery Type	AAA Alkaline (4 required, included)
Voltage	6 Volts
Battery Life (Lantern)	Up to 17 Hours
Battery Life (Flashlight)	Up to 72 Hours
Water Resistance	IPX4 (Lantern), Water Resistant (Flashlight)
Special Features	Durable, Shatterproof Lens

WARRANTY AND SUPPORT

Warranty information for this product is not explicitly provided as per the available data. For any product-related inquiries or support, please refer to the manufacturer's official website or contact their customer service directly.

© 2025 Energizer. All rights reserved.