

MAGIC JOHN Y2

MAGIC JOHN Selfie Stick Tripod with BT5.2 Remote

Model: Y2

INTRODUCTION

Thank you for purchasing the MAGIC JOHN Selfie Stick Tripod. This versatile device combines a selfie stick and a stable tripod, featuring Bluetooth 5.2 connectivity for remote control. Designed for ease of use and portability, it's ideal for capturing photos, videos, vlogs, and live streams. This manual will guide you through the setup, operation, and maintenance of your new device.

PRODUCT FEATURES

- **Automatic 1-Second Deployment:** Equipped with a unique automatic pop-up mechanism, the tripod legs deploy instantly when placed vertically on a surface, eliminating manual setup time.
- **8-Stage Extendable Pole (30.5cm to 150cm):** Adjust the height from a compact 30.5cm for portability to an extended 150cm for wide-angle shots and group photos.
- **Advanced Bluetooth 5.2 Remote:** Features the latest Bluetooth 5.2 chip for faster pairing, stable connection up to 10 meters, and improved power efficiency for longer battery life. The remote is detachable for convenient use.
- **180° Flexible Rotation & Stable Base:** The phone holder supports 180-degree rotation and tilt, allowing for diverse shooting angles. The wide tripod base with anti-slip rubber feet and aviation-grade aluminum alloy construction ensures excellent stability on various terrains.
- **Cold Shoe Mount:** Integrated cold shoe allows for attachment of accessories like LED lights or microphones, enhancing your content creation capabilities.
- **Lightweight & Compact Design:** Folds down to just 30.5cm, making it easy to carry in a backpack for travel and outdoor activities.

SETUP GUIDE

1. Unfolding the Tripod

The MAGIC JOHN Selfie Stick Tripod features an automatic deployment mechanism. Simply hold the stick vertically and place it on a flat surface. The tripod legs will automatically extend and lock into position.

スナップオープン・マジック



ご注意：落下する前にリモコンを外してください

トリガー リリース機構



フリック



立つ



オープン

1

(1) 地面に接触して迅速に三脚スタンドを展開する
(10cmの高さから地面に接触するまで)

2

(2) 自動展开。

Image: Automatic 1-second deployment of the tripod legs. Place the stick vertically on a surface, and the legs will pop out.

2. Mounting Your Smartphone

1. Gently pull apart the spring-loaded phone holder clamps.
2. Insert your smartphone into the holder, ensuring it is securely gripped by both clamps.
3. Adjust the phone's position to ensure balance and desired orientation (horizontal or vertical).

コンパクト & ポータブル

旅行のお供に最適



Image: The phone holder mechanism, demonstrating its compatibility with various smartphone models (iPhone, Galaxy, Google) and accessories such as fill lights and microphones.

3. Pairing the Bluetooth Remote

1. Ensure the remote control is charged (if applicable) and powered on.
2. On your smartphone, go to Bluetooth settings and enable Bluetooth.
3. Search for available devices. The remote will typically appear as "MAGIC JOHN" or a similar identifier.
4. Select the device to pair. Once paired, the indicator light on the remote will confirm connection.

取り外し可能な Bluetoothリモート



10メートル以内の感知範囲



人体工学に基づく柔らかな感触リモコン

Image: The detachable Bluetooth remote control, highlighting its ergonomic design and effective operating range of up to 10 meters.

OPERATING INSTRUCTIONS

1. Extending and Retracting the Pole

- To extend: Gently pull the top section of the pole upwards. It will extend in stages.
- To retract: Push the extended sections back down into the main body until fully collapsed.

X8 高さ 調節可能



30CM-150CM

三脚架だけでなく、
撮影用の多機能スタンドでもあります

Image: The selfie stick tripod extended to its maximum height of 150cm, demonstrating its 8-stage adjustable pole for various shooting perspectives.

2. Adjusting the Angle and Orientation

- The phone holder can rotate 180 degrees horizontally and tilt for optimal viewing and shooting angles. Loosen the adjustment knob (if present) or simply rotate the holder to your desired position.
- Ensure the phone is securely tightened in the holder after adjustment.



耐久性と安定性に優れた三脚ベース
どんな表面でも確実にサポート



滑り止め
シリコンパッド

航空グレードアルミ合金:
より軽く、より安定



Image: The phone holder's flexible 180-degree rotation and tilt capabilities, along with the integrated cold shoe mount for attaching external accessories like LED lights or microphones.

3. Using the Bluetooth Remote

- Once paired, open your smartphone's camera application.
- Press the button on the Bluetooth remote to trigger the shutter and take a photo or start/stop video recording.

MAINTENANCE

- **Cleaning:** Wipe the selfie stick tripod with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures. Ensure it is fully retracted and the remote is securely stored in its designated slot.
- **Battery Care (Remote):** If the remote uses a replaceable battery, ensure it is inserted correctly. If rechargeable, charge it regularly to maintain battery health.

TROUBLESHOOTING

- **Remote Not Connecting:**
 - Ensure the remote is powered on and has sufficient battery.
 - Check your phone's Bluetooth settings to ensure Bluetooth is enabled and the remote is paired. Try unpairing and re-pairing the device.
 - Make sure the remote is within the 10-meter operating range.
- **Tripod Legs Not Deploying Automatically:**
 - Ensure the stick is placed perfectly vertical on a flat, stable surface.
 - Check for any obstructions or debris in the leg mechanism.
- **Stability Issues:**
 - Ensure the tripod legs are fully extended and locked.
 - Place the tripod on a flat, stable surface. Avoid uneven ground.
 - Do not overload the phone holder with accessories beyond its capacity.

SPECIFICATIONS

Feature	Description
Brand	MAGIC JOHN
Model Number	Y2
Color	Black
Product Dimensions (D x W x H)	30 x 30 x 310 mm (folded)
Product Weight	0.28 kg
Max Extension Length	150 cm
Min Folded Length	30.5 cm
Extension Stages	8 stages
Bluetooth Version	5.2
Remote Control Range	Up to 10 meters
Compatible Devices	Smartphones (iPhone, Android), Cameras, Video Cameras
Material	Aviation-grade Aluminum Alloy
Country of Origin	China

WARRANTY AND SUPPORT

MAGIC JOHN is committed to providing high-quality products and excellent customer service.

- **Quality Guarantee:** This product comes with a 180-day quality guarantee.
- **Free Exchange Service:** Enjoy a 180-day free exchange service for any manufacturing defects.
- **Customer Support:** 24-hour customer support is available for any inquiries or assistance.
- **Return Policy:** We offer a 30-day unconditional return policy.



Image: Overview of MAGIC JOHN's customer support, including 24H customer support, 30-day unconditional return, and 180-day quality guarantee.