

## Saker SK-LB650

# Saker Cordless Leaf Blower

Model: SK-LB650

## 1. SAFETY INFORMATION

---

Always read and understand all safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.

- Wear appropriate personal protective equipment, including eye protection, hearing protection, and sturdy footwear.
- Keep children and bystanders away while operating the leaf blower.
- Do not operate the blower in wet conditions or near flammable liquids or gases.
- Ensure the battery is fully charged before use and removed when not in operation or during maintenance.
- Inspect the blower for any damage before each use. Do not operate if damaged.

## 2. PRODUCT OVERVIEW

---

The Saker Cordless Leaf Blower SK-LB650 is a versatile tool designed for efficient debris removal. It features a powerful motor, a dual battery system, and multiple speed settings for various tasks.

### Key Features:

- **Powerful Performance:** Delivers 650CFM of airflow for clearing leaves, debris, and dust from various surfaces.
- **Dual Battery System:** Equipped with two 5.0Ah batteries for extended runtime and seamless switching.
- **3-Speed Flexibility:** Adjustable low, medium, and high-speed settings for different cleaning needs.
- **Ergonomic Design:** Lightweight (4.2 lbs) with an anti-slip handle for comfortable, prolonged use.
- **Versatile Use:** Suitable for both indoor spaces like garages and warehouses, and outdoor areas such as yards, driveways, and patios.

# PRODUCT DETAILS



Figure 2.1: Product Details and Components

The blower is designed for a wide range of applications, from clearing leaves and snow outdoors to removing dust and grass clippings.



Figure 2.2: Wide Range of Applications

### 3. COMPONENTS INCLUDED

The Saker Cordless Leaf Blower SK-LB650 package includes the following items:

- Leaf Blower Unit
- Two 5.0Ah Batteries
- Battery Charger
- Blower Tube
- Extension Nozzle
- User Manual

- A pair of gloves

## 4. ASSEMBLY

Follow these steps to assemble your Saker Cordless Leaf Blower:

1. Push the blower tube onto the tool body buckle. Rotate and lock it into place.
2. Install the battery pack onto the body of the blower until it clicks securely.
3. Push the chassis to secure it to the product.



Figure 4.1: Simple Installation Steps

## 5. BATTERY CHARGING

The Saker Cordless Leaf Blower uses two 22V 5.0Ah batteries. Ensure batteries are fully charged before use for optimal performance.



Figure 5.1: Battery and Charging Indicators

- Connect the charger to a power outlet and insert the battery.
- A red LED indicates charging, and a green LED indicates a full charge.
- Press the check button on the battery pack to view the remaining battery power via the LED indicators.

## 6. OPERATION

The leaf blower features an electronic switch and three-speed settings for precise control.

# 3-SPEED ADJUSTMENT

## 01 Electronic Switch

### Long Press to Turn On / Off

Keep pressing "Level" Button for over **2 Secs** to start / stop the blower. The tool will start from lowest speed.

### Short Press to switch Speed

Quick click "Level" Button to change the air speed. The speed level will change from 1 to 3, then back to level 1.

## 02 Speed indicator LEDs

**LEVEL 1**   

**LEVEL 2**   

**LEVEL 3**  



Figure 6.1: 3-Speed Adjustment Controls

### Power On/Off:

- **To Turn On/Off:** Long press the "Level" button for over 2 seconds. The tool will start at the lowest speed.

### Adjusting Speed:

- **To Switch Speed:** Short press the "Level" button to change the air speed. The speed level will cycle from 1 to 3, then back to 1.
- **Level 1 (Low Speed):** Ideal for delicate tasks such as garage cleaning or indoor dust removal.
- **Level 2 (Medium Speed):** Suitable for general yard work and light debris.
- **Level 3 (High Speed):** Best for clearing thick foliage in gardens or public areas.

Your browser does not support the video tag.

Video 6.2: Demonstration of the Saker Cordless Leaf Blower in various cleaning scenarios, highlighting its power and versatility.

## 7. MAINTENANCE

---

Regular maintenance ensures the longevity and optimal performance of your leaf blower.

- **Cleaning:** After each use, wipe down the exterior of the blower with a damp cloth. Ensure air vents are clear of debris.
- **Battery Care:** Store batteries in a cool, dry place. Do not store fully discharged batteries for extended periods. Charge them periodically if not in use.
- **Storage:** Store the leaf blower in a dry, secure location away from direct sunlight and extreme temperatures.

## 8. TROUBLESHOOTING

---

If you encounter issues with your Saker Cordless Leaf Blower, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blower does not start	Battery not installed correctly or discharged	Ensure battery is fully seated. Charge battery if needed.
Reduced airflow	Air intake or blower tube obstructed	Clear any debris from the air intake and blower tube.
Short operating time	Battery not fully charged or nearing end of life	Fully charge batteries before use. Consider replacing old batteries.

## 9. SPECIFICATIONS

---

Detailed technical specifications for the Saker Cordless Leaf Blower SK-LB650:

Specification	Value
Brand	Saker
Model Name	Saker Electric Leaf Blower 650CFM
Model Number	SK-LB650
Air Volume	650 CFM
Voltage	22 Volts
Battery Capacity	2x 5.0Ah
Speed Settings	3-Speed (Low, Medium, High)
Weight	4.2 lbs
Product Dimensions (L x W x H)	10.6" x 6.7" x 17"

Specification	Value
Power Source	Battery Powered
Form Factor	Handheld
Special Features	Adjustable Speed, Adjustable Tube Length, Portable, Rechargeable

## 10. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the documentation included with your product packaging or contact Saker customer service. Keep your purchase receipt as proof of purchase.