



[Manuals.plus](#) /

› [GiveBest](#) /

› GiveBest 906ES 1500W Portable Ceramic Space Heater Instruction Manual

GiveBest 906ES

GiveBest 906ES 1500W Portable Ceramic Space Heater Instruction Manual

IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all safety instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Overheat Protection:** The heater is equipped with an automatic overheat protection system. If the heater overheats, it will automatically shut off. Unplug the heater and allow it to cool for 30 minutes before restarting.
- **Tip-Over Protection:** For your safety, the heater features a tip-over switch located on the bottom. If the heater is accidentally tipped over, it will automatically shut off. Ensure the heater is placed on a firm, level surface for proper operation.
- **Fire-Resistant Materials:** Constructed with V-0 grade fire-resistant materials for enhanced safety.
- **Power Consumption:** This 1500W heater draws significant power. Avoid plugging it into overloaded circuits or extension cords. Always plug directly into a wall outlet.
- **ETL Certified:** This product is ETL certified, ensuring it meets recognized safety standards.
- Keep all combustible materials (furniture, pillows, bedding, papers, clothes, and curtains) at least 3 feet (0.9 m) from the front, sides, and rear of the heater.
- Do not use outdoors.
- Do not use in bathrooms, laundry areas, or similar indoor locations where it may come into contact with water.

PRODUCT OVERVIEW

The GiveBest 906ES Portable Ceramic Space Heater is designed to provide efficient and rapid heating for indoor spaces up to 200 sq.ft. Featuring PTC ceramic technology, multiple operating modes, and advanced safety features, it offers a comfortable and secure heating solution.



Figure 1: Front view of the GiveBest 906ES Portable Ceramic Space Heater.

SETUP

1. **Unpack the Heater:** Carefully remove the heater from its packaging. Retain packaging materials for future storage or transport.
2. **Placement:** Place the heater on a firm, level surface. Ensure there are no obstructions within 3 feet (0.9 m) of the heater's front, sides, and rear. Do not place on soft surfaces like rugs or carpets that may block the bottom safety switch.
3. **Power Connection:** Plug the power cord directly into a 120V AC, 60Hz wall outlet. Do not use extension cords or power strips.

Multi-Layer Safety Protection



Figure 2: Top control panel and handle for easy portability.

OPERATING INSTRUCTIONS

Control Panel and Remote

The heater can be operated using the buttons on the top control panel or the included remote control.

Power On/Off

- Press the **Power** button (O) once to turn the heater on. The display will show the current room

temperature.

- Press the **Power** button again to turn the heater off. The fan will continue to run for a few seconds to cool down the heating elements before completely shutting off.

Mode Selection

Press the **Mode** button (**M**) to cycle through the available modes:

- **High Heat (P2)**: Provides 1500W of heating power.
- **Low Heat (P1)**: Provides 750W of heating power.
- **ECO Mode**: The heater automatically adjusts its power consumption (750W/1500W) to maintain the set temperature, optimizing energy efficiency.
- **Fan Only**: Circulates air without heat.

Temperature Adjustment

- In High Heat, Low Heat, or ECO Mode, use the **Temperature Up (+)** and **Temperature Down (-)** buttons to set your desired temperature (41°F to 95°F).
- The heater will cycle on and off to maintain the set temperature.

Timer Function

- Press the **Timer** button (**L**) to activate the timer.
- Use the **Temperature Up (+)** and **Temperature Down (-)** buttons to set the desired operating time (1 to 12 hours).
- The heater will automatically turn off after the set time has elapsed.

Child Lock

- Press and hold the **Child Lock** button (often indicated by a lock icon) for 3 seconds to activate or deactivate the child lock.
- When activated, the control panel buttons will be disabled to prevent accidental changes.

MODES AND FEATURES EXPLAINED

2s Rapid Whole-Room Heating

Powered by 1500W and PTC ceramic technology, this portable heater delivers instant, efficient warmth up to 200 sq.ft. Experience quick and comfortable heat exactly when you need it.



Figure 3: Illustration of the heater's rapid heating capability.

Whisper-Quiet Operation

Designed with quiet brushless DC motor technology and refined aerodynamic blades, this space heater delivers gentle warmth for a peaceful night's sleep. The portable heater ensures a calm and cozy atmosphere, keeping you comfortably focused on work and offering undisturbed comfort while sleeping.




Figure 4: Heater operating quietly in a bedroom setting.

ECO Mode for Energy Savings

The ECO mode intelligently manages power output to maintain your desired temperature while minimizing energy consumption, potentially saving up to 40% on energy compared to continuous high heat.

Heat Funnel Extends

Deliver Heat to
Where You Need it Most




Figure 5: Visual representation of energy efficiency in ECO mode.

Portable Design

With a durable integrated handle, the heater is easy to move between rooms, providing warmth wherever you need it most.

Deliver Heat to Where You Need it Most



Figure 6: Heater positioned on a desk for personal warmth.

MAINTENANCE

Cleaning

- Always unplug the heater and allow it to cool completely before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to remove dust from the grilles.

- Never immerse the heater in water or allow water to drip into the interior.

Storage

- Store the heater in its original packaging in a cool, dry place when not in use.
- Avoid placing heavy objects on top of the heater during storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in, power outlet malfunction, tip-over switch activated, overheat protection activated.	Ensure plug is firmly in outlet. Check circuit breaker. Ensure heater is upright on a flat surface. Unplug and allow to cool for 30 minutes.
Heater blows cold air.	Heater is in Fan Only mode, desired temperature is set too low.	Select a heat mode (P1, P2, or ECO). Increase the desired temperature setting.
Heater makes unusual noise.	Dust buildup, loose internal component.	Unplug and clean the grilles. If noise persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	GiveBest
Model Number	906ES
Power Source	Corded Electric
Heat Output	1500 Watts
Heating Coverage	200 sq.ft.
Voltage	120 Volts
Max Temperature Setting	95 Degrees Fahrenheit
Item Dimensions (D x W x H)	6.9"D x 5.5"W x 9.2"H
Special Features	Energy Efficient, Digital Display, Noise Reduction, Fast Heating, Remote Control, 12H Timer, Memory Function, Portable, Overheat Protection, ECO Mode, Child Lock

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or contact GiveBest customer service directly. Keep your purchase receipt for warranty claims.