

AIRMATE FB2067R-D

AIRMATE 12" Large Air Circulator Fan

Model: FB2067R-D

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance and retain for future reference. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always unplug the fan before cleaning or performing any maintenance.
- Do not operate the fan with a damaged cord or plug. If the cord or plug is damaged, contact qualified service personnel for repair or replacement.
- Do not place the fan in or near water or other liquids.
- Keep fingers and other objects away from the fan blades and openings during operation.
- Ensure the fan is placed on a stable, level surface to prevent tipping.
- This appliance is for indoor use only. Do not use outdoors.
- Do not cover the fan or restrict airflow during operation.
- Supervise children when the fan is in use. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. PRODUCT OVERVIEW

The AIRMATE 12" Large Air Circulator Fan is designed to provide efficient and powerful air circulation throughout your room. It features a quiet DC motor, multiple speed settings, and wide-angle oscillation for optimal comfort.



Image: The AIRMATE 12-inch Air Circulator Fan in InkBlack, shown with its accompanying remote control.

Key Features:

- **High Efficiency Air Circulation:** Utilizes aerodynamic turbine and bionic fan blade design for maximum airflow.
- **Quiet DC Motor:** Energy-saving motor provides strong airflow with low noise (as low as 25 dB).
- **Multi-directional Oscillation:** 120° horizontal automatic oscillation and 90° manual vertical tilt.
- **10 Speed Settings:** Ranging from soft wind to high velocity, suitable for various needs.
- **12-Hour Timer:** Programmable timer for automatic shut-off.
- **Remote Control:** Convenient operation from a distance.
- **Baby Soft Wind Mode:** A gentle wind setting specifically designed for sensitive environments.

Powerful Whole-room Air Circulation



22ft
Max Distance



13ft/s
Max Wind Speed



Image: A diagram illustrating how the AIRMATE fan circulates air throughout an entire room, demonstrating its powerful whole-room air circulation capability with a maximum distance of 22 feet and a maximum wind speed of 13 ft/s.

Package Contents:

- AIRMATE 12" Air Circulator Fan (Model: FB2067R-D)
- Remote Control
- User Manual

3. SETUP

The AIRMATE Air Circulator Fan comes pre-assembled and ready for use. No complex assembly is required.

1. **Unpack:** Carefully remove the fan and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the fan on a firm, level surface. Ensure there is adequate space around the fan for optimal airflow and oscillation. Avoid placing it directly against walls or furniture that could obstruct air intake or output.
3. **Power Connection:** Insert the power plug into a standard 120V AC electrical outlet.

4. OPERATING INSTRUCTIONS

The fan can be operated using the control panel on the unit or the included remote control.

Upscale & Easy-to-operate Panel

Work status at a glance, multifunctional control panel provide easy access to all settings




Image: A close-up view of the fan's control panel, showing buttons for On/Off, Wind Speeds, Timer, 120° Rotation, and Baby Soft Wind mode.

Control Panel Functions:

- **Power Button (U):** Press to turn the fan On or Off.
- **Wind Speed Button (~):** Press repeatedly to cycle through 10 speed settings. Indicators will light up to show the current speed.
- **Timer Button (L):** Press to set the timer for 1, 2, 4, or 8 hours. The fan will automatically turn off after the selected time.
- **Oscillation Button (C):** Press to activate or deactivate the 120° horizontal oscillation.
- **Baby Soft Wind Button (baby icon):** Press to activate the gentle baby soft wind mode.

Remote Control:

The remote control allows you to operate all fan functions from a distance. Ensure the remote is pointed towards the fan's receiver.



Image: The compact remote control for the AIRMATE fan, featuring power, speed, timer, and oscillation buttons.

Oscillation and Tilt:

- **Horizontal Oscillation:** Press the Oscillation button on the control panel or remote to activate the automatic 120° left-right swing.
- **Vertical Tilt:** The fan head can be manually tilted up or down by 90° to direct airflow as desired. Gently adjust the fan head to the desired angle.

Multi-directional Airflow

Equipped with a manual 90° and automatic 120° swivel head to direct air where you need it



Left/Right
automatically



Up/Down
manually



Image: A visual representation of the fan's multi-directional airflow capabilities, showing 120° automatic left/right swivel and 90° manual up/down tilt.

5. MAINTENANCE

Regular cleaning and maintenance will help ensure the longevity and optimal performance of your fan.

Cleaning:

1. **Unplug:** Always unplug the fan from the power outlet before cleaning.
2. **Exterior:** Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the surface.
3. **Grille and Blades:** The front grille can be removed for easier cleaning of the fan blades. Gently twist the front grille counter-clockwise to unlock and remove it. Use a soft cloth or a vacuum cleaner with a brush attachment to remove dust from the blades and inside the grille. Reattach the grille by aligning and twisting clockwise until secure.
4. **Storage:** If storing the fan for an extended period, cover it with a plastic bag or return it to its original packaging to

protect it from dust. Store in a cool, dry place.

More Features



Image: A visual guide demonstrating the easy-to-clean design of the fan, highlighting the removable front grille for access to the blades.

6. TROUBLESHOOTING

If you experience issues with your fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the Power button on the fan or remote.
Weak airflow.	Fan speed is too low. Air intake/output blocked. Dust accumulation on blades.	Increase the fan speed setting. Ensure nothing is obstructing the front or rear grilles. Clean the fan blades and grilles as per maintenance instructions.
Fan is noisy.	Fan is not on a level surface. Loose parts or foreign objects.	Place the fan on a stable, level surface. Unplug the fan and check for any loose parts or foreign objects inside the grilles.
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and fan.	Replace batteries with new ones, ensuring correct polarity. Ensure there is a clear line of sight between the remote and the fan's receiver.

If the problem persists after trying these solutions, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	AIRMATE

Feature	Detail
Model Name	FB2067R-D
Color	InkBlack
Electric Fan Design	Table Fan / Air Circulator
Power Source	DC
Product Dimensions	11"D x 11"W x 13"H
Item Weight	11.43 pounds
Noise Level	25 dB (minimum)
Wattage	20 watts
Air Flow Capacity	890 Cubic Feet Per Minute
Voltage	120 Volts
Oscillation	120° Horizontal (Auto), 90° Vertical (Manual)
Speed Settings	10 Speeds
Timer	Up to 12 Hours

8. WARRANTY AND SUPPORT

AIRMATE products are manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official AIRMATE website.

Please have your model number (FB2067R-D) and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question