

[Manuals.plus](#) /

› [OLIXIS](#) /

› OLIXIS 7-Drawer Fabric Dresser (Model LA7DRBK) User Manual

OLIXIS LA7DRBK

OLIXIS 7-Drawer Fabric Dresser (Model LA7DRBK) User Manual

Model: LA7DRBK

Brand: OLIXIS

INTRODUCTION

Thank you for choosing the OLIXIS 7-Drawer Fabric Dresser. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new storage unit.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions carefully before assembly and use.
- Keep all small parts and packaging materials away from children.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Always use the included anti-tip kit to secure the dresser to a wall to prevent tipping, especially in households with children or pets.
- Do not overload drawers. Distribute weight evenly.
- Do not climb on or stand on the dresser.
- Place the dresser on a level surface to prevent instability.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. Refer to the component list below and the provided diagram.



An image displaying all individual components included in the OLIXIS 7-Drawer Fabric Dresser package, such as metal frames, top board, fabric drawers, and hardware.

Component List

Component	Quantity
Left Frame (A)	1
Right Frame (B)	1
Middle Frame (C)	1
Top Frames (D)	2
Top Cross Bars (E)	2
Bottom Cross Bars (F)	2

Component	Quantity
Left Drawer Slides (L)	7
Right Drawer Slides (R)	7
Small Drawers (G)	3
Big Drawers (H)	4
Top Board (P)	1
Screws, Wrench, Adjusting Feet, Anti-tip Kit	Included

SETUP AND ASSEMBLY

Follow these steps for proper assembly. An assembly video is available for visual guidance.

Your browser does not support the video tag.

Official OLIXIS assembly video demonstrating the step-by-step process of constructing the 7-Drawer Fabric Dresser.

1. Step 1: Assemble the Base Frame

Attach the bottom crossbars to the left and right frames. Tighten screws to 50% initially. Ensure square holes on frames and top frames are consistent with illustrations.



Size Information

Maximum load capacity 66 Lbs



A side view of the dresser frame, highlighting the sturdy steel construction.

2. Step 2: Attach Top Frames and Middle Frame


Secure the top frames and middle frame to the assembled base. Again, tighten screws to 50%.

3. Step 3: Install Drawer Slides


Attach the left and right drawer slides to the frames. Ensure correct orientation. **Important:** Fully tighten all screws *after* drawer slides are assembled to ensure proper alignment and stability.

4. Step 4: Prepare Fabric Drawers


Unfold each fabric drawer and insert the bottom panel to create a sturdy box. Attach the handles.




Waterproof



Easy-to-Pull Handles



Wear Resistant



Adjustable Feet

An image illustrating the internal capacity of the fabric drawers, showing how clothes can be neatly stored.

5. **Step 5: Insert Drawers and Attach Top Board**

Place the prepared fabric drawers into their respective compartments. Secure the wooden top board to the frame.



A front view of the fully assembled OLIXIS 7-Drawer Fabric Dresser with all drawers in place and the wooden top board installed.

6. Step 6: Install Adjustable Feet and Anti-Tip Kit


Screw in the adjustable feet at the bottom of the dresser to ensure stability on uneven surfaces. Install the anti-tip kit to a wall stud and secure the dresser to it.

Studay Structure

No Deformation



Anti-Tilt Device



Cross Support
for Stability



A close-up image highlighting the adjustable feet for leveling and the anti-tip device for wall mounting, enhancing stability and safety.

OPERATING GUIDELINES

- **Drawer Use:** Pull drawers out gently using the handles. Avoid sudden forceful movements.
- **Weight Distribution:** Distribute items evenly within each drawer to prevent sagging or damage.
- **Top Surface:** The wooden top can hold decorative items or frequently used essentials. Do not exceed the maximum load capacity of 66 lbs.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the wooden top with a damp cloth. For fabric drawers, spot clean with a mild detergent and allow to air dry. Avoid harsh chemicals.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten as necessary.
- **Fabric Care:** The high-quality non-woven fabric is wear-resistant. Avoid sharp objects that could tear the fabric.

TROUBLESHOOTING

- **Dresser is Wobbly:**
 - Check if the adjustable feet are properly leveled.
 - Ensure all assembly screws are fully tightened.
 - Verify the anti-tip kit is securely installed.
- **Drawers Do Not Slide Smoothly:**
 - Ensure the drawer slides are correctly installed and not obstructed.
 - Check if drawers are overloaded or items are catching.
- **Missing Parts:**
 - Contact OLIXIS customer support immediately with your purchase details.

SPECIFICATIONS

Feature	Detail
Brand	OLIXIS
Model Name	LA7DRBK
Product Dimensions	11.81"D x 39.37"W x 30"H
Number of Drawers	7
Material	Fabric, Wood (MDF)
Frame Material	Steel
Color	Black
Item Weight	28.1 pounds
Maximum Load Capacity	66 lbs
Assembly Required	Yes

WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your OLIXIS 7-Drawer Fabric Dresser, please contact our customer support team. We aim to respond to all inquiries within 24 hours.

For additional product information or to explore other OLIXIS products, visit the [OLIXIS Store](#).

ADDITIONAL RESOURCES

Explore more about the OLIXIS 7-Drawer Fabric Dresser through these helpful videos:

Your browser does not support the video tag.

A short video showcasing the OLIXIS Dresser for Bedroom in a room setting, highlighting its aesthetic appeal and functionality.

Your browser does not support the video tag.

A brief preview video demonstrating the storage capabilities of the dresser, showing items being placed inside the drawers.

Your browser does not support the video tag.

A short video highlighting the dresser as an affordable and practical storage solution for bedrooms.

Your browser does not support the video tag.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question