

Miritz Google Certified Android Tracker

Miritz Google Certified Android Tracker User Manual

Model: Google Certified Android Tracker

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Miritz Google Certified Android Tracker. This device is designed to help you locate your personal items using the Google Find My Device app on compatible Android devices (Android 9 or higher). It is not compatible with iOS or Huawei devices.



Image 1.1: Miritz Google Certified Android Tracker and its app interface.

2. SAFETY INFORMATION

- Do not attempt to disassemble or modify the device. This may void the warranty and cause damage.
- Keep the device away from extreme temperatures, direct sunlight, and moisture.
- The device contains a replaceable CR2032 coin cell battery. Keep batteries out of reach of children. If swallowed, seek immediate medical attention.

- Dispose of the device and battery according to local regulations. Do not dispose of in household waste.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Miritz Google Certified Android Tracker (White)
- Keychain attachment
- CR2032 battery (pre-installed or included separately)
- Quick Start Guide (if applicable)

4. PRODUCT OVERVIEW



The Miritz Google Certified Android Tracker is a compact, lightweight device designed to help you keep track of your belongings. It connects to your Android smartphone via Bluetooth and leverages the Google Find My Device network for location tracking.

Key Features:

- **Google Certified:** Works seamlessly with Google Play Services for Android 9 or higher.
- **Sound Activation:** Activate a loud sound through the Google Find My Device app to locate nearby items.
- **Accurate Positioning:** Utilizes the Google Find My Device network for precise location and proximity display.
- **Privacy-First:** All location data is anonymous and encrypted, ensuring your privacy.
- **Versatile Use:** Ideal for keys, backpacks, luggage, wallets, pets, and more.
- **Replaceable Battery:** Powered by a standard CR2032 coin cell battery.
- **Water Resistant:** Designed to withstand splashes and light exposure to water.

Smart Bluetooth Tracker

No matter where you are, don't lose your belongings,
the world is big and the precious things are small



Note: Apple and Huawei devices are not supported

Image 4.1: The Miritz Android Tracker in use with a smartphone.

Compatibility:

This tracker is compatible with all Android phones running Android 9 or higher. It **is not** compatible with Apple iOS devices or Huawei devices.

Compatible With All Android Phones

Note : Apple and Huawei devices are not supported



Google
Play Store



Android



Google



xiaomi



Vivo



Oppo



Samsung



Other

Image 4.2: Examples of compatible Android devices.

5. SETUP

Follow these steps to connect your Miritz Android Tracker to your Android phone:

1. **Power On:** Ensure the tracker has a working CR2032 battery installed. The tracker is typically powered on by default when the battery is inserted.
2. **Proximity:** Hold the tracker close to your Android phone.
3. **Automatic Recognition:** Your phone should automatically recognize the tracker. A pop-up window will appear on your screen.
4. **Follow Prompts:** Follow the on-screen prompts to initiate the connection process.
5. **Google Find My Device App:**
 - If you already have the Google Find My Device app installed, open it and search for "Dahe Tag" (or the specific name displayed for your tracker) to connect.

- If you do not have the app installed, download it from the Google Play Store and then follow the prompts to connect your tracker.

6. **Connection Confirmation:** Once your tracker appears in the Google Find My Device app, the connection is successful, and you can begin using it.

Easy connection No need to download an app



It's easy to get started. You can connect through the "Find My" app that comes with Android devices




Image 5.1: Easy connection process with the Google Find My Device app.

6. OPERATING INSTRUCTIONS

Locating Your Items:

1. **Open Google Find My Device App:** Launch the app on your compatible Android phone.
2. **Select Your Tracker:** Choose the Miritz Android Tracker associated with the item you wish to locate.
3. **View Location:** The app will display the current or last known location of your item on a map.
4. **Play Sound:** If the item is nearby, tap the "Play Sound" option in the app. The tracker will emit an audible sound to

help you pinpoint its exact location.

5. **Proximity Display:** The app may show a real-time proximity display, indicating the distance to your item (accurate to meters), guiding you closer.




Image 6.1: Using the 'Play Sound' feature to find a nearby item.

Lost Mode and Left-Behind Reminders:

- **Activate Lost Mode:** If an item is truly lost, you can activate "Lost Mode" through the Google Find My Device app. This can help secure your item and potentially display contact information to anyone who finds it.
- **Left-Behind Reminders:** The tracker can notify you if you leave an item behind. When the tracker moves out of range from your phone, you may receive a notification on your device, helping to prevent loss.

Lost reminder

Do you often forget to bring things?

After something falls, the phone will send a reminder!

When you activate a lost item notification, whether it's a wallet, keys, or other personal belongings,

Once an item falls, the phone will receive a reminder to avoid loss!



With Google System Support Accurate Tracking Worldwide.



Two items were left behind

now

Detected that these Items are no longer with you.
Last time recorded In the office and vehicle

Image 6.2: Example of a 'Lost reminder' notification.

Privacy and Security:

The Miritz Android Tracker operates on Google's encrypted Find My Device network. All location information is anonymous and encrypted. Google's system cannot access your data, ensuring a privacy-first solution for tracking your items.

GLOBAL PRECISE LOCATION TRACKING

With Google System Support Accurate
Tracking Worldwide.



Works with Android
Find My Device

Google's system is continuously
being upgraded for
enhanced performance.




Image 6.3: Global precise location tracking capabilities.

Various Usage Scenarios:

NEVER LOSE AGAIN

Includes a keychain that easily attaches to any object.




Image 6.4: Examples of how the Miritz Android Tracker can be used.

The Miritz Android Tracker is a versatile tool for various items:

- **Keys:** Attach to your house or car keys.
- **Bags:** Secure to backpacks, purses, or luggage.
- **Wallets:** Place inside your wallet for easy retrieval.
- **Pets:** Attach to a pet's collar (ensure secure attachment and monitor pet comfort).
- **Other Valuables:** Use for any item you wish to track within the network's range.

7. MAINTENANCE

Battery Replacement:

The Miritz Android Tracker uses one CR2032 coin cell battery. When the battery is low, the app may notify you, or the tracker's performance may diminish. To replace the battery:

1. Carefully open the tracker casing. Refer to the product's physical design for the opening mechanism (e.g., twisting the two halves, prying open a small notch).
2. Remove the old CR2032 battery.
3. Insert a new CR2032 battery with the positive (+) side facing up.
4. Close the tracker casing securely, ensuring a tight seal to maintain water resistance.

Cleaning:

Wipe the tracker with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners, as these can damage the device.

Water Resistance:

The tracker is water resistant, meaning it can withstand splashes and light rain. It is not designed for submersion in water. Avoid exposing it to heavy rain, showering, or swimming.

8. TROUBLESHOOTING

If you encounter issues with your Miritz Android Tracker, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Tracker does not connect to phone.	• Ensure your Android phone is running Android 9 or higher. • Verify Bluetooth is enabled on your phone. • Make sure the tracker is powered on and has a fresh battery. • Hold the tracker close to your phone during the initial pairing process. • Restart your phone and try connecting again. • Ensure the Google Find My Device app is installed and updated.
Cannot hear the tracker's sound.	• The sound volume may be low, especially in noisy environments or if the tracker is obscured. Try to get closer to the estimated location. • Ensure the tracker is connected and within Bluetooth range of your phone or the Find My Device network. • Check the app to confirm the 'Play Sound' command was sent successfully.
Inaccurate location tracking.	• Location accuracy depends on the density of the Google Find My Device network in the area. In remote areas, accuracy may be lower. • Ensure your phone's location services are enabled. • The tracker's battery level can affect performance. Replace the battery if it's low.
Tracker frequently disconnects.	• The tracker may be moving out of Bluetooth range from your phone. • Interference from other electronic devices can cause disconnections. • A low battery can also lead to unstable connections.

9. SPECIFICATIONS

Feature	Detail
Brand	Miritz
Model	Google Certified Android Tracker
Connectivity Technology	Bluetooth
Compatible Devices	Android (Android 9 or higher)
Control Method	App (Google Find My Device)
Power Source	1 x CR2032 Battery (included)
Material	Plastic
Product Dimensions (L x W x Th)	1.26" x 1.26" x 0.39" (32mm x 32mm x 10mm)
Item Weight	0.8 Ounces
Range	Up to 100 meters (Bluetooth Low Energy)
Water Resistance	Yes



Image 9.1: Product dimensions and key features.

10. WARRANTY INFORMATION

The Miritz Google Certified Android Tracker comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper battery handling.

Please retain your proof of purchase for warranty claims.

11. SUPPORT

For any questions, technical assistance, or warranty claims regarding your Miritz Google Certified Android Tracker, please contact our customer service team. We are committed to providing support and will respond to your inquiries within 24 hours.

Please refer to the contact information provided with your product packaging or on the retailer's website where you

purchased the device.

© 2025 Miritz. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question