

Vibox IV-524

Vibox IV-524 Gaming PC User Manual

Model: IV-524

1. INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your Vibox IV-524 Gaming PC. This mid-range gaming PC offers a balance of performance and value, suitable for smooth gameplay at 1080p and 1440p resolutions. Equipped with a powerful multi-core processor and a dedicated graphics card, it efficiently runs popular games and provides room for future upgrades.

2. SAFETY INFORMATION

- **Power Supply:** Use only the provided power cable and connect it to a grounded outlet. Ensure the power supply voltage matches your local electrical standards.
- **Ventilation:** Do not block ventilation openings. Ensure adequate airflow around the PC to prevent overheating.
- **Liquid and Moisture:** Keep the PC away from liquids and excessive moisture. Do not operate the PC with wet hands.
- **Placement:** Place the PC on a stable, flat surface. Avoid placing it in direct sunlight or near heat sources.
- **Servicing:** Do not attempt to open or repair the PC yourself. Refer all servicing to qualified personnel.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Vibox IV-524 Gaming PC Tower
- Power Cable
- 300 Mbps Wi-Fi Adapter
- Documentation (Quick Start Guide, Warranty Information)
- RGB Lighting Controller (if applicable)

4. SETUP

4.1 Unpacking

Carefully remove the PC from its packaging. Inspect for any visible damage. Retain the original packaging for future transport or servicing.



Image: The Vibox IV-524 Gaming PC Tower, showcasing its white chassis and internal components.

4.2 Connecting Peripherals

1. **Monitor:** Connect your monitor to the graphics card (NVIDIA GeForce RTX 5060) using an HDMI or DisplayPort cable. Ensure the cable is securely fastened.
2. **Keyboard and Mouse:** Connect your keyboard and mouse to the available USB ports on the rear or front of the PC.
3. **Power:** Connect the power cable to the PC's power supply unit and then to a wall outlet.
4. **Network:** For wired internet, connect an Ethernet cable to the LAN port. For wireless internet, install the provided Wi-Fi adapter into an available USB port.




Image: Close-up of the Vibox IV-524 PC's front panel, highlighting USB 2.0, USB 3.0, headphone, and microphone ports, along with power and LED control buttons.

4.3 Initial Boot and Windows Setup

1. Press the power button on the front of the PC.
2. The PC will boot into Windows 11 Home. Follow the on-screen instructions to complete the initial Windows setup, including language, region, network connection, and user account creation.
3. Ensure all drivers are installed. Your system typically comes with pre-installed drivers. If any issues arise, visit the Vibox support website for the latest drivers.



Image: Visual representation of Windows 11 Home features, including faster loading times with DirectStorage, AutoHDR for enhanced graphics, seamless Xbox Game Pass integration, and optimized CPU performance.

5. OPERATING

5.1 Power On/Off and Restart

- **Power On:** Press the power button on the front panel.
- **Shut Down:** Click the Start button in Windows, then select Power > Shut down.
- **Restart:** Click the Start button in Windows, then select Power > Restart.

5.2 Connecting to Wi-Fi

1. Ensure the Wi-Fi adapter is connected to a USB port.
2. In Windows, click the Network icon in the taskbar.
3. Select your desired Wi-Fi network from the list and click 'Connect'.
4. Enter the network security key (password) if prompted.

5.3 RGB Lighting Control

Your PC features customizable RGB lighting. If an RGB controller or remote was included, refer to its specific instructions for changing colors and effects. Otherwise, lighting may be controlled via pre-installed software or motherboard utilities.

VENTILATEURS RVB INFINITY 120MM

PERSONNALISEZ VOTRE CONFIGURATION

PLUSIEURS COULEURS ET MODES RGB



Image: An internal view of the Vibox IV-524 PC, showcasing the illuminated RGB fans and components within the white chassis.

6. MAINTENANCE

6.1 Cleaning

- **Exterior:** Use a soft, damp cloth to clean the exterior surfaces. Avoid harsh chemicals.
- **Dust:** Periodically clean dust from the ventilation grilles and internal components using compressed air. Ensure the PC is powered off and unplugged before cleaning.

6.2 Software Updates

Regularly update your Windows operating system, graphics drivers, and other software to ensure optimal performance and security. Windows Update can be accessed via Settings > Windows Update.

7. TROUBLESHOOTING

- **No Power:** Ensure the power cable is securely connected to both the PC and the wall outlet. Check if the wall outlet is functional.
- **No Display:** Verify that the monitor cable is correctly connected to the graphics card and the monitor is powered on and set to the correct input source.
- **No Internet Connection:** For Wi-Fi, ensure the adapter is installed and drivers are up to date. For wired, check the Ethernet cable connection. Restart your router/modem.
- **System Slowdown:** Check for background applications consuming resources. Ensure sufficient free space on the SSD. Run a malware scan.

- **Overheating:** Ensure ventilation openings are clear. Clean dust from inside the PC.

For further assistance, refer to the Vibox support website or contact customer service.

8. SPECIFICATIONS

Component	Detail
Brand	Vibox
Model Number	IV-524
Processor	AMD Ryzen 7 5700X (8 Cores, Max 4.6 GHz)
Graphics Card	NVIDIA GeForce RTX 5060 (8 GB GDDR7, HDMI 2.1, DisplayPort)
RAM	16 GB DDR4 3200 MHz (Dual Channel)
Storage	1 TB SSD (Solid State)
Operating System	Windows 11 Home
Connectivity	Wi-Fi (300 Mbps adapter included)
USB Ports	3x USB 2.0, 3x USB 3.0
HDMI Ports	1
Dimensions (L x W x H)	37 x 20 x 46 cm
Weight	12 kg

PANNEAU FRONTAL RVB À MIROIR INFINI

ESTHÉTIQUE RGB ÉPOUSTOUFLANTE



Image: Diagram illustrating the dimensions of the Vibox IV-524 PC tower: 38cm (depth), 20cm (width), and 46cm (height).






9. WARRANTY AND SUPPORT

Your Vibox IV-524 Gaming PC comes with a manufacturer's warranty. Please refer to the warranty documentation included in your package for specific terms and conditions. For technical support, driver downloads, or further assistance, please visit the official Vibox support website or contact their customer service department.

Vibox Support: [Visit the Vibox Store on Amazon](#)

© 2025 Vibox. All rights reserved.

Related Documents - IV-524

	<p>Vibox IV-544 Gaming PC Quick Start Guide</p> <p>Concise quick start guide for setting up your Vibox IV-544 Gaming PC with Windows 11, including steps for internal checks, display and accessory connections, internet setup, and powering on.</p>
	<p>Vibox I-24 Game PC: Specifications and Features</p> <p>Detailed information about the Vibox I-24 Game PC, featuring an AMD Ryzen 3200G processor, 22-inch display package, and gaming capabilities. Includes specifications, gaming experience, and compliance details.</p>
	<p>EU Declaration of Conformity - Vibox Gaming PC (VIBOX-ZSYS-ZOS-WINDOWS-11)</p> <p>Official EU Declaration of Conformity for the Vibox Gaming PC, model VIBOX-ZSYS-ZOS-WINDOWS-11, confirming compliance with relevant Union harmonisation legislation and standards.</p>
 <p>Obsah</p> <ul style="list-style-type: none"> 01. Úvod 02. Instalace 03. Ovládací prvky 04. Ovládací prvky 05. Ovládací prvky 06. Ovládací prvky 07. Ovládací prvky 08. Ovládací prvky 09. Ovládací prvky 10. Ovládací prvky 11. Ovládací prvky 12. Ovládací prvky 13. Ovládací prvky 14. Ovládací prvky 15. Ovládací prvky 16. Ovládací prvky 17. Ovládací prvky 18. Ovládací prvky 19. Ovládací prvky 20. Ovládací prvky 21. Ovládací prvky 22. Ovládací prvky 23. Ovládací prvky 24. Ovládací prvky 25. Ovládací prvky 26. Ovládací prvky 27. Ovládací prvky 28. Ovládací prvky 29. Ovládací prvky 30. Ovládací prvky 31. Ovládací prvky 32. Ovládací prvky 33. Ovládací prvky 34. Ovládací prvky 35. Ovládací prvky 36. Ovládací prvky 37. Ovládací prvky 38. Ovládací prvky 39. Ovládací prvky 40. Ovládací prvky 41. Ovládací prvky 42. Ovládací prvky 43. Ovládací prvky 44. Ovládací prvky 45. Ovládací prvky 46. Ovládací prvky 47. Ovládací prvky 48. Ovládací prvky 49. Ovládací prvky 50. Ovládací prvky 51. Ovládací prvky 52. Ovládací prvky 53. Ovládací prvky 54. Ovládací prvky 55. Ovládací prvky 56. Ovládací prvky 57. Ovládací prvky 58. Ovládací prvky 59. Ovládací prvky 60. Ovládací prvky 61. Ovládací prvky 62. Ovládací prvky 63. Ovládací prvky 64. Ovládací prvky 65. Ovládací prvky 66. Ovládací prvky 67. Ovládací prvky 68. Ovládací prvky 69. Ovládací prvky 70. Ovládací prvky 71. Ovládací prvky 72. Ovládací prvky 73. Ovládací prvky 74. Ovládací prvky 75. Ovládací prvky 76. Ovládací prvky 77. Ovládací prvky 78. Ovládací prvky 79. Ovládací prvky 80. Ovládací prvky 81. Ovládací prvky 82. Ovládací prvky 83. Ovládací prvky 84. Ovládací prvky 85. Ovládací prvky 86. Ovládací prvky 87. Ovládací prvky 88. Ovládací prvky 89. Ovládací prvky 90. Ovládací prvky 91. Ovládací prvky 92. Ovládací prvky 93. Ovládací prvky 94. Ovládací prvky 95. Ovládací prvky 96. Ovládací prvky 97. Ovládací prvky 98. Ovládací prvky 99. Ovládací prvky 100. Ovládací prvky 	<p>Grand Theft Auto IV: Průvodce hrou a instalací</p> <p>Komplexní průvodce hrou Grand Theft Auto IV, včetně instalačních pokynů, ovládacích prvků pro PC a Xbox 360, přehledu míst ve hře, herních režimů a informací o tvůrcích.</p>
	<p>ETA Gustus IV Kitchen Machine Manual</p> <p>Comprehensive user manual for the ETA Gustus IV kitchen machine (model 4128). Includes safety instructions, usage guides for attachments like whisks, mincers, graters, blenders, maintenance, and technical specifications.</p>