

[Manuals.plus](#) /

› [MERACH](#) /

› MERACH Balancing Machine User Manual

MERACH MR-2416

MERACH Balancing Machine User Manual

Model: SKI_BALANCE_BLACK (MR-2416)

Brand: MERACH

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your MERACH Balancing Machine. The Ski Simulator with Resistance Bands is a portable slide stepper designed for full-body workouts, featuring an LCD monitor and a 300 lbs capacity. It mimics cross-country skiing for a low-impact cardio experience.

2. PRODUCT FEATURES



Effective Cardio Burns: The balance board's silky arcing motion targets thighs and glutes, burning fat faster than traditional steppers. It provides a rhythmic glide for an engaging cardio workout.

Low-Impact High Fun

Ski-Inspired Side Steps for
Knee-Friendly Cardio



Toned Arms



Thin Waist



Slim Legs



Fun Meets Joint Relief: This ski machine mimics cross-country skiing, offering low-impact cardio that is gentle on joints and helps improve balance.

Sweat in Silence

Work Out Anytime Without a Sound



20dB



25dB



40dB




60dB



Quiet & Stable Support: The ski simulator operates at less than 25dB, allowing for discreet workouts. It is constructed with 1.7mm thick steel and supports up to 300 lbs, ensuring safe and steady use.

Visible Calorie Control

Burn fat scientifically with data and diet



Real-Time Feedback: An integrated LCD screen tracks steps, time, and calories, providing immediate feedback to help users adjust their workouts and nutrition.

Easy to Store

Perfect for Home Workout



Easy to Store & Move: This compact unit (31"L x 13"W x 7"H, 10.4 lbs) requires no setup and can be easily stored under a bed, in a closet, or beside a couch, making it convenient for home workouts.

Humanized Design

Optimized Every Hidden Details



Smooth and Silent Pulleys



Anti-slip Foot Covers

Humanized Design: Features smooth and silent pulleys for fluid motion and anti-slip foot covers for enhanced stability during use.

3. SETUP

The MERACH Balancing Machine is designed for immediate use. It comes fully assembled in the box, requiring no complex installation. Simply remove it from its packaging, and it is ready for your workout. The only components that may need to be attached are the resistance bands, which can be easily clipped on to the designated points on the machine.



The machine is ready to use right out of the box, with no installation required.

4. OPERATING INSTRUCTIONS

To begin your workout, place the MERACH Balancing Machine on a stable, flat surface. Step onto the footpads, ensuring your feet are positioned securely. The machine features a side-to-side motion that mimics skiing. You can adjust the intensity by varying the speed and depth of your movements. For a more energizing workout, increase the pace of your glides. The resistance bands can be used simultaneously to engage your upper body and arms, providing a full-body exercise. Monitor your progress using the integrated LCD screen, which displays steps, time, and calories burned.

Important Tip: The MERACH balancing machine features a side-to-side motion that mimics skiing, providing a more energizing workout. If you are new to this type of exercise or have balance issues, we recommend using it with caution and holding onto a stable support initially until you gain confidence.



Engage in a full-body workout by utilizing the side-to-side motion and resistance bands.



Only 12 LBS



Compact & Portable

The compact design allows for exercise anytime, anywhere, including at home or in an office setting.

5. MAINTENANCE

To ensure the longevity and optimal performance of your MERACH Balancing Machine, regular maintenance is

recommended. Keep the machine clean by wiping it down with a damp cloth after each use. Inspect the resistance bands and all moving parts periodically for any signs of wear or damage. Ensure that the pulleys remain smooth and free of debris. Store the machine in a dry, cool place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you encounter any issues with your MERACH Balancing Machine, please refer to the following common troubleshooting tips:

- **LCD Monitor Not Displaying:** Check if the battery needs replacement. Ensure the monitor is securely connected.
- **Unusual Noises During Operation:** Verify that all parts are securely fastened. Check for any foreign objects obstructing the pulleys or moving components.
- **Reduced Smoothness of Movement:** Ensure the machine is on a flat, level surface. Check the pulleys for any dirt or obstruction and clean if necessary.
- **Resistance Bands Issues:** Inspect bands for fraying or damage. Ensure they are correctly clipped onto the machine.

For persistent issues not resolved by these steps, please contact MERACH customer support.

7. SPECIFICATIONS

Item Package Dimensions L x W x H	31 x 14 x 8 inches
Item Dimensions L x W x H	14 x 8 x 31 inches
Item Weight	11 Pounds
Brand Name	MERACH
Model Name	MR-2416
Color	PURPLE
Material	Alloy Steel
Manufacturer	MERACH
Style	SKI_BALANCE_BLACK
Included Components	2 Resistance Bands, SLIDE STEEPER MACHINE, USER MANUAL

8. WARRANTY AND SUPPORT

Your MERACH Balancing Machine comes with a **12 MONTHS** warranty. For any warranty claims or technical

assistance, please contact MERACH customer support. MERACH is committed to providing high-quality and affordable fitness products, and their dedicated R&D team ensures continuous innovation.

For further assistance, please visit the official MERACH store or contact their customer service channels.