

Fastrack 3304KD04

Fastrack Oceanyx-Ceramic Quartz Watch 3304KD04 User Manual

Model: 3304KD04

INTRODUCTION

Thank you for choosing the Fastrack Oceanyx-Ceramic Quartz Watch, Model 3304KD04. This manual provides essential information for the proper setup, operation, maintenance, and care of your new timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.



Image: Front view of the Fastrack Oceanyx-Ceramic Quartz Watch, Model 3304KD04, showcasing its green dial and ceramic strap.

1. SETUP

1.1 Setting the Time

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) to the outermost position.
2. **Set the time:** Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time.
3. **Push in the crown:** Once the time is set, push the crown back into its normal operating position. This will start the watch movement.



Image: Side view of the watch, highlighting the crown used for time adjustment.

1.2 Adjusting the Strap

The watch features a solid strap. For proper fit and comfort, the strap may need adjustment. It is recommended to have strap adjustments performed by a qualified watch technician or an authorized Fastrack service center to prevent damage to the ceramic links.

2. OPERATING YOUR WATCH

2.1 Basic Time Reading

Your Fastrack Oceanyx-Ceramic watch is an analog timepiece, displaying time with hour, minute, and second hands on a round dial. Read the time by observing the position of these hands relative to the hour markers.

2.2 Water Resistance

This watch is water-resistant up to 50 meters (5 ATM). This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. **It is not suitable for swimming, diving, or showering with hot water.** Always ensure the crown is fully pushed in before any contact with water.



Image: Back view of the watch case, showing the "50M WR" (Water Resistant) marking.

3. MAINTENANCE AND CARE

3.1 Cleaning Your Watch

- Wipe the watch case and strap regularly with a soft, dry cloth to remove dust and dirt.
- For more thorough cleaning, a slightly damp cloth can be used, followed by immediate drying with a soft, dry cloth.
- Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish and seals.

3.2 Battery Replacement

Your watch is powered by a quartz movement and requires a battery. When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure the water resistance seal is maintained.

3.3 Mineral Crystal Care

The watch features a durable mineral crystal. While resistant to scratches, it is not scratch-proof. Avoid

contact with sharp or abrasive surfaces to prevent damage to the crystal.

3.4 Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight, extreme temperatures, and strong magnetic fields.

4. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch has stopped or runs intermittently.	Low battery.	Replace the battery at an authorized service center.
Time is incorrect.	Crown is not fully pushed in, or time was set incorrectly.	Ensure the crown is fully pushed in. Re-set the time as per Section 1.1.
Condensation under the crystal.	Exposure to extreme temperature changes or compromised water resistance.	Immediately take the watch to an authorized service center for inspection.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact Fastrack customer support or an authorized service center.

5. SPECIFICATIONS

- Brand:** Fastrack
- Model:** 3304KD04
- Model Name:** Oceanyx - Ceramic
- Display Type:** Analog
- Movement:** Quartz
- Case Material:** Not explicitly stated, but implied ceramic/metal.
- Strap Material:** Ceramic
- Crystal Material:** Mineral Glass
- Water Resistance:** 50 Meters (5 ATM)
- Product Dimensions:** 14 x 10 x 7 cm (packaging dimensions)
- Item Weight:** 250 g
- Batteries:** Yes (Included, Required)
- Country of Origin:** India




Image: Diagram illustrating the watch case size of 44mm, shown in comparison to a standard credit card for scale.

6. WARRANTY INFORMATION

Your Fastrack Oceanyx-Ceramic Quartz Watch comes with a **Two-Year Guarantee** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, normal wear and tear, or battery replacement.

To claim warranty service, please retain your proof of purchase and contact an authorized Fastrack service center.

7. CUSTOMER SUPPORT

For any questions, service requests, or further assistance regarding your Fastrack watch, please contact:

Manufacturer: Titan Company Limited

Address: #3, SIPCOT Industrial Complex, Hosur - 635126, Tamil Nadu, India

Please refer to the official Fastrack website or your purchase documentation for the most current contact information and service center locations.

