

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Smoby](#) /

› [Smoby Black+Decker Bricolo Builder Workbench Instruction Manual](#)

Smoby 7600360741

Smoby Black+Decker Bricolo Builder Workbench Instruction Manual

Model: 7600360741

1. IMPORTANT SAFETY WARNINGS

WARNING! Not suitable for children under 3 years of age. Minimum age recommendation is 36 months. This product contains small parts which may present a choking hazard.

Adult supervision is recommended during play, especially during initial assembly and use.

2. PRODUCT OVERVIEW

The Smoby Black+Decker Bricolo Builder Workbench is an imitation toy designed to provide a comprehensive and engaging play experience for young builders. It allows children to mimic real-life construction activities and develop various skills.

This workbench is made in France, utilizing at least 60% recycled plastic material, reflecting a commitment to environmental responsibility.

Key Features:

- **Extensive Accessory Set:** Includes 87 accessories for diverse play scenarios.
- **7 Black+Decker Tools:** Features a saw, hammer, flat wrench, screwdriver, pliers, square, and vice.
- **Mechanical Screwdriver:** A mini mechanical screwdriver for realistic building.
- **Functional Crane:** A working crane to lift and move objects.
- **Vehicle Construction Set:** Components to build a toy vehicle.
- **Tap/Tap Nail Function:** An interactive feature for hammering play.
- **Integrated Storage:** Large storage areas to keep all accessories organized.



Image 2.1: The Smoby Black+Decker Bricolo Builder Workbench, showcasing its various features and a child engaged in play.

Included Accessories:

The workbench comes with a comprehensive set of 87 accessories, including:

- 7 Black+Decker branded tools: saw, hammer, flat wrench, screwdriver, pliers, square, vice.
- 1 mini mechanical screwdriver.
- Crane components.
- Various screws, nuts, and nails.
- Construction boards and vehicle parts.
- Storage bins.



Image 2.2: A detailed view of all 87 accessories included with the workbench, such as tools, screws, nuts, and construction pieces.

3. SETUP AND ASSEMBLY

The Smoby Black+Decker Bricolo Builder Workbench requires assembly. Please follow the detailed assembly instructions provided in the separate instruction leaflet included in the product packaging. Ensure all parts are present before beginning assembly.

General Assembly Steps:

- 1. Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify against the parts list in the included manual.
- 2. Assemble Base Structure:** Connect the main workbench legs and base according to the diagrams.
- 3. Attach Workbench Top:** Secure the main work surface to the base.
- 4. Install Back Panel and Tool Holders:** Mount the back panel and attach the various tool holders and storage bins.
- 5. Assemble Crane:** Follow the instructions to build and attach the functional crane to the workbench.
- 6. Place Accessories:** Organize the tools, screws, nuts, and other accessories into their designated storage

areas.

Ensure all connections are secure before allowing children to play with the workbench.

4. OPERATING INSTRUCTIONS

The Bricolo Builder Workbench offers various interactive elements for imaginative play. Encourage children to explore and create.

Using the Tools:

- **Hammer:** Use the hammer with the included nails and the 'tap/tap nail' function on the workbench surface.
- **Screwdriver & Wrench:** Practice fastening and unfastening screws and nuts using the screwdriver and flat wrench with the construction pieces.
- **Saw:** Pretend to cut the construction boards with the toy saw.
- **Pliers & Square:** Use these tools for various imaginative tasks, such as gripping or measuring.
- **Vice:** Secure small construction pieces in the vice for more stable 'working'.



Image 4.1: A child demonstrating the use of the toy drill, an essential tool for construction play.

Operating the Crane:

The workbench features a manual crane. Children can use the crank to raise and lower the hook, simulating lifting and moving materials around the construction site. The crane can rotate to transport items from one area to another.



Image 4.2: A child actively engaging with the functional crane feature of the workbench, lifting a toy object.

Building a Vehicle:

Use the provided construction boards, screws, and nuts to assemble the toy vehicle. This activity encourages problem-solving and fine motor skills.

5. MAINTENANCE

To ensure the longevity and hygiene of the Smoby Black+Decker Bricolo Builder Workbench, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down all surfaces with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals, as they may damage the plastic.
- **Drying:** Ensure all parts are completely dry before storing or allowing continued play to prevent moisture buildup.
- **Storage:** Store the workbench and its accessories in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Inspection:** Periodically check all connections, screws, and moving parts (like the crane mechanism) to ensure they are secure and functioning correctly. Tighten any loose screws as needed.

6. TROUBLESHOOTING

If you encounter any issues with your Smoby Black+Decker Bricolo Builder Workbench, please refer to the following common solutions:

- **Missing Parts:** If any parts are missing upon unboxing, please refer to the parts list in the assembly manual and contact Smoby customer support for assistance.
- **Difficulty Assembling:** Double-check the assembly instructions and diagrams. Ensure all pieces are oriented correctly and that you are using the appropriate fasteners. Do not force parts together.
- **Crane Not Functioning Smoothly:** Inspect the crane mechanism for any obstructions or misaligned parts. Ensure the string is properly threaded and not tangled.
- **Loose Connections:** If the workbench feels wobbly, check all screws and connections and tighten them securely.

7. SPECIFICATIONS

Product Dimensions (L x W x H)	36 x 57.5 x 101.6 cm
Product Weight	3.15 kg
Recommended Age	36 months - 12 years
Model Number	7600360741
Educational Value	Creative thinking, Imagination development, Hand-eye coordination, Concentration, Logical thinking, Motor skills
Assembly Required	Yes
Batteries Required	No
Main Material	Plastic (at least 60% recycled)
Color	Multicolor
Country of Origin	France




Image 7.1: Dimensional diagram of the workbench, indicating its height, width, and depth.

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Smoby Black+Decker Bricolo Builder Workbench, please contact Smoby customer service. Details for contacting support are typically found on the product packaging or on the official Smoby website.

Please retain your proof of purchase for any warranty claims or support inquiries.

