

Manuals.plus /

- › Fossil /
- › Fossil Pearson Multifunction Watch (Model FS6138) User Manual

## Fossil FS6138

# Fossil Pearson Multifunction Watch (Model FS6138) User Manual

Your guide to setting up, operating, and maintaining your Fossil timepiece.

## INTRODUCTION

---

Thank you for choosing a Fossil watch. The Fossil Pearson Multifunction Watch (Model FS6138) combines classic design with practical features, including day, date, and 24-hour sub-dials. This manual provides essential information to ensure proper use and care of your watch.

## SETUP

---

### 1. Setting the Time

1. Pull the crown (the knob on the side of the watch) out to position 2.
2. Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time. Ensure the AM/PM is correctly set, especially when setting the date.
3. Once the time is set, push the crown back into position 0.





**Image:** Side view of the Fossil Pearson watch, highlighting the crown used for setting the time and date.

## **2. Setting the Date and Day**

1. Pull the crown out to position 1.
2. Turn the crown clockwise to adjust the date sub-dial.

3. Turn the crown counter-clockwise to adjust the day sub-dial.
4. Once the date and day are set, push the crown back into position 0.



**Image:** Close-up of the watch face, showing the day, date, and 24-hour sub-dials.

### 3. Adjusting the Leather Strap

The genuine leather strap is designed for self-adjustment. Use the buckle to find a comfortable and secure fit on your wrist. Ensure the watch is not too tight to allow for proper circulation.

## OPERATING YOUR WATCH

---

### Multifunction Dials

- **Day Sub-dial:** Indicates the current day of the week (e.g., MON, TUE).
- **Date Sub-dial:** Displays the current day of the month.
- **24-Hour Sub-dial:** Shows the current time in a 24-hour format, useful for distinguishing AM/PM.

The watch features luminous hands and markers for improved visibility in low-light conditions.



**Image:** The watch face displaying luminous hands and hour markers in a dark environment.

## MAINTENANCE AND CARE

---

## Cleaning

To maintain the appearance of your watch, wipe the case and crystal with a soft, dry cloth. For the leather strap, avoid prolonged exposure to water and direct sunlight to prevent damage and discoloration.

## Water Resistance

This watch is water resistant up to 50 meters (5 ATM or 165 feet). This means it is suitable for short periods of recreational swimming and showering. It is **not** suitable for diving, snorkeling, or high-impact water sports. Always ensure the crown is fully pushed in before any water exposure.

## Battery Replacement

Your watch is powered by one A battery (included). When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure the water resistance seal is maintained.

## TROUBLESHOOTING

---

### Watch Not Running or Stopping Intermittently

- **Check the Crown:** Ensure the crown is fully pushed into position 0. If it is pulled out, the watch will not run.
- **Battery Life:** The battery may need replacement. Refer to the 'Battery Replacement' section.
- **Impact:** If the watch has experienced a significant impact, internal components may be damaged. Contact customer support for service.

### Dials Difficult to Read

The sub-dials for day and date are designed for compact integration within the watch face. If you find them difficult to read, this is a characteristic of the watch's design. Ensure adequate lighting when checking these features.

## SPECIFICATIONS

---

Feature	Detail
Model Name	Pearson
Model Number	FS6138
Case Material	Stainless Steel
Band Material	Leather
Case Diameter	42 Millimeters
Band Width	22 Millimeters
Case Thickness	12 Millimeters
Band Length	200 Millimeters
Movement Type	Quartz
Display Type	Analog
Crystal Type	Mineral (Scratch-Resistant)
Water Resistance Depth	50 Meters (5 ATM)
Power Source	Battery Powered (1 A battery included)
Item Weight	71.3 Grams
UPC	807320012115



**Image:** Rear view of the watch case, displaying the model number FS6138 and other engravings.

