

feekaa FK-BB-05

Feekaa 1L Electric Glass Kettle Instruction Manual

Brand: Feekaa | Model: FK-BB-05

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Feekaa 1L Electric Glass Kettle. This appliance is designed to provide precise temperature control for various beverages, including tea, coffee, and milk. Its features include a removable infuser, a 72-hour keep warm function, and multiple safety devices, ensuring a convenient and safe user experience.

Key Features:

- **4 Preset Temperatures:** Optimized settings for different tea types, milk, and coffee.
- **Precise Temperature Adjustment:** Control temperature within $\pm 1^{\circ}\text{C}$, from 37°C to 95°C .
- **1L Large Capacity:** Suitable for family use.
- **72-Hour Keep Warm Function:** Maintains desired temperature for extended periods.
- **Removable 304 Stainless Steel Infuser:** For brewing loose leaf tea and easy cleaning.
- **Memory Feature:** Allows kettle removal without entering standby mode.
- **Dechlorination Mode:** Boils continuously at 100°C for 3 minutes to reduce residual chlorine.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the kettle and retain them for future reference. Improper use can result in electric shock, fire, or serious injury.

- Do not immerse the power base, cord, or plug in water or other liquids.
- Ensure the kettle is placed on a stable, flat, heat-resistant surface, away from the edge of the countertop.
- Do not operate the kettle if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Keep the appliance out of reach of children. Close supervision is necessary when the appliance is used by or near children.
- Do not touch hot surfaces. Use handles or knobs.
- Always unplug the kettle from the outlet when not in use and before cleaning. Allow it to cool before putting on or taking off parts, and before cleaning the appliance.

- Do not use the kettle for anything other than its intended use.
- Only use the kettle with the provided power base.
- Avoid filling above the maximum fill line to prevent boiling water overflow.
- The kettle is equipped with multiple safety devices including overheat protection, auto shutdown, and anti-dry burning.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Feekaa Electric Glass Kettle:

- **Borosilicate Glass Kettle Body:** Odor-free and easy to clean.
- **304 Stainless Steel Inner Lid:** High temperature resistant and easy to clean.
- **304 Stainless Steel Tea Infuser:** Removable and stain-resistant for brewing.
- **Burn-Preventing Handle:** Ergonomically designed for safe handling.
- **High-Temperature Resilient Base:** Contains precise temperature and time controls.
- **Control Panel:** Digital display with buttons for settings.
- **Clearly Visible Water Level Line:** For accurate filling.




Figure 3.1: Exploded view of the Feekaa Electric Kettle components, highlighting the glass body, stainless steel infuser, lid, handle, and control base.

4. SETUP

1. **Unpack:** Carefully remove all packaging materials and inspect the kettle for any damage.
2. **Initial Cleaning:** Before first use, fill the kettle with water to the maximum level. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Place on Base:** Place the kettle securely on its power base on a dry, flat, and stable surface.
4. **Connect Power:** Plug the power cord into a grounded electrical outlet.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

1. **Fill Kettle:** Open the lid and fill the kettle with the desired amount of water. Do not exceed the MAX fill line or go below the MIN fill line.
2. **Close Lid:** Ensure the lid is securely closed.

3. **Power On:** Press the power button (U) on the control panel to turn on the kettle. The display will illuminate.

5.2 Temperature Control and Presets

The kettle offers 4 preset temperature settings and a custom adjustment range.



Figure 5.1: Control panel with preset temperature options for various beverages.

- **Preset Selection:** Press the corresponding preset buttons (45°C for Milk, 70°C for Tea, 90°C for Coffee, 100°C for Boiling) on the control panel. The kettle will automatically heat to the selected temperature.
- **Custom Temperature Adjustment:** For temperatures between 37°C and 95°C, use the "+" and "-" buttons to set the desired temperature in 1°C increments. The LCD display shows the real-time and preset temperature.

5.3 Using the Removable Infuser

The kettle includes a 304 stainless steel infuser for brewing loose leaf tea or other infusions.

1. Place your loose leaf tea or ingredients into the infuser.
2. Insert the infuser into the kettle, ensuring it is properly seated.
3. Fill the kettle with water and select your desired temperature setting.
4. Once brewing is complete, carefully remove the infuser using its handle.

5.4 72-Hour Keep Warm Function

The kettle can maintain your desired beverage temperature for up to 72 hours.



Figure 5.2: The kettle's 72-hour automatic keep warm function.

After reaching the set temperature, the kettle will automatically activate the keep warm function. The display will show the current temperature and the remaining keep warm time. You can adjust the keep warm duration using the time control buttons if available, or simply let it run for the default 72 hours.

5.5 Memory Feature

The convenient memory feature allows you to lift the kettle from its base without interrupting the current heating or keep warm cycle. When the kettle is returned to the base, it will resume its previous operation without needing to re-enter settings.



Figure 5.3: The memory feature allows seamless kettle removal and return.

5.6 Dechlorination Mode

To reduce residual chlorine in tap water, the kettle features a dechlorination mode.



Figure 5.4: Dechlorination mode, which boils water continuously at 100°C for 3 minutes to remove residual chlorine.

In addition to standard boiling, the kettle can boil water continuously at 100°C for 3 minutes. This mode effectively removes chlorine that cannot be fully eliminated by simply bringing water to a boil. This function is especially recommended in areas with high residual chlorine levels.

5.7 Official Product Video

Your browser does not support the video tag.

Video 5.5: An official product video demonstrating the Feekaa Electric Kettle's features, including custom settings and brewing various beverages.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your kettle.

6.1 General Cleaning

- Always unplug the kettle and allow it to cool completely before cleaning.
- The kettle body and infuser are designed for hand washing. Do not wash the power base in water.
- Wipe the exterior of the kettle and power base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- The wide opening design of the kettle allows for easy access to the interior for thorough cleaning.

How to Remove Water Stains



Add the right amount of water to the kettle. Add the right amount of citric acid or vinegar and stir.



Boil the water. After the water in the kettle boils, let it sit for about 2 hours.



After removing the scale from the kettle, pour out the hot water, then add an appropriate amount of water again, heat it up and pour it out once more to complete the cleaning.

White stains on the inside of the kettle are hardening of the mineral content of the water and are not harmful to your health. Water stains also vary from region to region (water quality). Clean it regularly.

Figure 6.1: The kettle's wide opening facilitates easy hand washing and cleaning of the interior.

6.2 Removing Water Stains (Descaling)

Mineral deposits from water can accumulate inside the kettle over time. These stains are not harmful but can affect performance. To remove them:

All-Around Safety

Approved food-grade stainless steel and glass throughout the kettle, ensuring safety from top to bottom.



304 Stainless Steel Tea Infuser
Removable and Stain-Resistant

304 Stainless Steel Inner Lid
High Temperature Resistant and Easy to Clean

High Borosilicate Glass Body
Odor-Free and Easy to Clean

Figure 6.2: Step-by-step instructions for descaling the kettle using citric acid or vinegar.

1. Add the right amount of water to the kettle. Add the right amount of citric acid or vinegar and stir.
2. Boil the water. After the water in the kettle boils, let it sit for about 2 hours.
3. After removing the scale from the kettle, pour out the hot water, then add an appropriate amount of water again, heat it up and pour it out once more to complete the cleaning.

Note: White stains inside the kettle are hardening of mineral content and are not harmful. Water stains vary by region (water quality). Clean regularly.

7. TROUBLESHOOTING

If you encounter issues with your Feekaa Electric Glass Kettle, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Kettle does not turn on.	No power, kettle not properly seated on base.	Check if the power cord is securely plugged in. Ensure the kettle is correctly placed on the power base.
Water is not heating.	Kettle is dry-boiled, heating element malfunction.	Unplug the kettle, let it cool down, then refill with water and try again. If the issue persists, contact customer support.
"E1" error code displayed.	Kettle not firmly seated, connection issue between kettle and base.	Ensure the kettle is firmly seated on the base. Check for any debris on the electrical contacts. If the error persists, contact customer support.
Temperature is inaccurate or inconsistent.	Sensor issue, mineral buildup.	Perform descaling as described in Section 6.2. If the problem continues, contact customer support.
Kettle boils to 100°C then cools when a lower preset is selected.	Potential unit defect (as reported by some users).	Ensure you are using the correct preset or custom temperature setting. If the issue persists, especially with preset temperatures, contact customer support for assistance.

For issues not listed here, or if troubleshooting steps do not resolve the problem, please contact Feekaa customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	feekaa
Model Name	FK-BB-05
Capacity	1 Litre
Material	Glass (Borosilicate), 304 Stainless Steel
Colour	Black
Voltage	120 Volts
Wattage	600 Watts
Product Dimensions (L x W x H)	18L x 18W x 29H Centimetres
Special Feature	Removable Filter, Temperature Control, Keep Warm Function

Feature	Detail
Included Components	Electric kettle
Product Care Instructions	Hand Wash

9. WARRANTY AND SUPPORT

Feekaa offers a **30-day replacement policy** and a **12-month guarantee** for this product. Please retain your proof of purchase for warranty claims.

For technical support, warranty claims, or any questions regarding your Feekaa Electric Glass Kettle, please contact Feekaa customer service through the retailer where you purchased the product or refer to the contact information provided in your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question