

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [YIDPU](#) /

› YIDPU CL-001 Digital Alarm Clock with 15W Wireless Charging and RGB Nightlight User Manual

## YIDPU CL-001

# YIDPU CL-001 Digital Alarm Clock with 15W Wireless Charging and RGB Nightlight User Manual

Model: CL-001

## 1. PRODUCT OVERVIEW

---

The YIDPU CL-001 is a versatile digital alarm clock designed for modern bedrooms. It combines a clear time display with a 15W fast wireless charging pad, an RGB nightlight, and multiple alarm functions. This manual provides detailed instructions for its proper use and maintenance.



Figure 1: The YIDPU CL-001 alarm clock features a 15W wireless charging pad on its top surface, allowing compatible smartphones to charge by simply placing them on the device.

## 2. PACKAGE CONTENTS

- YIDPU CL-001 Digital Alarm Clock
- Type-C Charging Cable
- Instruction Manual
- Power Adapter (provided)

## 3. SETUP

### 3.1 Initial Power-Up

1. Connect the provided Type-C cable to the clock's Type-C interface (refer to Figure 4 for location).
2. Plug the other end of the cable into the power adapter, and then into a wall outlet.
3. The display will illuminate, indicating the clock is powered on.

### 3.2 Battery Backup

The clock uses a CR2032 button battery (not included) for time and setting memory backup during power outages. To install or replace the battery:

1. Locate the battery cover on the bottom of the unit.
2. Use a small screwdriver to turn the battery cover slot to the left and remove the cover.
3. Insert one CR2032 battery with the positive (+) side facing up.
4. Replace the battery cover and turn the slot to the right to secure it.



Figure 4: This image provides a closer look at the clock's design elements, including the textured top, the Type-C power input, and the discreetly placed control buttons for various functions.

## 4. OPERATING INSTRUCTIONS

### 4.1 Time Setting

In normal display mode:

1. Short press the "S" key (located on the bottom) to enter time setting mode. The hour display will flash.
2. Use the "^" (Up) and "V" (Down) keys (located on the bottom) to adjust the hour.
3. Short press "S" again to move to minute setting. Adjust minutes using "^" and "V".
4. Continue pressing "S" to cycle through year, month, and day settings, adjusting each with "^" and "V".
5. After setting the date, short press "S" to exit, or wait 60 seconds for automatic exit.

## 4.2 Alarm Setting

The clock features 8 alarm tones and a customizable snooze duration.

1. In normal display mode, long press the "M" key (located on the bottom) to enter alarm clock setting mode.
2. Short press "M" to cycle through hour, minute, snooze time, alarm tone, and alarm activation/deactivation.
3. Use the "^" and "V" keys to adjust each parameter.
4. The snooze time is adjustable from 1 to 60 minutes (default is 5 minutes).
5. After setting, short press "M" to exit, or wait 60 seconds for automatic exit.

## 4.3 Snooze Function

When the alarm sounds, press the large "SNOOZE" button on top of the clock to activate snooze. The alarm will temporarily pause and sound again after the set snooze duration.

## 4.4 15W Fast Wireless Charging

The top surface of the clock features a 15W Qi-compatible wireless charging pad.

1. Place your Qi-compatible smartphone or earbuds on the center of the charging pad.
2. A green indicator light will illuminate for 1 second when charging begins.
3. A red indicator light will remain on during charging, turning green when fully charged.



Figure 5: The integrated 15W wireless charging pad provides convenient power for compatible devices, eliminating

cable clutter.

#### 4.5 RGB Nightlight Function

The clock features an RGB nightlight with multiple color modes.

1. Short press the light icon button (located on the top left) to turn on the color light and cycle through modes: Solid Color, Gradient Flow, Dynamic Chase.
2. Long press the light icon button to turn off the color light.
3. The night light and the color light cannot be active simultaneously.



Figure 6: The clock's RGB lighting can be controlled via touch, offering three distinct modes: Solid Color, Gradient Flow, and Dynamic Chase, to suit various preferences.

#### 4.6 Display Brightness Adjustment

The display brightness can be adjusted to suit your preference.

1. In normal running state, short press the "SNOOZE" button (located on top) to cycle through the backlight modes: High brightness, Medium brightness, Off.

## Display screen brightness adjustment

The brightness of the three display screens can be freely switched to meet various needs



Highlight



Low brightness



OFF

Figure 7: The digital display offers three adjustable brightness levels (High, Medium, Off) to ensure optimal visibility day or night without causing disturbance.

## 5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the clock. Avoid using abrasive cleaners or solvents.
- **Placement:** Place the clock on a stable, flat surface. Avoid direct sunlight, high temperatures, or humid environments.
- **Handling:** Do not disassemble or attempt to repair the device yourself. Refer to qualified service personnel for any issues.

## 6. TROUBLESHOOTING

- **Clock not turning on:** Ensure the Type-C cable is securely connected to both the clock and the power adapter, and the adapter is plugged into a working power outlet. Check if the battery backup is installed correctly.
- **Wireless charging not working:** Verify that your device is Qi-compatible and properly centered on the charging pad. Remove any thick phone cases that might interfere with charging. Ensure the clock is powered on.

- **Display too dim/bright:** Adjust the display brightness using the "SNOOZE" button as described in Section 4.6.
- **Alarm not sounding:** Check that the alarm is set correctly and activated in the alarm settings (Section 4.2). Ensure the volume is not set to minimum.

## 7. SPECIFICATIONS

---

Feature	Detail
Brand	YIDPU
Model Number	CL-001
Color	Black
Display Type	Digital
Special Feature	Alarm, 15W Wireless Charging, RGB Nightlight
Product Dimensions	4.6"W x 6.4"H
Power Source	Corded Electric
Room Type	Bedroom
Indoor/Outdoor Usage	Indoor
Frame Material	Plastic
Batteries Included	No (CR2032 for backup, not included)
Item Weight	13.28 ounces

## 8. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the product packaging or contact YIDPU customer service directly. Keep your purchase receipt for warranty claims.