

[manuals.plus](#) /› [memzuoix](#) /› [memzuoix Ergonomic Vertical Wireless Mouse \(Model WM-791\) User Manual](#)

memzuoix WM-791

memzuoix Ergonomic Vertical Wireless Mouse (Model WM-791) User Manual

Your guide to setup, operation, and maintenance.

INTRODUCTION

The memzuoix Ergonomic Vertical Wireless Mouse is designed to provide a comfortable and natural hand position, reducing wrist and arm strain during extended use. This 2.4G optical cordless mouse features adjustable DPI levels and multiple buttons for enhanced productivity. This manual provides essential information for setting up, operating, and maintaining your mouse.

PACKAGE CONTENTS

- Ergonomic Vertical Wireless Mouse
- USB 2.0 Receiver
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your memzuoix Ergonomic Vertical Wireless Mouse.



Image: Multiple views of the memzuoix vertical mouse, highlighting the DPI button, scroll wheel, left and right click buttons, previous and next page buttons, and the textured thumb area for grip.

SETUP INSTRUCTIONS

1. Battery Installation

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery cover.
3. Insert two AAA batteries (not included) according to the polarity indicators inside the compartment.
4. Close the battery cover securely.



Image: The underside of the mouse with the battery compartment open, illustrating where to insert two AAA batteries and the location of the USB receiver storage.

2. Connecting the USB Receiver (Plug-and-Play)

1. Locate the USB receiver, typically stored within the battery compartment of the mouse.
2. Remove the USB receiver from its storage slot.
3. Plug the USB receiver into an available USB port on your computer (PC, laptop, or desktop).
4. Turn on the mouse using the ON/OFF switch located on the underside.
5. Your computer should automatically detect and install the necessary drivers. The mouse is ready for use.



2.4GHz Wireless Transmission

Up To 43.0 Teet

Image: The memzuoix vertical mouse positioned next to a laptop, with its USB receiver clearly shown plugged into a USB port, demonstrating the plug-and-play setup.

Setup Demonstration Video


Video: A demonstration of the memzuoix 2.4G Optical Cordless Mouse, showcasing its features and setup process.

OPERATING INSTRUCTIONS

Ergonomic Design

The vertical design of this mouse promotes a natural "handshake" posture, which helps to alleviate pressure in the wrist joint and reduces the risk of cramping and discomfort during prolonged computer use.

ALL DAY COMFORT



Smooth Silky and Comfortable



Textures
Anti-slip Silicone

Image: A visual comparison illustrating the natural hand position with a vertical ergonomic mouse versus the twisted wrist position with a traditional flat mouse.

DPI Adjustment

The mouse features a dedicated DPI button, allowing you to switch between three sensitivity levels: 800, 1200, and 1600 DPI. Press the DPI button (located near the scroll wheel) to cycle through these settings and find the precision that best suits your task.

Multi-functional Buttons

In addition to the standard left and right click buttons and scroll wheel, the mouse includes forward and back buttons located on the side. These buttons enhance navigation in web browsers and file explorers.

Note: Forward/back buttons are not compatible with Mac OS.

Auto-Sleep Function

To conserve battery life, the mouse will automatically enter sleep mode after 7 minutes of inactivity. To wake the mouse, simply click any button.

MAINTENANCE

- Cleaning:** Use a soft, dry cloth to clean the mouse. Avoid using harsh chemicals or abrasive

materials.

- **Battery Replacement:** Replace AAA batteries when the mouse performance degrades or stops responding.
- **Storage:** When not in use for extended periods, turn off the mouse using the ON/OFF switch and store the USB receiver in its designated compartment.

TROUBLESHOOTING

- **Mouse not responding:**

- Ensure the mouse is turned ON.
- Check if the batteries are correctly installed and have sufficient charge. Replace if necessary.
- Verify that the USB receiver is securely plugged into a working USB port on your computer.
- Try plugging the USB receiver into a different USB port.

- **Cursor movement is erratic or slow:**

- Clean the optical sensor on the underside of the mouse.
- Ensure you are using the mouse on a suitable surface (non-reflective, opaque).
- Adjust the DPI setting using the DPI button to a higher or lower sensitivity.

- **Wireless connection issues:**

- Move the mouse closer to the USB receiver.
- Avoid using the mouse near other wireless devices that may cause interference.

SPECIFICATIONS

Model Number	WM-791
Brand	memzuoix
Connectivity Technology	2.4G Wireless (USB Receiver)
Movement Detection Technology	Optical
DPI Levels	800 / 1200 / 1600
Number of Buttons	6 (Left, Right, Scroll Wheel, DPI, Forward, Back)
Power Source	2 x AAA Batteries (not included)
Item Weight	3.9 ounces
Dimensions	5 x 3.27 x 2.91 inches

COMPATIBILITY

The memzuoix Ergonomic Vertical Wireless Mouse is compatible with a wide range of operating systems, including:

- Windows 8/9/10/XP

- Vista
- Linux (software setup may be required)

Note: Forward/back buttons are not compatible with Mac OS.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official memzuoix website. Keep your purchase receipt for warranty claims.

© 2025 memzuoix. All rights reserved.