

LEFXMOPHY RC923A FMB1 / RC813A FMB1 Compatible

LEFXMOPHY Silicone Remote Cover User Manual

Model: RC923A FMB1 / RC813A FMB1 Compatible

INTRODUCTION

This manual provides essential information for the proper use and maintenance of your LEFXMOPHY Silicone Remote Cover. Designed specifically for the 2025 TCL RC923A FMB1 and RC813A FMB1 QM6K QM7K TV remotes, this cover offers protection and enhanced usability.

PRODUCT FEATURES

- **Precise Fit:** Custom-designed for 2025 TCL RC923A FMB1 and RC813A FMB1 QM6K QM7K TV remotes, ensuring full access to all buttons, ports, and functions.
- **High-Quality Silicone Material:** Made from environmentally friendly, soft, and lightweight silicone, providing a comfortable grip and skin-friendly feel.
- **Enhanced Protection:** Shields your remote from accidental slips, cracks, scratches, and dust. The elastic silicone material offers shock absorption.
- **Glow-in-the-Dark Functionality:** The luminous material glows in the dark after being exposed to light for a few minutes, making your remote easier to locate in low-light conditions. The longer the exposure time, the brighter the glow.
- **Washable:** The cover is washable, allowing for easy cleaning and maintaining its new appearance even after prolonged use.

SETUP AND INSTALLATION

Installing the LEFXMOPHY Silicone Remote Cover is a straightforward process.

1. Ensure your TCL RC923A FMB1 or RC813A FMB1 remote control is clean and free of debris.
2. Align the top of the silicone cover with the top of your remote control.
3. Gently slide the remote control into the silicone cover, ensuring all buttons and ports align with the corresponding openings in the cover.
4. Adjust the cover as needed to ensure a snug and secure fit.

Easy To Install

No need for complicated processes, installation and removal in one step.




Figure 1: Easy installation process of the silicone cover.

OPERATING INSTRUCTIONS

Once installed, the silicone cover does not interfere with the normal operation of your remote control. All buttons remain fully accessible and functional.

- **Glow Function:** To activate the glow-in-the-dark feature, expose the cover to a light source (e.g., room light, sunlight) for several minutes. The longer the exposure, the brighter and longer the glow will last.
- **Protection:** The cover provides a protective layer against everyday wear and tear, accidental drops, and spills.



Figure 2: The silicone cover with glow-in-the-dark functionality.

MAINTENANCE

Maintaining your LEFXMOPHY Silicone Remote Cover is simple and helps prolong its lifespan and appearance.

- **Cleaning:** The silicone cover is washable. To clean, remove the remote control from the cover. Wash the cover with mild soap and water. Rinse thoroughly and allow it to air dry completely before re-installing the remote.
- **Discoloration:** The material is designed to resist yellowing and discoloration, ensuring it stays like new even after prolonged use.

Easy To Clean

No yellowing or discoloration, stains wash off easily, stays like new even after prolonged use.



Figure 3: The washable design of the silicone cover for easy cleaning.

TROUBLESHOOTING

If you encounter any issues with your silicone remote cover, refer to the following common solutions:

Problem	Possible Cause	Solution
Cover does not glow in the dark.	Insufficient light exposure.	Expose the cover to a bright light source for a longer duration (e.g., 5-10 minutes) before placing it in the dark.
Cover does not fit the remote properly.	Incorrect remote model or improper installation.	Verify your remote is a 2025 TCL RC923A FMB1 or RC813A FMB1 QM6K QM7K model. Re-install the cover, ensuring it is aligned correctly.
Buttons are difficult to press.	Cover is not fully seated or misaligned.	Adjust the cover to ensure all button cutouts are perfectly aligned with the remote's buttons.

SPECIFICATIONS

- **Material:** High-Quality Silicone
- **Color:** Lime Green
- **Compatible Models:** 2025 TCL RC923A FMB1, RC813A FMB1 QM6K QM7K TV Remotes
- **Dimensions (Package):** 8.78 x 2.6 x 0.59 inches
- **Item Weight:** 1.06 ounces
- **Special Features:** Glow-in-the-dark, Shockproof, Washable, Skin-friendly

WARRANTY AND SUPPORT

For any questions, concerns, or warranty inquiries regarding your LEFXMOPHY Silicone Remote Cover, please contact LEFXMOPHY customer support. Refer to your purchase documentation for specific warranty terms and contact information.

Manufacturer: LEFXMOPHY

First Available: June 12, 2025

For further assistance, please visit the official LEFXMOPHY support page or contact their customer service directly.

© 2025 LEFXMOPHY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

