

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PocBuds](#) /

› [PocBuds Open Ear Headphones User Manual](#)

PocBuds B0FCYBVL55

PocBuds Open Ear Headphones User Manual

Model: B0FCYBVL55

1. INTRODUCTION

Thank you for choosing PocBuds Open Ear Headphones. This manual provides essential information for the proper setup, operation, and maintenance of your device. Please read it carefully before use and retain it for future reference.

2. PACKAGE CONTENTS

- PocBuds Open Ear Headphones (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual



Image: PocBuds Open Ear Headphones, showing both earbuds with earhooks and the accompanying black zippered charging case.

3. SETUP

3.1 Initial Charging

1. Place both earbuds into the charging case.
2. Connect the USB charging cable to the charging case and a power source.
3. The indicator lights on the earbuds and/or case will illuminate to show charging status. Allow approximately 1-2 hours for a full charge.

3.2 Bluetooth Pairing

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing LED light (usually blue or red/blue alternating).
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. Select "PocBuds" from the list.
5. Once connected, the LED indicator on the earbuds will stop flashing or show a solid light.
6. If prompted for a password, enter "0000" (four zeros).

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- **Power On:** Open the charging case, and the earbuds will power on automatically. Alternatively, press and hold the multi-function button on each earbud for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically. Alternatively, press and hold the multi-function button on each earbud for 5 seconds.

4.2 Music Playback

- **Play/Pause:** Single tap the multi-function button on either earbud.
- **Next Track:** Double tap the multi-function button on the right earbud.
- **Previous Track:** Double tap the multi-function button on the left earbud.
- **Volume Up:** Triple tap the multi-function button on the right earbud.
- **Volume Down:** Triple tap the multi-function button on the left earbud.

4.3 Call Management

- **Answer/End Call:** Single tap the multi-function button on either earbud.
- **Reject Call:** Press and hold the multi-function button on either earbud for 2 seconds.

4.4 Voice Assistant

- **Activate Voice Assistant:** Press and hold the multi-function button on either earbud for 2 seconds (when not on a call).

5. MAINTENANCE

5.1 Cleaning

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- The earbuds are sweatproof, but avoid submerging them in water.

5.2 Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid storing in extreme temperatures or high humidity.

5.3 Battery Care

- To prolong battery life, charge the earbuds regularly, even if not used frequently.
- Avoid completely draining the battery before recharging.

6. TROUBLESHOOTING

- **Earbuds not pairing:**
Ensure both earbuds are charged. Place them back in the case, close the lid, wait a few seconds, then open the lid again to re-enter pairing mode. Forget "PocBuds" from your device's Bluetooth list and try pairing again.
- **Only one earbud working:**
Ensure both earbuds are charged. Try resetting the earbuds by placing them in the case, then removing them. If the issue persists, try re-pairing them with your device.

- **No sound:**

Check the volume level on both your device and the earbuds. Ensure the earbuds are properly connected to your device. Try playing audio from a different application or source.

- **Charging issues:**

Ensure the charging cable is securely connected to both the case and the power source. Try using a different USB port or charging cable. Clean the charging contacts on the earbuds and inside the case with a dry cotton swab.

7. SPECIFICATIONS

Model	B0FCYBVL55
Brand	PocBuds
Connectivity	Bluetooth
Design	Open Ear, Earhook
Playtime	Up to 80 hours (with charging case)
Water Resistance	Sweatproof
UPC	722549919413
Manufacturer	PocBuds

8. WARRANTY AND SUPPORT

PocBuds products are designed and manufactured to the highest quality standards. For specific warranty information, please refer to the warranty card included with your purchase or contact PocBuds customer support.

If you encounter any issues or have questions regarding your PocBuds Open Ear Headphones, please visit the official PocBuds store or contact their customer service for assistance.

PocBuds Store: <https://www.amazon.com/stores/PocBuds/>